

## PARTS PRICE LIST

123 751

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
5960	Gasket	ea. .02	.01	.01	45210	Washer	ea. .05	.03	.04
	In Pkgs. of 50					In Pkgs. of 10			
9172	Use 510693				45229	Belt	.67	.34	.42
9439	Bushing	.65	.39	.49	105344	Gasket	.46	.26	.32
13166	Use 1 Ea. 197402 and 306-06				105345	Gasket	.07	.04	.05
16869	Gasket	.03	.02	.02	106028	Plug	.02	.01	.01
16870	Shaft	4.37	2.42	3.02	106635	Washer	ea. .05	.03	.04
16871	Impeller	1.75	.87	1.09		In Pkgs. of 10			
16945	Shaft	.62	.31	.39	107190	Use 526868			
16967	Gasket	.05	.02	.03	107220	Cup	3.39	1.61	2.03
16981	Gear	1.54	1.01	1.16	107221	Cone	7.49	3.56	4.49
17358	Use 262-06				108712	Stud	.31	.19	.24
17416	Gasket	.25	.13	.16	108875	Use 661331			
17794	Bumper	.12	.07	.09	108878	Nut	.50	.30	.38
19889	Use 630728				108879	Nut	.50	.30	.38
23232	Bushing	.70	.39	.49	108932	Fuse	.06	5/.17	5/.21
24449	Use 251-07				109124	Bearing	2.65	1.26	1.58
30214	Gasket	2.06	1.13	1.42	109137	Facing	2.06	1.03	1.29
30264	Terminal	.03	.02	.03	109193	Gasket	.25	.13	.16
30328	Spacer	.05	.03	.04	109488	Facing	.08	.05	.06
31721	Pinion	1.80	1.05	1.32	110527	Bulb	.12		
31834	Terminal	ea. .01	12/.07	4/.03		Pkg. of 10			
	In Pkgs. of 12					# 1 to 9 Pkgs.		.75	.75
32039	Stud	.62	.37	.46		10 or more Pkgs.		.67	.75
32210	Bushing	.35	.19	.24	110678	Cap	.98	.65	.81
32220	Retainer	.07	.04	.05	112274	Gasket	.36	.19	.24
32232	Cap	.36	.20	.25	112593	Gasket	.07	.04	.05
32318	Packing	.12	.07	.09	112663	Use 252-10			
35412	Gasket	.15	.08	.10	112936	Plug	.25	.15	.19
36832	Bulb	.14			112971	Gasket	.02	10/.10	10/.13
	Pkg. of 10				113368	Holder	ea. .20	.12	.14
	# 1 to 9 Pkgs.		.87	.87		In Pkgs. of 5			
	10 or more Pkgs.		.77	.87	113370	Cable	ea. .15	.09	.11
36899	Gasket	5/.06	5/.03	.01		In Pkgs. of 2			
39002	Gasket	2.06	1.13	1.42	114702	Valve	1.54	.85	1.07
39201	Screw	.02	.01	.01	114842	Spring	.17	.10	.13
39409	Bolt	.15	.10	.12	114919	Clip	.05	.03	.04
39855	Screw	.46	.28	.33	115026	Bolt	.15	.09	.11
43181	Cup	3.26	1.55	1.96	115232	Gear	1.23	.68	.85
43308	Shaft	1.95	1.17	1.48	115233	Gear	1.23	.68	.85
43311	Disc	.51	.29	.36	115242	Gasket	2.06	1.13	1.42
43354	Gasket	.03	.02	.03	115252	Washer	.04	.02	.03
43370	Bushing	.60	.33	.41	115317	Pin	ea. .05	.03	.04
43372	Bushing	.50	.28	.35		In Pkgs. of 10			
43377	Impeller	1.54	.77	.97	115391	Retainer	.17	.09	.11
43416	Spring	.02	.01	.01	115436	Terminal	.01	20/.12	20/.15
43480	Gasket	.36	.19	.24	115502	Gear	5.45	2.73	3.40
43493	Flange	.62	.31	.39	120007	Use 125718			
43494	Gasket	ea. .15	.08	.10	120010	Gear	2.11	1.16	1.45
	In Pkgs. of 5				120013	Gear	1.65	.99	1.23
43519	Gasket	.20	.11	.14	120131	Cover	2.57	1.68	1.93
43529	Gasket	1.95	1.08	1.35	120457	Gasket	.10	.05	.06
43604	Shaft	2.42	1.34	1.68	120458	Gasket	.20	.10	.13
43605	Flange	1.03	.62	.77	120817	Spring	.05	.03	.04
43649	Gasket	.08	.04	.05	120818	End	2.42	1.33	1.66
43728	Disc	1.29	.72	.91	122073	Facing	1.54	.85	1.07
43863	Gasket	.10	.05	.06	122258	Gasket	.20	.10	.13
44271	Arm	1.03	.62	.72	122316	Bushing	.45	.27	.34
44285	Use 526868				122684	Cover	.05	.03	.04
44372	Use 526868				122685	Stud	.62	.37	.46
44384	Washer	ea. .05	.03	.04	122825	Bearing	6.75	3.21	4.01
	In Pkgs. of 10				123081	Washer	.17	.10	.13
44387	Washer	ea. .05	.03	.04	123098	Gasket	1.95	1.08	1.35
	In Pkgs. of 10				123577	Brush	ea. <del>15.21</del>	<del>.0710</del>	<del>.09 12</del>
44388	Washer	.05	.03	.04		In Pkgs. of 10			
44541	Use 282012				123749	Spring	.17	.10	.13
44961	Nipple	2/.07	15/.21	15/.26	123751	End	2.42	1.44	1.80

The symbols used in this book are explained on Page III.

1

December 1, 1953 - Printed in U. S. A.

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
123953	Nut	.30	.15	.19	130180	Plug	.02	.01	.01
123955	Nut	.25	.13	.16	130252	Bearing	1.00	.50	.60
123956	Bushing	.75	.41	.51	130262	Use 197275			
125718	Chain	12.86	7.71	9.65	130301	Bushing	.12	.06	.08
125727	Seat	.31	.19	.24	130302	Ratchet	.36	.22	.27
125728	Spring	.10	.06	.08	130315	Pin	.05	.03	.04
125729	Plug	.31	.19	.24	130338	Pawl	.25	.15	.19
125750	Sprocket	3.34	2.01	2.51	130400	Shaft	8.23	4.77	5.97
125778	Facing	2/1.75	2/.97	2/1.21	130408	Cup	2.79	1.33	1.67
125868	Bushing	.25	.15	.19	130562	Use 203-0624			
125917	Cover	1.70 <del>1.54</del>	.79	.94	130563	Use 252-06			
125920	Holder	.57	.37	.42	130796	Gasket	.25	.13	.16
125921	Use 661926				130980	Cup	1.23	.58	.74
125923	Retainer	.05	.03	.04	130983	Cup	.87	.41	.52
125924	Arm	.72	.36	.43	130984	Cone	2.32	1.10	1.39
125925	Screw	.46	.30	.35	130986	Washer	.07	4/.16	4/.20
125995	Retainer	ea. .05	.03	.04	131026	Grommet	.03	5/.10	5/.13
	In Pkgs. of 2				131243	Plug	.10	.06	.08
125999	Casing	.51	.29	.36	131248	Washer	.03	.02	.03
126001	Cross	2.83	1.70	2.12	131487	Retainer	.41	.23	.29
126002	Bearing	.25	.14	.18	131505	Sleeve	.02	.01	.01
126003	Wire	.05	.03	.04	131569	Rotor	.46	.23	.28
126010	Casing	.51	.29	.36	131572	Gear	1.03	.67	.77
126011	Use 173367				131611	Screw	.12	.07	.09
126119	Gasket	ea. .06	.03	.04	131624	End	.36	.22	.27
	In Pkgs. of 10				131644	Spring	.05	4/.12	4/.15
126190	Gasket	ea. .10	.05	.06	131646	Link	.36	.22	.27
	In Pkgs. of 10				131647	Nut	.20	.12	.15
126240	Belt	1.49	.72	.91	131648	Pin	.15	.09	.11
127045	Pin	1.39	.76	.96	131652	Link	.15	.09	.11
127047	Plug	.03	5/.10	5/.13	131657	Screw	.08	.05	.06
127053	Bearing	.89	.44	.55	131863	Bulb	.29		
127181	Pipe	3.03	1.82	2.27		Pkg. of 10			
127250	Hose	.20	.10	.13		# 1 to 9 Pkgs.	1.74	1.74	
127254	Gasket	.10	.05	.06		10 or more Pkgs.	1.54	1.74	
127267	Retainer	.17	.10	.13	131875	Cover	.08	.05	.06
127269	Screw	.12	5/.36	5/.45	131877	Gasket	.02	10/.10	10/.13
127273	Valve	ea. 1.29	.71	.88	131891	Casing	.77	.46	.58
	In Pkgs. of 6				131944	Screw	.03	.02	.03
127274	Bolt	.12	.07	.09	131971	Bushing	ea. .15	.07	.09
127276	Gasket	ea. .36	.19	.24		In Pkgs. of 10			
	In Pkgs. of 5				131980	Spring	ea. .05	.03	.04
127278	Cover	1.23	.74	.93		In Pkgs. of 10			
127279	Valve	ea. .93	.51	.65	131985	Wick	ea. .05	.03	.04
	In Pkgs. of 6					In Pkgs. of 5			
127365	Gasket	.15	.08	.10	132205	Cup	3.04	1.44	1.82
127366	Plug	.05	5/.12	5/.15	132247	Washer	ea. .15	.08	.10
127369	Gasket	.12	.06	.08		In Pkgs. of 5			
127375	Gasket	.15	.08	.10	132248	Cover	.03	.02	.03
127379	Pipe	2.11	1.27	1.58	132404	Spring	.17	.09	.11
127409	Muffler	4.89	2.67	3.34	132965	Plug	.15	.09	.11
127410	Insulator	.12	.07	.09	133028	Gasket	.07	.04	.05
127456	Shaft	3.34	2.01	2.51	133113	Bag	.31	.19	.24
127485	Spring	ea. .15	.09	.11	133193	Button	.17	.10	.13
	In Pkgs. of 5				133336	Collar	1.95	1.18	1.47
127499	Shaft	.25	.14	.18	133337	Bearing	.87	.44	.56
127502	Gear	1.39	.76	.96	133353	Ring	.10	.06	.08
127504	Gear	1.39	.76	.96	134029	Bearing	3.75	1.78	2.23
127604	Nut	.15	.09	.11	134030	Bearing	4.25	2.02	2.53
127605	Key	.02	.01	.01	134095	Spring	.12	.07	.09
127614	Bushing	.35	.21	.26	134207	Hose	.57	.29	.36
127615	Bushing	.30	.18	.23	134231	Use 1-0516			
127624	Cup	.80	.48	.60	134393	Nut	.05	.03	.04
127627	Shaft	4.22	2.53	3.17	134438	Spring	.05	4/.12	4/.15
127676	Use 252-06				134443	Pin	.82	.45	.57
128003	Gasket	.12	.06	.08	134517	Bushing	.25	.13	.16
128270	Hose	.46	.24	.30	135001	Nut	.02	.01	.01
130071	Bushing	.35	.18	.23	135005	Bolt	.12	.07	.09

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

165 758

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
135065	Bearing	2.90	1.45	1.81	157706	Pin	.72	.36	.45
135199	Plate	11.83	7.10	8.88	157721	Gasket	.25	.13	.16
135201	Case	21.19	12.86	16.08	157781	Shaft	5.14	3.09	3.86
135562	Gasket	.15	.08	.10	157792	Bushing	.40	.22	.28
135563	Gasket	.07	.04	.05	157856	Thermostat	2.83	1.61	2.02
136775	Lever	4.22	2.53	3.29	157861	Cup	.35	.21	.26
136783	Pin	.08	.05	.06	157875	Coupling	.87	.57	.66
136787	Washer	.03	.02	.03	157945	Cover	6.17	4.01	4.94
136806	Nut	.10	.06	.08	158115	Washer	.25	.13	.16
136813	Spring	.07	5/.20	5/.25	158131	Gasket	.20	.10	.13
136826	Spring	.03	.02	.03	158217	Coupling	.57	.34	.42
140554	Cover	.08	.05	.06	158218	Flange	1.03	.62	.77
140706	Bearing	.99	.49	.59	158219	Pin	.02	.01	.01
140844	Sleeve	.01	12/.07	4/.03	158261	Pad	.36	.22	.27
141068	Gear	7.82	4.69	5.86	158433	Spring	ea. .20	.12	.15
150030	Washer	.15	.08	.10		In Pkgs. of 10			
150078	Pin	1.49	.82	1.03	158622	Rotor	1.70	1.02	1.19
150079	Key	.20	.11	.15	158753	Washer	.03	.02	.02
150082	Plug	.03	.02	.03	159075	Pipe	4.22	2.53	3.17
150087	Bearing	.92	.45	.55	159121	Pipe	2.57	1.54	1.93
150324	Pipe	2.31	1.39	1.74	159143	Shaft	10.80	6.26	7.83
150441	Clip	.05	.03	.04	159207	Nut	.12	.07	.09
150454	Pawl	.31	.19	.24	159304	Spring	.30	.15	.19
150508	Bolt	.12	.07	.09	159476	Bolt	.12	.06	.08
150509	Nut	.05	.03	.04	159488	Shim	.08	.05	.06
150597	Muffler	5.61	3.09	3.86	160179	Retainer	.05	.03	.04
150792	Gear & Shaft	.62	.37	.46	160180	Felt	.03	.02	.02
150812	Ball	3.34	2.01	2.51	160185	Shackle	1.49	.77	.97
150948	Gasket	.05	10/.25	10/.31	160186	Shackle	1.49	.77	.97
150949	Use 524634				160191	Bearing	.60	.30	.38
151134	Bushing	.25	.15	.19	160202	Pin	.87	.44	.56
151227	Lever	.62	.37	.46	165008	Pin	1.54	.85	1.07
151229	Lever	.62	.37	.46	165010	Bearing	ea. .60	.30	.36
151231	Lever	.62	.37	.46		In Pkgs. of 10			
151606	Use 191600				165014	Arm	2.37	1.42	1.78
156006	Valve	ea. 1.39	.70	.87	165045	Gear	3.34	2.01	2.51
	In Pkgs. of 8				165048	Cup	2.57	1.22	1.54
156009	Valve	ea. .93	.46	.58	165051	Cup	1.96	.93	1.18
	In Pkgs. of 6				165052	Cone	2.78	1.32	1.67
156072	Gasket	.98	.49	.62	165085	Gasket	.25	.13	.16
156078	Use 168242				165148	Screw	.23	.13	.16
156090	Pin	.04	5/.10	5/.13	165160	Cone	5.15	2.45	3.09
156104	Gasket	ea. .03	10/.15	.02	165165	Shaft & Plug	8.74	5.07	6.34
	In Pkgs. of 10				165167	Cup	1.23	.58	.74
156114	Nut	.07	.04	.05	165168	Cone	3.45	1.64	2.07
156124	Gasket	.20	.10	.13	165174	Washer	.20	.10	.13
156229	Use 179828				165176	Retainer & Washer	.51	.29	.36
156305	Gasket	.46	.24	.30	165223	Pipe	2.83	1.70	2.12
156307	Gasket	.15	.08	.10	165225	Pipe	3.34	2.01	2.51
156314	Gasket	.15	.08	.10	165351	Spring	.20	.12	.15
156333	Facing	1.03	.51	.65	165391	Nut	.17	.10	.13
156526	Gasket	.20	.10	.13	165523	Bolt	.07	.04	.05
156660	Gear	10.29	5.14	6.43	165546	Clip	.46	.26	.32
156768	Gasket	.02	10/.10	10/.13	165572	Rod	6.53	3.92	4.90
157393	Use 156090					See Green Section			
157407	Gasket	2.31	1.29	1.60	165581	Spring	.30	.15	.19
157440	Manifold	4.11	2.67	3.34	165609	Lever	3.19	1.90	2.40
157571	Rotor	.67	.43	.50	165616	Spring	.08	.05	.06
157579	Screw	ea. .05	.03	.04	165634	Spring	.20	.11	.14
	In Pkgs. of 5				165667	Cone	5.15	2.45	3.09
157580	Nut	.03	.02	.02	165669	Gear	4.58	2.65	3.32
157586	Plate	2.31	1.39	1.63	165670	Shaft	8.74	5.07	6.34
157587	Cable	.26	.16	.18	165723	Stud	.62	.37	.46
157601	Wick	ea. .05	.03	.04	165724	End	3.34	1.84	2.30
	In Pkgs. of 5				165725	End	3.34	1.84	2.30
157604	Shield	ea. .36	.22	.25	165757	Cap	2.06	1.13	1.42
	In Pkgs. of 5				165758	Gear Cluster	10.80	6.48	8.11
157607	Wick	.05	.03	.04					

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
165759	Gear	5.91	3.55	4.43	167640	Spring	.15	.09	.11
165760	Gear	4.63	2.78	3.48	167744	Cover	1.03	.67	.77
165787	Clip	.05	4/.12	4/.15	167772	Washer	.05	5/.10	5/.13
165821	Plate	10.54	5.80	7.25	167798	Clip	.03	5/.10	5/.13
167019	Pin	ea. .72	.36	.45	167924	Cover	.05	.03	.04
	In Pkgs. of 8				167944	Control	.77	.42	.52
167020	Pin	ea. .72	.36	.45	166974	Bushing	2.42	1.33	1.66
	In Pkgs. of 8				167975	Bushing	1.75	.97	1.22
167033	Gasket	2.06	1.13	1.42	167976	Bushing	1.34	.74	.93
167040	Manifold	3.34	2.01	2.51	167977	Bushing	1.34	.74	.93
167044	Gasket	ea. .15	.08	.10	167984	Muffler	5.66	3.09	3.86
	In Pkgs. of 5				168006	Tank	14.61	8.76	10.95
167062	Ring	.12	.07	.09	168011	Gasket	.02	24/.30	24/.37
167067	Shim	.03	.02	.02	168032	Pulley	1.80	1.08	1.35
167068	Shim	.03	.02	.02	168175	Spring	7.71	4.27	5.34
167069	Shim	.03	.02	.02	168200	Screw	.05	.03	.04
167075	Cap	1.34	.80	1.00	168205	Facing	2/2.37	2/1.18	2/1.48
167087	Tube	.57	.34	.42	168229	Pulley	3.09	1.85	2.31
167126	Gear	1.54	.85	1.07	168230	Hub	2.31	1.39	1.74
167128	Strainer	2.47	1.48	1.85	168242	Gasket	.05	.03	.04
167132	Pipe	1.23	.74	.93	168265	Muffler	5.40	2.97	3.71
167136	Plug	.10	.06	.08	168305	Coupling	.87	.57	.66
167145	Screw	.10	.06	.08	168311	Pipe	3.34	2.01	2.51
167146	Washer	.03	.02	.02	168366	Spring	.20	.12	.15
167147	Plate	.62	.37	.46	168445	Lining Set	3.09	1.54	1.93
167148	Spacer	.17	.10	.13	168522	Spring	.17	.09	.11
167151	Cover	2.73	1.65	2.06	168535	Damper	ea. .10	.06	.08
167156	Washer	.20	5/.50	5/.60		In Pkgs. of 4			
167157	Valve	ea. 1.29	.65	.81	168543	Use 518937			
	In Pkgs. of 8				168594	Clamp	.12	4/.24	4/.30
167158	Valve	ea. .87	.44	.56	168634	Packing	4/.35	4/.18	4/.23
	In Pkgs. of 8				168851	Shaft	1.90	1.13	1.42
167160	Retainer	.17	.10	.13	168885	Screw	ea. .08	.05	.06
167161	Guide	1.85	1.11	1.39		In Pkgs. of 20			
167163	Gasket	ea. .25	.13	.16	170045	Pin	ea. .72	.36	.45
	In Pkgs. of 5					In Pkgs. of 6	X		
167178	Gasket	ea. .87	.44	.56	170046	Pin	ea. .72	.36	.45
	In Pkgs. of 5					In Pkgs. of 6			
167187	Use 168242				170047	Pin	ea. .72	.36	.45
167194	Gland	.41	.23	.29		In Pkgs. of 6			
167197	Bushing	.40	.22	.28	170141	Pipe	2.83	1.70	2.12
167198	Shaft & Impeller	3.03	1.67	2.09	170142	Pipe	3.34	2.01	2.51
167201	Washer	.17	.10	.13	170200	Bushing	.10	4/.20	4/.24
167202	Gasket	.03	.02	.02	170337	Cable	4.42	2.44	3.04
167220	Gasket	.41	.21	.26	170338	Cable	4.27	2.35	2.93
167238	Pipe	.51	.31	.39	170375	Coil	5.66	3.68	4.25
167282	Pipe	3.09	1.85	2.31	170376	Lock	1.80	1.08	1.35
167285	Pipe	5.09	3.05	3.82	170417	Core	1.65	.99	1.23
167287	Gasket	.15	.08	.10	170444	Spring	ea. .07	.04	.05
167320	Clip	.03	.02	.02		In Pkgs. of 5			
167329	Pin	.72	.36	.45	170475	Cock	.65	.33	.41
167334	Bushing	.35	.18	.23	170503	Sleeve	.05	4/.12	4/.15
167412	Knuckle	9.15	5.49	6.87	170508	Drive (E)	6.80	4.08	4.76
167424	Gear	4.58	2.65	3.32	170509	Housing	4.63	3.01	3.48
167435	Retainer	.51	.29	.36	170518	Packing	.06	.03	.04
167439	Retainer	.46	.24	.30	170616	Switch	2.06	1.34	1.54
167443	Shaft	8.74	5.07	6.34	170628	Pipe	3.09	1.85	2.31
167444	Block	.72	.43	.55	170643	Spring	.08	.05	.06
167446	Cone	4.68	2.22	2.81	170660	Screw	.05	.03	.04
167468	Gear	1.54	.85	1.07	170688	Clip	.05	.03	.04
167469	Shaft	.41	.23	.29	170710	Screw	.03	.02	.02
167470	Gear	1.54	.85	1.07	170765	Bolt	.15	.09	.11
167480	Cone	3.45	1.64	2.07	170899	Cap	2.06	1.13	1.42
167541	Pipe	2.83	1.70	2.12	171024	Manifold	4.11	2.67	3.34
167578	Bushing	.30	.15	.19	171030	Spring	.20	.12	.15
167579	Bushing	.40	.20	.25	171062	Pin	.10	2/.12	2/.15
167589	Rod	.46	.28	.35	171069	Shaft	1.54	.93	1.16
					171070	Pulley	2.42	1.44	1.80

## PARTS PRICE LIST

173 601

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
171071	Hub	1.49	.89	1.12	172546	Shackle	.62	.31	.39
171112	Switch	1.18	.71	.88	172547	Shackle	.62	.31	.39
171136	Collar	1.95	1.18	1.48	172553	Spring	.07	.04	.05
171138	Ball	.41	.23	.29	172554	Pin	.30	.15	.19
171154	Clip	.05	.03	.04	172555	Lock	.07	.04	.05
171288	Bumper	.57	.34	.42	172620	Shaft	1.23	.68	.85
171397	Terminal	.05	10/.28	10/.35	172622	Gasket	.04	10/.20	10/.25
171409	Cable	4.89	2.93	3.66	172631	Plug	.06	4/.12	4/.15
171410	Cable	4.22	2.32	2.91	172651	Clip	.05	4/.12	4/.15
171414	Leaf	3.34	1.84	2.30	172652	Clip	.05	4/.12	4/.15
171415	Leaf	2.47	1.36	1.70	172653	Clip	.05	4/.12	4/.15
171417	Lever	.67	.40	.50	172654	Clip	.05	4/.12	4/.15
171418	Lever	.67	.40	.50	172732	Spring	.31	.19	.24
171433	Cover	.41	.25	.31	172754	Gasket	ea. 1.95	1.08	1.35
171439	Screw	.08	.05	.06		In Pkgs. of 4			
171440	Nut	.31	.19	.24	172783	Shim	.02	.01	.01
171466	Pipe	3.34	2.01	2.51	172813	Packing	4/.35	4/.18	4/.23
171498	Conduit	.57	.37	.46	172814	Nut	.51	.26	.32
171499	Cap	ea. .12	.07	.09	172815	Washer	.17	.10	.13
	In Pkgs. of 10				172817	Hub	1.49	.89	1.12
171500	Plug	.10	2/.12	2/.15	172821	Shaft & Impeller			
171502	Ferrule	.05	4/.12	4/.15			3.34	1.85	2.31
171571	Screw	.12	.07	.09	172824	Gasket	.07	.04	.05
171583	Ball	.46	.26	.32	172826	Gasket	.05	.03	.04
171584	Knob	.41	.25	.31	172840	Bearing	.85	.43	.54
171585	Spring	ea. .07	.04	.05	172870	Shoe	.10	.05	.06
	In Pkgs. of 10				172901	Bushing	.30	.15	.19
171601	Stud	.15	.09	.11	172902	Bushing	.30	.15	.19
171634	Retainer	.60	.30	.36	172938	Terminal	.04	5/.10	5/.13
171683	Ring	.96	.48	.58	172987	Clevis	.45	.27	.34
171688	Ring	.96	.48	.58	173050	Spacer	.02	.01	.01
171724	Core	1.65	.99	1.23	173053	Yoke	6.38	3.51	4.38
171780	Bushing	.15	.10	.12	173064	Case	20.31	12.19	15.23
171831	Bracket	.31	.19	.24	173065	Plate	27.26	16.35	20.45
171833	End	.31	.19	.24	173084	Pipe	3.09	1.85	2.31
171835	Link	.20	.12	.15	173086	Wick	.03	.02	.02
171839	Washer	15/.22	15/.11	15/.14	173088	Collar	1.95	1.18	1.48
171886	Washer	12/.18	12/.09	.01	173092	Case	16.71	10.03	12.54
171892	Fan	8.13	4.88	6.10	173112	Case	18.00	10.80	13.51
171893	Blade	.82	.49	.62	173123	Bracket	.57	.34	.42
171894	Blade	.82	.49	.62	173124	Use 525055			
171914	Screw	.10	.06	.08	173125	Muffler	4.89	2.67	3.34
171958	Stud	.62	.37	.46	173127	Retainer	.12	.07	.09
171969	Bolt	.17	.09	.11	173161	Leaf	2.73	1.50	1.88
171972	Terminal	.10	4/.24	4/.30	173170	Insulator	.06	4/.15	4/.19
172050	Brush	.10	.05	.06	173183	Washer	.36	.22	.27
172201	Packing	3/.30	3/.15	3/.19	173199	Use 173466			
172203	Cover	.72	.43	.55	173211				
172269	Gasket	ea. .20	.10	.13	173212				
	In Pkgs. of 5				173213				
172294	Flywheel	5.14	3.09	3.86	173214	Use 526225			
172295	Disc	.46	.28	.35	173215				
172297	Spacer	.08	.05	.06	173216				
172298	Cushion	.10	.06	.08	173246	Valve	.15	.09	.11
172310	Sprocket	2.98	1.80	2.25	173254	Cover	1.54	.77	.93
172386	Pulley	1.54	.93	1.16	173258	Collar	ea. .26	.17	.20
172387	Nut	.10	.05	.06		In Pkgs. of 2			
172391	Spacer	.05	.03	.04	173322	Ring	.96	.48	.58
172416	Outlet	1.23	.74	.93	173367	Spring	.12	.07	.09
172420	Gear	1.54	.85	1.07	173422	Gear	1.55	.85	1.06
172436	Gasket	.20	.12	.15	173423	Gear	1.39	.76	.96
172438	Pin & Cone	4.01	2.41	3.01	173426	Clip	.05	.03	.04
172439	Rollers	.60	.36	.45	173466	Pinion	15.02	9.01	11.26
172454	Pipe	3.34	2.01	2.51	173496	Bushing	.30	.15	.19
172457	Case	17.23	10.34	12.92	173513	Cables	3.70	2.04	2.55
172458	Plate	10.54	5.80	7.25	173514	Cables	3.96	2.18	2.73
172512	Clip	.04	.02	.03	173551	Spring	.20	.12	.15
172539	Use 679609				173601	Guide	1.85	1.11	1.39

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
173602	Nut	.03	.02	.02	175346	Gasket	.10	.05	.06
173621	Retainer	.03	.02	.02	175359	Washer	.36	.22	.27
173639	Use 518999				175360	Washer	.67	.40	.50
173641	Spring	.05	.03	.04	175363	Plug	.01	2/.01	.01
173649	Muffler	7.71	4.25	5.31	175387	Arm(E)	.25	.14	.18
173662	Use 518999				175388	Shaft	1.80	1.17	1.35
173663	Use 518999				175495	Spring	.05	.03	.04
173664	Use 518999				175589	Spring	.20	.12	.15
173771	Washer & Retainer	.67	.37	.46	175595	Cap	2.57	1.68	1.93
173779	Shaft	32.40	17.85	22.31	175691	Washer	.02	.01	.01
173780	Shaft	9.00	5.23	6.53	175758	Rod	.25	.15	.19
173890	Pipe	3.60	2.31	2.89	175847	Chain	7.41	4.07	5.09
173891	Pipe	3.34	2.01	2.51	175885	Lock & Keys	1.29	.77	.97
174035	Shaft	10.18	5.90	7.39	175887	Contact	.51	.34	.39
174039	Cap	1.34	.80	1.01	175895	Washer	.12	.07	.09
174053	Washer	ea. .67	.37	.46	175960	Cam (E)	2.05	1.11	1.44
	In Pkgs. of 10				175961	Cover (E)	1.34	.72	.94
174060	Washer	.57	.34	.42	175964	Insulator (E)	.01	2/.01	.01
174110	Pipe	3.34	2.01	2.51	175965	Bushing (E)	.02	.01	.01
174149	Bracket	2.31	1.39	1.74	175966	Washer (E)	.01	20/.11	20/.14
174209	Cable	3.96	2.18	2.73	175967	Condenser (E)	.98	.53	.69
174225	Terminal	.01	24/.14	24/.18	175968	Plate (E)	.31	.17	.22
174259	Muffler	4.63	2.55	3.19	175969	Holder (E)	.35	.19	.25
174332	Spring	.12	.06	.08	175970	Nut	.04	.02	.03
174346	Plate	14.40	7.92	9.91	175975	Collar (E)	.22	.12	.15
174466	Cable	4.58	2.52	3.15	175976	Clip (E)	.06	.04	.05
174491	Collar	1.95	1.18	1.48	175979	Pipe	2.83	1.70	2.12
174527	Nut	.05	.03	.04	175982	Pipe	3.09	1.85	2.31
174528	Clip	.02	10/.10	10/.13	175988	Hose	.25	.13	.16
174533	Cam	2.06	1.34	1.54	176073	Spring	.20	.12	.15
174534	Rotor	.51	.26	.31	176094	Lifter	1.08	.60	.75
174539	Base	4.11	2.67	3.09	176147	Washer	.06	.04	.05
174545	Gasket	ea. .02	.01	.01	176189	Switch	.77	.46	.58
	In Pkgs. of 10				176195	Joint	13.78	7.58	9.47
174590	Shaft	9.00	5.23	6.53	176200	Use 510775			
174664	Pinion	1.80	1.08	1.35	176201	Use 524262			
174688	Guide	.36	.19	.24	176203	Spring (E)	.13	.07	.09
174833	Use 187169				176206	Shield (E)	.24	.13	.17
174835	Valve	ea. 1.29	.65	.81	176208	Bushing (E)	ea. .25	.14	.18
	In Pkgs. of 6					In Pkgs. of 20			
174836	Valve	ea. .93	.46	.58	176223	Washer	.02	10/.10	10/.13
	In Pkgs. of 6				176225	Relay (E)	3.10	1.67	2.17
174837	Seat	.08	12/.48	12/.60	176226	Brush (E)	.29	.16	.20
174839	Switch	1.03	.67	.77	176227	Bolt	.05	.03	.04
174969	Nut	.15	.08	.10	176228	Spring	.10	.06	.08
174970	Nut	.15	.08	.10	176266	Spring	.03	.02	.02
174998	Cap	2.06	1.13	1.42	176267	Spring	.03	.02	.02
175001	Latch	.25	.15	.19	176304	Shaft	4.22	2.53	3.17
175002	Diaphragm	.12	.07	.09	176320	Plate	.36	.22	.27
175003	Washer	.03	.02	.02	176321	Ring	.05	.03	.04
175022	Switch	10.29	5.66	7.08	176322	Gasket	.03	.02	.03
175136	Spring	.03	.02	.02	176325	Oil Seal	.85	.43	.51
175137	Cup	.02	.01	.01	176327	Countershaft	1.13	.68	.85
175138	Cup	.02	.01	.01	176336	Washer	.25	.15	.19
175149	Belt	2.21	1.06	1.33	176338	Spring	.03	.02	.02
175150	Cable	4.11	2.26	2.83	176344	Gear	3.60	2.16	2.71
175181	Radimeter	4.11	2.47	3.09	176351	Gasket	.07	.04	.05
175187	Gage	2.06	1.23	1.54	176352	Pinion	12.86	7.71	9.65
175188	Ammeter	1.80	1.08	1.35	176355	Gasket	.05	.03	.04
175254	Pinion	22.11	13.27	16.59	176361	Gear Cluster	15.17	9.10	11.38
175317	Bearing	.70	.42	.53	176363	Roller	.12	.07	.09
175326	Pinion	13.22	7.93	9.92	176366	Washer	.72	.43	.55
175328	Ring	.07	.04	.05	176368	Washer	.72	.43	.55
175329	Countershaft	1.65	.99	1.23	176369	Sleeve	3.86	2.31	2.89
175330	Cluster	19.29	11.57	14.46	176400	Plunger	.02	.01	.01
175332	Shaft	.72	.43	.55	176401	Ring	.10	.06	.08
175335	Gear	6.43	3.86	4.82	176404	Screw	.02	.01	.01

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

179 974

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
176533	Pump	8.45			178705	Spacer	.25	.13	.16
	#Lots of 1 to 5		5.15	5.15	178707	Gasket	ea. .12	.06	.08
	6 to 11		4.73	4.73		In Pkgs. of 10			
	12 or more		4.31	4.31	178726	Bolt	.62	.34	.42
176541	Bolt	.05	.03	.04	178748	Nut	.06	.03	.04
176542	Swivel	.30	.15	.19	178762	Bolt	.07	.04	.05
176716	Rod	4.83	2.90	3.63	178769	Retainer	.03	.02	.02
176733	Use 173065				178770	Washer	.02	.01	.01
176747	Plate	6.43	3.86	4.82	178789	Bushing	.40	.20	.25
176762	Use 518937				178802	Crankshaft	73.80	47.98	59.98
176764	Spring	.25	.14	.18	178804	Connector	1.10	.55	.66
176772	Lever	.77	.46	.58	178832	Washer	.46	.26	.32
176774	Collar	1.44	.87	1.09	178858	Bearing	2.75	1.65	2.06
176873	Clip	.08	.05	.06	178862	Bearing	3.05	1.83	2.29
176917	Collar	1.18	.65	.81	178866	Bearing	1.95	1.17	1.46
177034	Cap	.70	.39	.49	178870	Spacer	.36	.19	.24
177041	Use 665945				179070	End	1.08	.60	.75
177082	Bearing	.67	.43	.50	179071	End	1.08	.60	.75
177128	Washer & Retainer	.87	.44	.56	179072	Stud	.62	.37	.46
177302	Washer	.07	.04	.05	179073	Bearing	.12	.07	.09
177303	Spring	.05	.03	.04	179074	Bushing	.17	.09	.11
177336	Screw	.03	.02	.02	179075	Washer	.05	.03	.04
177339	Yoke	2.83	1.70	2.12	179093	Plate & Point	.57	.31	.37
177351	Bolt	.15	.08	.10	179094	Plate & Point	.51	.26	.31
177413	Washer	ea. .01	2/.01	.01	179119	Pipe	3.29	1.97	2.47
	In Pkgs. of 20				179233	Nut	.15	.09	.11
177496	Gasket	.41	.21	.26	179240	Bolt	.10	.06	.08
177731	Gasket	.20	.10	.13	179319	Gasket	.10	.05	.06
177976	Gasket	ea. .38	.19	.23	179328	Pin	1.54	.85	1.07
	In Pkgs. of 10				179363	Leaf	2.47	1.36	1.70
177979	Gasket	ea. .12	.06	.07	179369	Screw	ea. .05	.03	.04
	In Pkgs. of 10					In Pkgs. of 10			
178022	Shaft & Impeller	3.03	1.67	2.09	179378	Lock	.05	.03	.04
178128	Packing	.03	.02	.02	179382	Plug	.10	4/.24	4/.30
178199	Gasket	2.06	1.13	1.42	179386	Gasket	.03	.02	.03
178228	Core & Shaft	4.01	2.41	3.01	179387	Piston	1.60	.96	1.20
178242	Gasket	.20	.12	.15	179399	Washer	ea. .05	.03	.04
178270	Gasket	ea. .30	.15	.19		In Pkgs. of 5			
	In Pkgs. of 5				179400	Retainer	ea. .03	.02	.03
178271	Gasket	ea. .15	.08	.10		In Pkgs. of 5			
	In Pkgs. of 5				179402	Use 173246			
178272	Gasket	ea. .12	.06	.08	179403	Spring	.05	.03	.04
	In Pkgs. of 10				179434	Thermostat	2.00	1.20	1.50
178277	Screw	.10	.06	.08	179463	Retainer	.25	.15	.19
178294	Rod	6.53	3.92	4.90	179465	Link	.65	.39	.46
	See Green Section				179466	Facing	2/1.75	2/.97	2/1.21
178295	Use 518935				179524	Power Unit	21.24	12.74	15.93
178296	Use 187550				179537	Rod	.62	.37	.46
178299	Washer	.36	.20	.25	179539	Rod	.25	.15	.19
178357	Gasket	.20	.10	.13	179578	Gasket	ea. .03	.02	.03
178371	Body, Shaft & Gear	8.85	4.87	6.08		In Pkgs. of 5			
178373	Collar	.31	.19	.24	179587	Switch	.77	.46	.58
178387	Pin	.04	.02	.03	179605	Cable	3.91	2.15	2.68
178388	Belt	2.06	.99	1.23	179608	Cable	3.91	2.15	2.68
178407	Use 636814				179634	Jet	.40	.24	.30
178447	Case	14.14	8.49	10.60	179638	Valve	.20	.12	.15
178450	Gear	3.34	1.70	2.12	179639	Jet	.70	.42	.53
178454	Spring	.05	.03	.04	179645	Spring	.10	.06	.08
178509	Gasket	5/.06	50/.30	50/.38	179648	Float	1.05	.63	.79
178515	Screw	.17	.09	.11	179715	Boot	.30	.18	.23
178537	Gasket	ea. .05	.03	.04	179828	Gasket	.25	.13	.16
	In Pkgs. of 10				179878	Use 517087			
178594	Terminal	.02	24/.24	24/.30	179965	Cover	2.73	1.65	2.06
178599	Impeller	1.34	.67	.83	179966	Gasket	ea. .20	.10	.13
178699	Nut	.35	.20	.25		In Pkgs. of 5			
					179973	Packing	.06	.03	.04
					179974	Use 186692			

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
180007	Pipe	.51	.31	.39	181197	Rod	4.63	2.78	3.48
180009	Shaft	1.39	.76	.96			See Green Section		
180010	Body, Shaft & Gears	7.05	3.88	4.84	181218	Bearing	3.35	1.84	2.30
180011	Gasket	.12	.06	.08	181222	Bearing	1.85	1.02	1.28
180054	Gasket	ea. .22	.11	.13	181226	Bearing	2.50	1.38	1.73
	In Pkgs. of 10				181230	Rod	5.04	3.02	3.79
180062	Gasket	.20	.10	.13			See Green Section		
180132	Piston	4.89	2.67	3.34	181231	Tank Unit	2.78	1.67	2.09
180138	Piston	4.89	2.67	3.34	181233	Gear	9.05	4.53	5.66
180165	Cables	4.27	2.35	2.93	181237	Gear	3.34	1.70	2.12
180286	Valve	.57	.34	.42	181259	Bushing	.40	.24	.30
180437	Cushion	.40	.22	.24	181262	Post	9.77	6.36	7.95
180575	Retainer	.17	.10	.13	181266	Shaft	10.29	6.17	7.71
180673	Spacer	.36	.19	.24	181275	Pin & Race	3.19	1.91	2.40
180674	Gasket	ea. .35	.18	.21	181276	Washer	.02	.01	.01
	In Pkgs. of 10				181277	Nut	.03	.02	.02
180699	Rod	4.63	2.78	3.48	181280	Screw (E)	.05	4/.12	4/.15
		See Green Section			181282	Washer	.03	.02	.02
180700	Rod	4.63	2.78	3.48	181307	Gasket	.03	.02	.03
		See Green Section			181313	Nipple	.05	.03	.04
180703	Gasket	ea. .20	.10	.13	181314	Fitting	ea. .07	.04	.05
	In Pkgs. of 5						In Pkgs. of 10		
180704	Lifter	ea. .93	.51	.65	181317	Use 730-02			
	In Pkgs. of 6				181325	Screw	.05	.03	.04
180706	Flywheel	10.80	6.48	8.11	181326	Plate	ea. .03	.02	.03
180708	Cover	2.73	1.65	2.06			In Pkgs. of 10		
180737	Bushing	.45	.25	.31	181331	Screw	.25	.15	.19
180741	Shackle	.93	.46	.58	181364	Gun	1.49	.89	1.12
180742	Bushing	.55	.30	.38	181372	Housing	.41	.25	.31
180747	Washer	.05	4/.12	4/.15	181385	Shield	.02	.01	.01
180767	Washer & Retainer	.51	.26	.32	181386	Bearing	ea. 1.05	.58	.73
180777	Shaft	8.49	4.93	6.16			In Pkgs. of 4		
180793	Rod	5.40	3.24	4.05	181387	Retainer	.02	.01	.01
180800	Plug	.02	.01	.01	181388	Washer	.02	.01	.01
180802	Shackle	.93	.51	.65	181389	Cross	1.29	.71	.88
180803	Shackle	.93	.51	.65	181394	Manifold	15.69	10.19	12.74
180804	Bushing	.55	.30	.38	181408	Joint	8.90	4.90	6.12
180811	Spring	16.66	9.16	11.46	181422	Flange	3.60	2.16	2.71
180833	Bolt	.67	.37	.46	181435	Jaw	.72	.43	.55
180834	Bushing	.40	.22	.28	181440	Leaf	3.81	2.10	2.62
180850	Cable	4.58	2.75	3.44	181466	Cable	5.66	4.24	4.88
180872	Rod	.31	.19	.24	181467	Cable	5.66	4.24	4.88
180877	Pipe	.67	.40	.50	181485	Stud	.21	.12	.15
180878	Muffler	6.17	3.39	4.25	181486	Stud	.21	.12	.15
180879	Muffler	6.69	3.68	4.61	181492	Gear	12.19	6.12	7.65
180880	Pipe	3.60	1.99	2.48	181493	Gear	12.19	6.12	7.65
180888	Pipe	3.50	1.93	2.41	181500	Pinion	2.06	1.23	1.54
180953	Hanger	.23	.14	.18	181506	Use 723-03			
180969	Gear Cluster	15.38	9.23	11.53	181510	Cap	4.73	2.60	3.25
180970	Gear	7.71	4.63	5.79	181511	Cap	1.80	.99	1.23
180972	Gear	5.66	3.39	4.25	181531	Use 192314			
180976	Pinion	12.86	7.71	9.65	181545	Spring	.62	.37	.46
180979	Pipe	3.09	1.70	2.12	181546	Modifier (E)	2.15	1.16	1.51
180996	Tube	2.31	1.28	1.59	181550	Use 181551			
180997	Tube with ends	8.13	4.47	5.60	181551	Rod	.51	.31	.39
181038	Spring	.20	.12	.15	181552	Washer	.05	.03	.04
181039	Valve & Shaft	1.75	1.05	1.32	181553	Distributor (E)	12.45	6.72	8.72
181041	Washer	.51	.31	.39	181563	Plate	3.03	1.82	2.27
181059	Switch	1.18	.71	.88	181590	Ring	.66	.33	.40
181071	Ring	.08	.05	.06	181595	Ring	.66	.33	.40
181135	Tank	18.35	11.00	13.75	181604	WSupport	.72	.43	.55
181136	Tank	15.40	9.25	11.56	181619	Shell- Prime	30.55	19.85	24.82
181169	Hanger	2.16	1.41	1.76	181657	Spacer	ea. .03	.02	.03
181196	Rod	4.63	2.78	3.48			In Pkgs. of 10		
		See Green Section			181658	Spacer	.03	.02	.02
					181659	Spacer	.03	.02	.02
					181660	Spacer	.03	.02	.02
					181661	Spacer	.03	.02	.02



## PARTS PRICE LIST

183 032

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
181683	Bearing	1.10	.55	.66	182143	Pin	ea. .05	.03	.04
181693	Bushing	.50	.30	.38		In Pkgs. of 10			
181694	Bushing	1.75	1.05	1.31	182139	Screw	.10	.06	.08
181695	Nut	.45	.27	.34	182208	Race	.95	.57	.71
181697	Packing	4/.35	4/.18	4/.23	182239	Pipe	3.75	2.07	2.58
181698	Shaft & Impeller	2.73	1.39	1.74	182271	Cover (E)	1.70	.92	1.19
181699	Impeller	1.34	.67	.83	182273	Adjuster	.46	.26	.32
181700	Washer	.17	.10	.13	182274	Adjuster	.46	.26	.32
181714	Shaft	10.29	6.17	7.71	182277	Spring	.05	.03	.04
181716	Post	9.77	6.36	7.95	182313	Shim	.06	.03	.04
181718	Retainer	.36	.22	.27	182314	Shim	.10	.06	.08
181726	Flange	1.03	.62	.77	182315	Shim	.10	.06	.08
181728	Flange	1.03	.62	.77	182320	Washer	.08	.05	.06
181731	Bolt	.03	.02	.02	182321	Washer	.04	.02	.03
181733	Arm (E)	.25	.14	.18	182329	Spring	9.87	5.45	6.82
181742	Bolt (E)	.07	.04	.05	182332	Terminal	ea. .15	.08	.10
181749	Shaft	8.74	5.07	6.34		In Pkgs. of 10			
181751	Key	.20	.12	.15	182348	Distributor	23.14	15.05	17.36
181753	Washer	.12	.06	.08	182349	Cap	2.83	1.84	2.12
181776	Shaft	9.00	5.23	6.53	182350	Cover	.93	.56	.65
181778	Gasket	.25	.13	.16	182396	Retainer & Washer	1.03	.62	.77
181782	Use 63X33				182413	Gasket	ea. .03	.02	.03
181785	Pinion	2.31	1.54	1.93		In Pkgs. of 5			
181786	Block	1.03	.62	.77	182415	Screw	.25	.15	.19
181787	Shaft	1.29	.75	.94	182416	Washer	.05	.03	.04
181788	Screw	.17	.09	.11	182417	Nut	.17	.09	.11
181789	Washer	.36	.22	.27	182483	Fuse	.06	5/.17	5/.21
181790	Washer	.17	.10	.13	182522	Spring	ea. .08	.05	.06
181794	Cone	5.61	2.66	3.37		In Pkgs. of 10			
181814	Clip	.05	.03	.04	182523	Clip	.05	.03	.04
181822	Stud	.15	.09	.11	182538	Retainer	.06	.03	.04
181825	Bushing	.55	.30	.38	182539	Washer	.06	8/.28	8/.35
181832	Thermostat	4.00	2.40	3.00	182540	Ring	ea. .06	.03	.04
181836	Clip	.05	.03	.04		In Pkgs. of 24			
181849	Switch	1.18	.71	.88	182541	Bearing	.89	.49	.61
181850	Button & Wire	.51	.31	.39	182546	Retainer	.07	.04	.05
181852	Switch	1.29	.93	1.13	182547	Washer	.07	4/.16	4/.20
181878	Pump	9.75			182550	Cap	.41	.23	.29
	#Lots of 1 to 5		5.94	5.94	182561	Plug	.15	.09	.11
	6 to 11		5.46	5.46	182574	Adjuster	.46	.26	.32
	12 or more		4.97	4.97	182575	Adjuster	.46	.26	.32
181882	Use 182746				182578W	Retainer	1.23	.74	.93
181884	Harness	2.67	1.60	2.01	182587	Use 186317			
181920	Grommet	.17	.10	.13	182589	Spring (E)	.21	.12	.15
181985	Fitting (E)	.22	.12	.15	182592	Spring	10.18	5.61	7.00
182000	Eccentric	.15	.08	.10	182606	Rod	2.42	1.45	1.81
182001	Spring	.05	.03	.04	182697	Lever (E)	ea. .36	.20	.25
182002	Spring	.20	.12	.15		In Pkgs. of 24			
182003	Spring	.12	.07	.09	182698	Spring (E)	.17	.09	.11
182010	Retainer	.05	.03	.04	182700	Pin (E)	.05	.03	.04
182011	Retainer	.02	.01	.01	182701	Strut (E)	.10	.06	.08
182017	Clevis	.51	.36	.45	182703	Plate (E)	9.00	4.95	6.19
182018	Screw	.15	.08	.10	182711	Shaft	9.00	5.23	6.53
182022	Gage	2.06	1.23	1.54	182712	Leaf	2.47	1.36	1.70
182035	Housing, Lock & Keys (E)	6.15	3.32	4.31	182739	Stud	.12	.07	.09
182036	Coil (E)	6.70	3.62	4.69	182746	Pump	7.40		
182050	Clip	.05	.03	.04		# Lots of 1 to 5		4.51	4.51
182073	Coil	4.17	2.73	3.13		6 to 11		4.14	4.14
182075	Spring	.06	5/.18	5/.23		12 or more		3.77	3.77
182076	Valve	.17	.10	.13	182828	Pin	1.54	.85	1.07
182077	Use 199438				182920	Bushing	ea. .25	.13	.16
182083	Pilot	.05	.03	.04		In Pkgs. of 8			
182084	Plate	.05	4/.12	4/.15	182998	Control	.82	.49	.62
182099	Nut	.08	.04	.05	183011	Shaft (E)	4.00	2.16	2.80
182101	Cleaner	2.21	1.33	1.66	183026	Ring	.66	.33	.40
182132	Gasket	.05	.03	.04	183030	Ring	.66	.33	.40
					183032	Ring	.66	.33	.40

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
183033	Ring	.66	.33	.40	184012	Use 521878			
183034	Ring	.66	.33	.40	184020	Pipe	3.50	1.93	2.41
183046	Seat	1.40	.84	1.05	184030	Gasket	ea. .05	10/.25	.04
183047	Use 187069					In Pkgs. of 10			
183051	Valve	1.70	1.02	1.28	184041	Use 181718			
183105	Relay (E)	3.10	1.67	2.17	184057	Rod	.51	.31	.39
183139	Gasket	.17	.09	.11	184095	Cover (E)	15.15	8.33	10.41
183191	Pipe	3.60	1.99	2.48		See Green Section			
183205	Link	1.95	1.17	1.46	184110	Coupling (E)	.33	.18	.23
183214	Cushion	.07	.04	.05	184115	Pinion	.62	.34	.42
183215	Cushion	.07	.04	.05	184116	Pinion	.62	.34	.42
183221	Screw	.17	.10	.13	184156	Pipe	2.06	1.23	1.54
183227	Regulator	7.97	5.18	5.98	184161	Gasket	.05	5/.15	5/.19
183250	Link	.41	.25	.29	184168	Sleeve	.36	.22	.27
183277	Stop	.15	.09	.11	184173	End	3.34	1.84	2.30
183279	Guide	1.85	1.11	1.39	184174	End	3.34	1.84	2.30
183281	Switch (E)	1.39	.75	.97	184175	Rod	6.94	3.82	4.77
183288	Fork	1.80	1.08	1.35	184176	Rod	7.46	4.10	5.13
183289	Plate	.62	.37	.46	184177	Cover	.05	.03	.04
183290	Spring	.05	.03	.04	184192	Retainer	.05	.03	.04
183303	Spring	.13	.08	.09	184195	Shaft	5.09	3.05	3.82
183306	Thermostat	2.52	1.44	1.80	184196	Shaft	5.09	3.05	3.82
183307	Thermostat	2.52	1.44	1.80	184234	Washer	.05	.03	.04
183316	Washer	ea. .03	.02	.02	184269	Pump	7.40		
	In Pkgs. of 10					# Lots of 1 to 5		4.51	4.51
183323	Oiler	ea. .05	.03	.04		6 to 11		4.14	4.14
	In Pkgs. of 10					12 or more		3.77	3.77
183327	Gasket	.05	.03	.04	184274	Chain	6.17	3.39	4.25
183332	Spring	ea. .05	.03	.04	184277	Rod	1.00	.60	.75
	In Pkgs. of 10				184287	Rod	.25	.15	.19
183333	Spring	ea. .05	.03	.04	184288	Stud	.15	.09	.11
	In Pkgs. of 10				184289	Crank	.31	.19	.24
183335	Brush	ea. .20	.10	.12	184290	Stud	.17	.10	.13
	In Pkgs. of 10				184291	Washer	.02	10/.10	10/.13
183339	Arm	.20	.12	.14	184294	Collar	.10	.06	.08
183342	Ring	.04	.02	.03	184327	Use 165523			
183344	Retainer	.01	2/.01	.01	184341	Link	.60	.36	.45
183345	Use 673910				184343	Bushing	.30	.18	.23
183347	Cover (E)	.14	.08	.10	184351	Pipe	3.34	1.84	2.30
183348	Gasket	ea. .02	.01	.01	184352	Bracket	.41	.25	.31
	In Pkgs. of 10				184365	Knuckle	11.83	7.10	8.88
183397	Pipe	3.09	1.70	2.12	184367	Spring	11.01	6.07	7.59
183452	Absorber	5.90	3.84	4.43	184368	Spring	19.29	10.60	13.26
183495	Link	3.86	2.31	2.89	184369	Spring	19.29	10.60	13.26
183543	Ring	1.80	.99	1.23	184371	Leaf	2.88	1.58	1.99
183546	Bushing	.50	.25	.31	184372	Leaf	3.96	2.18	2.73
183599	Lock	.15	.09	.11	184413	Nut	.05	8/.24	8/.30
183613	Screw	.12	.07	.09	184421	Cylinder	54.65	38.26	45.09
183616	Case	12.34	7.16	8.95	184439	Gasket	ea. .06	.03	.04
183617	Case	12.86	7.71	9.65		In Pkgs. of 10			
183637	Manifold	7.71	5.02	6.27	184441	Oiler	.72	.40	.50
183639	Valve	.93	.56	.70	184442	Gasket	1.13	.57	.71
183640	Gasket	.12	.06	.08	184478	Screw	.17	5/.45	5/.56
183652	Handle	.72	.43	.55	184479	Screw	.17	.09	.11
183680	Arm	3.03	1.82	2.27	184486	Stud	.15	.08	.10
183701	Bushing	.72	.43	.55	184487	Stud	.15	.08	.10
183898	Gear	3.90	1.95	2.44	184526	Washer	.02	10/.10	10/.10
183904	Cup	3.66	1.74	2.20	184545	Screw	.17	.09	.11
183930	Gasket	ea. .05	.03	.04	184552	Plate	.67	.40	.50
	In Pkgs. of 5				184555	Outlet	1.65	.99	1.23
183931	Support	10.65	6.39	7.98	184558	Hose	.15	.08	.10
183932	Support	10.65	6.39	7.98	184560	Housing & Carrier	36.00	23.40	29.25
183935	Arm	10.29	6.17	7.71	184574	Hose	.15	.08	.10
183938	Use 186664				184576	Pipe	1.03	.67	.83
183939	Pin	.87	.52	.66	184593	Cable	.67	.40	.50
183954	Knuckle	11.83	7.10	8.88	184600	Use 196090			
183955	Knuckle	11.83	7.10	8.88	184619	Muffler	5.91	3.25	4.06
183985	Bolt	.87	.48	.61					

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

185 439

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
184620	Muffler	6.17	3.39	4.25	185038	Gage	.51	.31	.39
184624	Pipe	.87	.52	.66	185047	Cover	.05	.03	.04
184625	Pipe	3.03	1.67	2.09	185048	Seal	.05	.03	.04
184631	Gasket	ea. 2.25	1.24	1.46	185049	Spring	.04	.02	.03
	In Pkgs. of 5				185053	Body	9.00	5.40	6.75
184651	Gasket	ea. .93	.46	.58	185055	Harness	3.60	2.16	2.71
	In Pkgs. of 4				185057	Harness	4.63	2.78	3.48
184657	Pump	17.00			185059	Pump	18.00	10.80	13.51
	# Lots of 1 to 5		10.37	10.37	185063	Clip	.12	.07	.09
	6 to 11		9.52	9.52	185075	Gasket	.15	.08	.10
	12 or more		8.67	8.67	185086	Switch	.41	.25	.31
184674	Hub & Drum	15.43	8.49	10.60	185087	Spring	.20	.12	.15
184675	Hub & Drum	15.43	8.49	10.60	185091	Harness	1.90	1.14	1.43
184677	Hub & Caps	7.97	4.38	5.48	185092	Harness	2.57	1.54	1.93
184679	Stud	.15	.08	.10	185102	Harness	3.39	2.04	2.55
184680	Stud	.15	.08	.10	185107	Control	.82	.49	.62
184681	Stud	.21	.12	.15	185127	Switch	1.18	.71	.88
184682	Stud	.21	.12	.15	185136	Gear	2.57	1.54	1.93
184717	Use 520462				185138	Pinion	1.75	1.05	1.31
184752	Cable	3.60	2.35	2.93	185141	Pinion	1.75	1.05	1.31
184766	Thermostat	3.95	2.37	2.96	185145	Core	3.50	2.10	2.62
184767	Rod	.75	.45	.54	185146	Core	3.50	2.10	2.62
184778	Gasket	ea. .12	.06	.08	185148	Shaft	3.50	2.10	2.62
	In Pkgs. of 5				185153	Core	1.65	.99	1.23
184780	Moulding	9.05	5.88	7.35	185154	Core	1.65	.99	1.23
184794	Cable	3.60	2.35	2.93	185160	Use 515-05			
184795	Cable	3.60	2.35	2.93	185161	Fitting (E)	.38	.23	.27
184801	Shim	.10	.06	.08	185163	Screw x	.37	.22	.26
184802	Shim	.10	.06	.08	185164	Washer (E)	ea. .03	.02	.03
184803	Shim	.10	.06	.08		In Pkgs. of 10			
184804	Shim	.10	.06	.08	185165	Washer (E)	ea. .03	.02	.03
184805	Retainer	1.03	.62	.77		In Pkgs. of 10			
184807	Cleaner	4.22	2.53	3.17	185166	Washer (E)	ea. .03	.02	.03
184808	Washer	.17	.10	.13		In Pkgs. of 10			
184820	Deflector	1.39	.83	1.04	185167	Washer (E)	ea. .03	.02	.03
184824	Grille	5.50	3.29	4.11		In Pkgs. of 10			
184825	Grille	5.50	3.29	4.11	185169	Fitting (E)	.38	.23	.27
184834	Cap	4.11	2.26	2.83	185170	Screw (E)	.38	.23	.27
184838	Cap	4.11	2.26	2.83	185171	Fitting (E)	.50	.30	.35
184841W	Support	.72	.43	.55	185172	Screw (E)	.38	.23	.27
184870	Nut	.62	.37	.46	185175	Button	.36	.22	.27
184882	Shaft	9.51	5.52	6.90	185179	Gage	3.55	2.13	2.66
184885	Bushing	.25	.13	.16	185252	Plate	2.16	1.30	1.63
184898	Lock	.07	.04	.05	185256	Switch	1.18	.71	.88
184913	Cover	1.65	.91	1.13	185266	Ammeter	1.80	1.08	1.35
184929	Spring	.03	.02	.03	185267	Gage	2.98	1.79	2.24
184951	Clip	.05	.03	.04	185269	Radimeter	4.63	2.78	3.48
184954	Washer	.08	.05	.06	185302	Connector	.07	.04	.05
184973	Joint	ea. .30	.18	.23	185336	Swivel	.12	.06	.08
	In Pkgs. of 10				185344	Knuckle	11.83	7.10	8.88
184974	Bracket	.72	.43	.55	185345	Support	10.65	6.39	7.98
184976	Rod	4.89	2.93	3.66	185346	Support	10.65	6.39	7.98
184977	Rod	4.27	2.56	3.20	185361	Cover	.82	.49	.62
184996	Bushing	.55	.30	.38	185368	Bulb	.11		
185004	Pipe	.36	.19	.24		Pkg. of 10			
185005	Pipe	.67	.34	.42		# 1 to 9 Pkgs.		.69	.69
185006	Pipe	.62	.31	.39		10 or more Pkgs.		.61	.69
185008	Pipe	1.34	.67	.83	185387	Gasket	ea. .02	.01	.01
185011	Pipe	.87	.44	.56		In Pkgs. of 10			
185014	Use 515-04				185389	Screen	.16	.10	.11
185015	Hose (E)	1.86	.93	1.12	185400	Gasket	.02	.01	.01
185016	Tee (E)	.65	.39	.46	185428	Bushing	.50	.30	.38
185017	Tee (E)	.56	.34	.39	185430	Bolt	.36	.22	.27
185018	Tee (E)	.56	.34	.39	185433	Lock	.08	.04	.05
185020	Hose (E)	1.34	.67	.80	185434	Lock	.08	.04	.05
185021	Clamp (E)	.12	.07	.08	185438	Cup (E)	ea. .35	.18	.21
185027	Steering Gear	25.72	16.71	20.89		In Pkgs. of 10			
185032	Cap	1.95	1.09	1.35	185439	Link (E)	.41	.25	.29

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
185441	Piston (E)	1.16	.58	.70	185655	Spring	.05	.03	.04
185442	Stop (E)	.07	.04	.05	185663	Washer	.82	.49	.62
185443	Wire (E)	.07	.04	.05	185675	Shell	8.69	5.22	6.52
185444	Cup (E)	ea. .34	.20	.24	185724	Sleeve	1.00	.60	.75
	In Pkgs. of 10				185731	Spring (E)	.16	.10	.11
185445	Ring (E)	.07	.04	.05	185745	Belt	2.42	1.16	1.45
185447	Spring (E)	.33	.20	.23	185761	Armature (E)	13.35	7.21	9.35
185448	Retainer (E)	.06	.04	.05		Add \$1.00 net charge pending return of old armature			
185449	Head (E)	.88	.53	.62	185766	Retainer	.12	.07	.09
185450	Gasket (E)	ea. .12	.07	.08	185779	Regulator (E)	8.25	4.46	5.78
	In Pkgs. of 10				185780	Fuse	.05	5/.17	5/.21
185451	Seat (E)	.25	.15	.18	185789	Plug	.03	.02	.03
185452	Use 532103				185790	Washer	ea. .03	.02	.03
185453	Boot (E)	.47	.24	.28		In Pkgs. of 5			
185454	Clamp (E)	.07	.04	.05	185792	Bushing	.75	.45	.56
185455	Clamp (E)	.12	.07	.08	185809	Spring	20.31	11.17	13.97
185457	Gasket (E)	.07	.04	.05	185817	Leaf	4.73	2.60	3.25
185459	Cylinder (E)	4.19	2.10	2.72	185824	Rod	1.13	.68	.85
185460	Cylinder (E)	4.19	2.10	2.72	185832	Ball	.30	.17	.21
185467	Spring (E)	.16	.10	.11	185873	Bearing	2.20	1.21	1.51
185468	Piston (E)	ea. .54	.32	.38	185887	Bearing	2.55	1.40	1.75
	In Pkgs. of 2				185888	Use 516390			
185469	Piston (E)	ea. .54	.32	.38	185892	Bearing	2.55	1.40	1.75
	In Pkgs. of 2				185897	Glass	.87	.52	.66
185470	Piston (E)	.34	.20	.24	185921	Arm	9.00	5.40	6.75
185471	Cup (E)	ea. .35	.18	.21	185951	Link	2.31	1.39	1.74
	In Pkgs. of 10				185956	Plate	5.91	3.86	4.82
185472	Cup (E)	ea. .35	.18	.21	185962	Bolt	.31	.19	.24
	In Pkgs. of 10				185978	Knuckle	11.83	7.10	8.88
185473	Cup (E)	ea. .35	.18	.21	185981	Plate	ea. .07	.04	.05
	In Pkgs. of 10					In Pkgs. of 10			
185474	Boot (E)	ea. .26	.13	.16	185984	Use 184192			
	In Pkgs. of 10				185987	Rod	.36	.22	.27
185475	Boot (E)	ea. .26	.13	.16	185992	Rod	.31	.19	.24
	In Pkgs. of 10				185995	Crank	.31	.19	.24
185476	Use 679046				185999	Ring	.31	.19	.24
185477	Link (E)	.73	.44	.51	186007	Use 523537			
185478	Cover (E)	.06	.04	.05	186012	Leaf	3.86	2.12	2.65
185479	Spring (E)	ea. .13	.08	.09	186029	Gage	.51	.31	.39
	In Pkgs. of 10				186090	Clip	.05	.03	.04
185480	Spring (E)	.25	.15	.18	186113	Pulley	3.60	2.16	2.71
185482	Use 673910				186123	Use 526600X3			
185483	Washer (E)	.03	10/.20	10/.25	186125	Gasket	ea. .03	.02	.03
185485	Spring (E)	.14	.08	.10		In Pkgs. of 10			
185487	Use 515696				186127	Gasket	ea. .10	.06	.08
185488	Cam (E)	ea. .24	.14	.17		In Pkgs. of 10			
	In Pkgs. of 10				186134	Screw	.30	.18	.23
185489	Washer (E)	.07	.04	.05	186135	Float	.60	.36	.45
185513	Plate (E)	.14	.08	.10	186143	Jet	.60	.36	.45
185532	Tube	.90	.54	.68	186188	Spacer	.05	.03	.04
185546	Cover	.46	.28	.35	186208	Bushing	.30	.15	.19
185547	Ring	.02	.01	.01	186238	Adaptor	.25	.15	.19
185548	Housing	10.23	6.66	8.32	186250	Spring	.08	.05	.06
185550	Post & Worm	8.74	5.69	7.11	186257	Gasket	ea. .05	.03	.04
185552	Post & Worm	8.74	5.69	7.11		In Pkgs. of 10			
185554	Shaft	5.09	3.05	3.82	186270	Pump	9.75		
185560	Retainer	1.10	.55	.66		#Lots of 1 to 5		5.94	5.94
185563	Housing	9.62	6.25	7.82		6 to 11		5.46	5.46
185565	Shaft	10.80	6.48	8.11		12 or more		4.97	4.97
185568	Ring	.02	.01	.01	186273	Washer (E)	.03	10/.20	10/.25
185586	Bushing	.30	.15	.19	186275	Thermostat	2.52	1.44	1.80
185603	Use 188134				186310	Eccentric (E)	.26	.16	.18
185606	Spring	21.34	11.74	14.67	186311	Pin (E)	.24	.14	.17
185624	Oil Seal	1.23	.62	.77	186316	Post & Worm	11.06	7.20	9.00
185626	Bearing	4.45	2.11	2.64	186317	Drum	8.65	4.76	5.95
185630	Ring	.07	4/.16	4/.20	186334	Pipe	3.34	1.84	2.30
185647	Bushing	.35	.21	.26					
185654	Pawl	4.53	2.72	3.39					

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
186337	Gasket In Pkgs. of 10	ea. .15	.08	.10	186748	Cover (E)	17.35	9.54	11.93
186340	Bracket	2.31	1.39	1.74		See Green Section			
186343P	Grille	7.82	4.68	5.85	186749	Retainer	.03	.02	.03
186393	Use 186394				186756	Support	2.83	1.84	2.30
186394	Spring	20.31	11.17	13.97	186758	Clamp	.17	.10	.13
186453	Link	.45	.27	.34	186759	Clamp	.17	.10	.13
186466	Cover	.46	.28	.35	186779	Bracket	1.08	.70	.87
186467	Cover	.72	.43	.55	186784	Clip	.51	.29	.36
186481	Pipe	3.09	1.70	2.12	186787	Stud	.10	.06	.08
186489	Rod	8.74	4.81	6.02	186801	Knuckle	11.83	7.10	8.88
186521	Thermostat	.72	.43	.55	186820	Pipe	.36	.22	.27
186534	Spring	.10	.06	.08	186821	Elbow	.51	.31	.39
186539	Boot	.51	.31	.39	186827P	Wheel-Prime	13.60	7.48	9.35
186547	Bulb	.38			186846	Nut	.25	.15	.19
	Pkg. of 10				186847	Spring	.25	.15	.19
	# 1 to 9 Pkgs.		2.31	2.31	186848	Bearing	.46	.28	.35
	10 or more Pkgs.		2.05	2.31	186849	Lock	.12	.07	.09
186567	Clutch	20.57	13.37	16.71	186852	Spring (E)	.25	.14	.18
186571	Valve & Shaft	1.85	1.11	1.39	186853	Shoes (E)	5.70	3.42	3.99
186572	Shaft	1.23	.74	.93	186875	Tank	15.85	9.51	11.89
186575	Balance	.72	.43	.55	186888	Gasket	.06	10/.30	10/.38
186576	Cover	.72	.43	.55	186896	Bushing	.55	.30	.38
186578	Body	2.78	1.67	2.09	186898	Bushing	.55	.30	.38
186579	Pin	.03	.02	.03	186901	Bolt	.67	.37	.46
186588	Shaft	12.09	7.25	9.06	186902	Bolt	.87	.48	.61
186605	Shaft	1.39	.76	.96	186903	Retainer	.15	.09	.11
186612	Cap	1.23	.74	.93	186904	Shackle	.93	.51	.65
186613	Cap	1.08	.65	.81	186914	Elbow	.51	.26	.32
186615	Use 517087				186937	Rod	1.49	.89	1.12
186616	Use 1 ea. 189614, 189697				186938	End	3.60	1.99	2.48
186622	Pack	.20	.12	.15	186940	Pin	1.03	.57	.71
186638	Lock	.02	10/.10	10/.13	186941	Pin	1.03	.57	.71
186643	Grommet	.08	.05	.06	186945	Knuckle	11.83	7.10	8.88
186644	Washer	.08	.05	.06	186946	Knuckle	11.83	7.10	8.88
186646	Bracket	1.29	.77	.97	186947	Support	9.77	5.86	7.32
186659	Use 189319				186948	Support	9.77	5.86	7.32
186664	Screw	.20	.12	.15	186964	Cable	2.93	1.61	2.02
186666	Guide	.38	.19	.23	186967	Bracket	1.65	1.07	1.34
186668	Gasket	ea. .20	.10	.12	186991	Cushion	.36	.22	.27
	In Pkgs. of 10				186992	Screw	.10	.06	.08
186669	Use 189167				186998	Gasket	ea. .17	.09	.11
186670	Gasket	ea. .12	.06	.08		In Pkgs. of 10			
	In Pkgs. of 10				187001	Pipe	3.09	1.70	2.12
186682	Pack	.31	.19	.24	187003	Gasket	ea. .35	.18	.21
186685	Impeller	.82	.41	.51		In Pkgs. of 10			
186687	Gage	.51	.31	.39	187005	Manifold	11.31	7.35	9.20
186688	Flywheel	2.35	1.41	1.76	187006	Valve	.41	.25	.31
186690	Hub	1.54	.93	1.16	187009	Balance	.46	.28	.35
186692	Washer	.57	.34	.42	187015	Screw	.15	.08	.10
186693	Shim	.05	4/.12	4/.15	187016	Collar	1.54	.93	1.16
186694	Shim	.05	4/.12	4/.15	187023	Nut	ea. .03	.02	.03
186695	Shim	.05	4/.12	4/.15		In Pkgs. of 50			
186696	Use 524114				187027	Manifold	8.74	5.69	7.11
186701	Lifter	.93	.51	.65	187044	Gasket	ea. 1.85	1.02	1.28
186702	Plate	.31	.19	.24		In Pkgs. of 10			
186703	Cushion	.25	.15	.19	187047	Starter (E)	42.60	23.00	29.82
186704	Cushion	.25	.15	.19	187048	Flange	.17	.09	.11
186705	Pulley	3.45	2.06	2.57	187050	Gear	3.55	1.95	2.44
186710	Gasket	ea. .55	.28	.33	187051	Gear	3.09	1.70	2.12
	In Pkgs. of 5				187052	Flywheel	13.37	8.02	10.03
186711	Pump	11.31	6.22	7.78	187069	Valve	1.40	.84	1.05
186713	Body	5.40	3.24	4.05	187071	Seal	ea. .16	.10	.13
186715	Plate	.46	.28	.35		In Pkgs. of 10			
186719	Nut	.40	.22	.28	187072	Spacer	.03	.02	.03
186723	Use 189122				187090	Stud	.20	.12	.15
186727	Use 526204				187091	Stud	.20	.12	.15
186741	Manifold	1.39	.83	1.04	187095	Fitting (E)	.24	.14	.17
					187106	Seal	.06	10/.36	10/.45

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
187110	Gage (E)	3.00	1.62	2.10	187478	Shaft	1.95	1.17	1.47
187116	Starter (E)	42.60	23.00	29.82	187481	Bushing	1.03	.62	.77
187134	Rod	1.29	.77	.97	187485	Rod	.51	.31	.39
187144	Pad	.77	.46	.58	187491	Hanger	.30	.19	.24
187145	Pad	.77	.46	.58	187492	Hanger	.25	.15	.19
187151	Pipe	3.50	1.93	2.41	187503	Wheel	11.57	6.94	8.68
187154	Clamp	.17	.10	.13	187504	Wheel	12.65	7.59	9.49
187156	Pipe	4.00	2.20	2.75	187507	Wheel	6.02	3.61	4.52
187159	Pipe	3.50	1.93	2.41	187508	Bushing	.30	.15	.19
187164	Hose	.25	.13	.16	187511	Support	.17	.10	.13
187166	Elbow	.77	.46	.58	187515	Lever	1.29	.77	.96
187169	Valve	ea. .87	.44	.56	187525	Jacket	4.11	2.47	3.09
	In Pkgs. of 8				187540	Pipe	2.06	1.23	1.54
187171	Valve	ea. .98	.49	.61	187545	Post & Worm	8.74	5.69	7.11
	In Pkgs. of 6				187546	Post & Worm	8.74	5.69	7.11
187179	Use 1-525945, and 2-522144				187547	Post & Worm	8.74	5.69	7.11
187183	Pipe	.72	.43	.55	187550	Plate	13.01	7.15	8.94
187196	Neck	1.95	1.17	1.47	187569	Gear (E)	1.23	.66	.86
187199	Piston	5.40	2.97	3.71	187570	Pinion	1.75	1.05	1.31
187206	Piston	5.40	2.97	3.71	187573	Spring	20.31	11.17	13.97
187207	Piston	5.40	2.97	3.71	187575	Pinion (E)	1.44	.78	1.01
187208	Piston	5.40	2.97	3.71	187579	Spring	.20	.11	.14
187210	Piston	5.40	2.97	3.71	187580	Spring	.14	.08	.10
187211	Piston	5.40	2.97	3.71	187596	Shaft	14.61	8.03	10.04
187223	Camshaft	15.33	9.21	11.51	187612	Bushing	.45	.27	.34
187232	Core	58.50	35.10	43.88	187618	Gasket	.12	.06	.08
187233	Core	70.46	42.28	52.85	187627	Cup	3.36	1.60	2.02
187253	Bearing	3.50	1.93	2.41	187628	Cone	4.85	2.30	2.91
187254	Bearing	3.85	2.12	2.65	187629	Seal	.93	.56	.70
187255	Bearing	3.85	2.12	2.65	187631	Shaft	1.96	1.18	1.48
187256	Bearing	3.85	2.12	2.65	187637	Wick	.12	.07	.09
187262	Use 519297				187639	Rod	.51	.31	.39
187263	Use 519295				187640	Stud	.36	.22	.27
187271	Rod	.25	.15	.19	187641	Seat	.20	.12	.15
187272	Crank	.31	.19	.24	187642	Retainer	.05	.03	.04
187276	Rod	.31	.19	.24	187645	Rod	.36	.22	.27
187303	Rod	.75	.45	.56	187646	Rod	.36	.22	.27
187304	Stud	.15	.09	.11	187670	Shield	.17	.10	.13
187309	Rod	.36	.22	.27	187677	Outlet	1.65	.99	1.23
187317	Cock	.40	.20	.25	187679	Pinion (E)	1.54	.83	1.08
187322	Gasket (E)	ea. .07	.04	.05	187680	Hose	.67	.34	.42
	In Pkgs. of 10				187681	Hose	1.03	.51	.65
187333	Strainer	1.35	.81	1.01	187682	Thermostat	2.52	1.44	1.80
187337	Clip	ea. .05	.03	.04	187685	Camshaft	27.52	16.51	20.63
	In Pkgs. of 4				187698	Pipe	ea. .90	.54	.68
187338	Shaft	1.08	.65	.81		In Pkgs. of 10			
187343	Moulding	7.88	5.08	6.36	187700	Spring	.07	.04	.05
187361	Cover	.77	.46	.58	187702	Cable	.51	.31	.39
187365	Cap	2.73	1.64	2.05	187706	Pump	6.85		
187373	Bracket	2.83	1.70	2.12		#Lots of 1 to 5		4.18	4.18
187376	Yoke	7.10	3.91	4.62		6 to 11		3.83	3.83
187402	Plate	3.09	1.85	2.31		12 or more		3.49	3.49
187423	Shaft	14.61	8.03	10.04	187714	Use 523099			
187425	Clip	ea. .30	.17	.20	187724	Bar	1.70	1.02	1.28
	In Pkgs. of 10				187725	Bar	1.29	.77	.97
187432	Joint	12.24	6.74	8.42	187735	Use 262-08			
187439	Cross	2.78	1.53	1.91	187743	Clamp	.17	.10	.13
187441	Bearing	.73	.40	.50	187746	Clip	.02	.01	.01
187443	Yoke	6.43	3.54	4.42	187748	Shield	.25	.15	.19
187452	Spring	.30	.15	.19	187762	Gasket	.05	.03	.04
187456	Jacket	3.03	1.82	2.27	187763	Washer	2/.03	15/.11	15/.14
187461	Spacer	.02	.01	.01	187769	Cartridge (E)	See Pink Sheet on Fram Filters		
187462	Retainer	.17	.10	.13	187774	Shaft	.46	.28	.35
187464	Clip	.51	.29	.36	187775	Bell Crank	.87	.52	.66
187466	Arm (E)	.77	.42	.54	187776	Use 520-04			
187467	Screw & Point (E)	.35	.19	.25	187777	Flange	2.42	1.45	1.81
187471	Clip	.51	.29	.36	187780	Spring	12.60	6.93	8.67
187477	Shaft	1.85	1.11	1.39					

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

188 324

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
187781	Spring	26.74	14.71	18.39	188111	Gage (E)	1.80	.97	1.26
187787	Bar	1.70	1.02	1.28	188112	Ammeter (E)	1.80	.97	1.26
187788	Bar	1.70	1.02	1.28	188113	Radimeter (E)	4.65	2.51	3.26
187790	Use 515-03				188114	Gage (E)	3.00	1.62	2.10
187792	(518-03) Nipple	.12	.06	.08	188115	Speedometer (E)	15.40	8.30	10.78
187795	Use 520-03				188124	Sockets & Cables	.67	.40	.50
187802	Elbow	.20	.10	.13	188128	Gear	4.06	2.44	3.04
187809	Pulley	5.14	3.34	4.18	188132	Lens	.05	.03	.04
187811	Spacer	.10	.06	.08	188134	Spring	13.73	7.55	9.44
187813	Hose	.41	.21	.26	188141	Gear	9.26	5.55	6.94
187819	Spring	.07	.04	.05	188175	Fork	2.57	1.54	1.93
187822	Gear	1.70	1.02	1.28	188177	Bearing	.75	.38	.48
187823	Block	1.03	.62	.77	188178	Bolt	.12	.07	.09
187834	Pipe	.46	.28	.35	188208	Leaf	2.83	1.55	1.94
187836	Clip	.05	.03	.04	188209	Leaf	4.01	2.21	2.77
187844	Belt	2.50	1.25	1.50	188210	Leaf	4.73	2.60	3.25
187860	Pinion (E)	1.35	.73	.95	188211	Washer	.36	.22	.27
187863	Gear (E)	2.05	1.11	1.44	188213	Spacer	.12	.07	.09
187871	Rod	.46	.28	.35	188215	Washer	.03	.02	.03
187878	Gasket	ea. .10	.05	.06	188221	Spring	22.37	12.30	15.38
	In Pkgs. of 10				188226	Cover	1.49	.82	1.03
187879	Gasket	.03	.02	.03	188228	Gasket	ea. .05	.03	.04
187884	Harness	3.91	2.35	2.93		In Pkgs. of 5			
187897	Ornament	3.03	1.80	2.25	188230	Bar	1.70	1.02	1.28
187900	Harness	2.11	1.27	1.58	188231	Bar	1.70	1.02	1.28
187906	Shell-Prime	27.77	18.05	22.57	188232	Bar	1.39	.83	1.04
187908	Pipe	.67	.40	.50	188233	Bar	1.39	.83	1.04
187930	Shaft (E)	3.20	1.73	2.24	188236	Bearing	5.70	2.71	3.39
187935	Gasket	ea. .10	.05	.06	188239	Case	13.11	8.53	10.66
	In Pkgs. of 5				188262	Support	1.03	.62	.77
187937	Shield	.25	.15	.19	188268	Gasket	ea. .10	.05	.06
187952	Washer	.72	.43	.55		In Pkgs. of 10			
187956	Use 529408X48				188273	Coil (E)	6.60	3.56	4.62
187964	Use 517-04				188274	Lock & Cable (E)	5.55	3.00	3.89
187978	Weight	1.80	1.17	1.47	188277	Flange	2.31	1.39	1.74
187993	Cable	2.99	1.65	2.06	188279	Gasket	ea. .03	.02	.03
188000	Clip	.05	.03	.04		In Pkgs. of 5			
188002	Gear Cluster	20.06	12.03	15.05	188281	Ring	.07	.04	.05
188004	Use 198526				188282	Spacer	.41	.25	.31
188005	Fitting (E)	.56	.34	.39	188284	Shaft	.77	.46	.58
188006	Switch	1.39	.83	1.04	188285	Countershaft	1.70	.94	1.17
188008	Washer	.08	.05	.06	188287	Washer	ea. .25	.15	.19
188009	Washer	.40	.24	.30		In Pkgs. of 10			
188010	Ring	.07	.04	.05	188289	Washer	.31	.19	.24
188011	Ring	.07	.04	.05	188290	Switch	1.03	.51	.62
188012	Ring	.07	.04	.05	188291	Roller	44/.80	44/.40	44/.50
188031	Gasket	ea. .03	.02	.03	188293	Flange	4.32	2.59	3.24
	In Pkgs. of 5				188295	Roller	14/.50	14/.30	14/.38
188036	Switch	1.49	.90	1.12	188296	Gasket	ea. .05	.03	.04
188037	Button & Rod	.36	.22	.27		In Pkgs. of 5			
188038W	Support	.62	.37	.46	188297	Gasket	ea. .05	.03	.04
188039	Sleeve & Tube	.87	.52	.66		In Pkgs. of 5			
188044	Nut	.15	.09	.11	188298	Gasket	.05	.03	.04
188045	Gasket	ea. .35	.18	.21	188299	Washer	.05	.03	.04
	In Pkgs. of 5				188300	Bushing	.25	.15	.19
188058	Rod	7.97	4.38	5.48	188302	Spring	.03	.02	.03
188061	End	3.60	1.99	2.48	188310	Support	.62	.37	.46
188062	Harness	4.37	2.62	3.28	188316	Pinion	12.86	7.71	9.65
188063	Harness	4.99	2.99	3.74	188317	Sleeve	3.86	2.31	2.89
188064	Adapter	.25	.15	.19	188318	Plate	.05	.03	.04
188066	Harness	4.89	2.93	3.66	188319	Head	16.46	9.87	12.34
188067	Terminal	.03	10/.15	10/.19	188322	Spring (E)	ea. .07	.04	.05
188075	Harness	2.42	1.45	1.81		In Pkgs. of 10			
188078	Gasket	.02	.01	.01	188323	Sleeve	ea. .10	.06	.08
188088	Spring	10.80	5.95	7.44		In Pkgs. of 10			
188093	Button & Wire	.62	.37	.46	188324	Washer	.03	.02	.03
188102	Cap	.17	.09	.11					

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
188329	Oiler	ea. .05	.03	.04	188549	Washer	.03	.02	.03
	In Pkgs. of 5				188550	Gear	9.77	5.86	7.33
188330	Collar	ea. .15	.10	.12	188552	Retainer	.05	.03	.04
	In Pkgs. of 2				188553	Plate	.03	.02	.03
188342	Washer	ea. .05	.03	.04	188554	Plate	.03	.02	.03
	In Pkgs. of 10				188555	Cage	28.29	16.97	21.22
188344	Switch	4.63	3.01	3.48	188561	Clutch	20.57	13.37	16.71
188348	Ring	.07	4/.16	4/.20	188567	Washer	.03	.02	.03
188349	Ring	.07	4/.16	4/.20	188586	Link	.67	.40	.50
188350	Ring	.07	4/.16	4/.20	188598	Hub & Drum	12.91	7.10	8.88
188351	Ring	.07	4/.16	4/.20	188599	Hub & Drum	12.91	7.10	8.88
188356	Ball	.10	.06	.08	188602	Clip	.03	.02	.03
188358	Base	2.06	1.34	1.68	188610	Facing	2/2.88	2/1.44	2/1.80
188359	Spring	.05	.03	.04	188622	Brush (E)	.40	.22	.28
188361	Valve (E)	10.00	6.00	7.00	188623	Brush (E)	.40	.22	.28
188362	Rod (E)	.25	.15	.18	188624	Use 711-04			
188365	Extension (E)	.14	.08	.10	188626	Armature (E)	12.65	6.83	8.86
188367	Ring	.08	4/.20	4/.24	188627	Spacer	.01	20/.10	20/.13
188369	Radimeter (E)	5.40	2.92	3.78	188628	Drive (E)	6.05	3.63	4.24
188370	Gage (E)	2.42	1.31	1.69	188629	Spring (E)	.86	.46	.60
188371	Ammeter (E)	2.42	1.31	1.69	188630	Screw (E)	ea. .08	.04	.05
188373	Facing	2/3.39	2/1.69	2/2.11		In Pkgs. of 5			
188375	Rivet	24/.18	24/.09	24/.11	188631	Housing (E)	3.90	2.11	2.73
188376	Pulley (E)	1.49	.80	1.04	188632	Washer	.01	12/.07	.01
188380	Seat	.03	.02	.03	188635	Lock	.03	.02	.03
188383	Washer	.10	.06	.08	188640	Fitting	ea. .12	.07	.09
188384	Shaft	.77	.46	.58		In Pkgs. of 10			
188385	Countershaft	1.70	.94	1.17	188641	Use 718-04			
188399	Washer	.67	.40	.50	188644	Shim	.05	.03	.04
188401	Hanger	1.39	.91	1.13	188645	Spring	.38	.19	.22
188402	Hanger	1.39	.91	1.13	188646	Retainer	ea. .17	.10	.13
188405	Bolt	.10	4/.24	4/.30		In Pkgs. of 5			
188417	Shim	.01	20/.10	20/.13	188647	Stud	.17	.10	.13
188450	Dowel	.01	2/.01	.01	188653	Spacer	.12	.07	.09
188468	Gasket	.05	.03	.04	188659	Bulb	.11		
188473	Washer	.03	.02	.03		Pkg. of 10			
188475	Base (E)	3.10	1.67	2.17		# 1 to 9 Pkgs.		.69	.69
188476	Bushing (E)	.28	.15	.20		10 or more Pkgs.		.61	.69
188477	Camshaft (E)	2.21	1.19	1.55	188660	Washer	.02	.01	.01
188478	Washer	.03	.02	.03	188678	Cushion	.10	.06	.08
188479	Ring	.02	.01	.01	188690	Button & Rod	.46	.28	.35
188480	Arm & Point (E)	.82	.44	.57	188691	Control	.87	.52	.66
188483	Weight (E)	.40	.22	.28	188702	Pump	15.52		
188484	Spring (E)	.15	.08	.11		# Lots of 1 to 5		9.31	9.31
188493	Gasket	ea. .03	.02	.03		6 to 11		8.53	8.53
	In Pkgs. of 10					12 or more		7.76	7.46
188494	Bearing	4.65	2.21	2.76	188705	Button & Wire	.41	.25	.31
188505	Gear	5.14	3.09	3.86	188707	Button & Wire	.62	.37	.46
188506	Synchronizer	7.71	4.63	5.79	188728	Gasket	.03	10/.16	10/.20
188508	Spring	.03	.02	.03	188768	Pipe	3.50	1.93	2.41
188513	Gears	29.32	24.69	29.32	188845	Gear	8.74	5.25	6.56
188515	Race	4.11	2.47	3.09	188846	Pipe	.67	.40	.50
188520	Plate	.03	.02	.03	188850	Cover	.77	.46	.58
188521	Ring	.10	2/.12	2/.15	188889	Gear	2.57	1.54	1.93
188522	Ring	.10	2/.12	2/.15	188897	Steering Gear	28.29	18.39	22.99
188523	Ring	.10	2/.12	2/.15	188898	Steering Gear	28.29	18.39	22.99
188524	Ring	.10	2/.12	2/.15	188899	Rod	.36	.22	.27
188525	Fork	2.57	1.54	1.93	188902	Absorber	8.25	5.35	6.45
188526	Spring	.05	.03	.04		See Green Section			
188527	Sleeve	.36	.22	.27	188903	Absorber	8.25	5.35	6.45
188528	Washer	.02	.01	.01		See Green Section			
188529	Rod	1.29	.77	.97	188951	Glass	.87	.52	.66
188532	Shaft	2.47	1.60	2.01	188968	Cable	.67	.40	.50
188533	Spring	.25	.15	.19	188970	Grille	6.50	3.25	4.23
188539	Roller	12/1.20	12/.72	12/.90	188985	Pulley	4.11	2.67	3.09
188540	Retainer	.57	.34	.42	188987	Screw	.17	.09	.11
188541	Spring	.05	4/.12	4/.15	188990	Screw	.17	.09	.11
188547	Washer	.07	.04	.05	188991	Bushing	1.10	.66	.83



## PARTS PRICE LIST

189 697

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
189008	Brush	.26	.13	.16	189339	Gasket	ea. 1.85	.93	1.16
189012	Coupling	ea. 1.25	.62	.75		In Pkgs. of 10			
189057	Tee	.25	.13	.16	189340	Use 680292			
189098	Rod	1.65	.99	1.23	189342	Shackle	.93	.46	.58
189099	Rod	1.13	.68	.85	189350	Use 184368			
189113	Rotor (E)	.62	.33	.43	189351	Spring	20.31	11.17	13.97
189115	Spring	.10	.06	.08	189352	Cable	2.98	1.65	2.06
189119	Pipe	.46	.24	.30	189353	Cable	2.98	1.65	2.06
189121	Use 189122				189354	Lever	.25	.15	.19
189122	Spring	28.54	15.70	19.63	189355	Extension	.51	.30	.46
189125	Pipe	.82	.41	.51	189358	Clip	.08	.05	.06
189126	Joint	10.13	6.08	7.60	189366	Shaft	1.39	.83	1.04
189127	Shaft	12.34	8.02	10.03	189368	Rod	7.46	4.10	5.13
189129	Bolt	.25	.15	.19	189369	Rod	6.94	3.82	4.77
189130	Washer	.05	.03	.04	189371	Bracket	.98	.64	.80
189133	Gasket	.03	5/.09	5/.11	189378	Spring	.08	.05	.06
189134	Screw	.03	.02	.03	189379	Pedal	1.03	.62	.77
189138	Shaft	6.25	3.75	4.69	189382	Pad	.05	.03	.04
189139	Jacket	3.60	2.16	2.71	189388	Cradle	.72	.47	.60
189140	Jacket	3.60	2.16	2.71	189389	Pipe	3.50	1.93	2.41
189141	Clamp	.25	.15	.19	189393	Strap	.07	5/.20	5/.25
189142	Cover	1.03	.62	.77	189396	Pipe	4.00	2.20	2.75
189143	Shim	ea. .05	.03	.04	189413	Hanger	1.59	1.03	1.29
	In Pkgs. of 10				189416	Clip	.58	.31	.39
189144	Shim	ea. .03	.02	.03	189418	Clip	.58	.31	.39
	In Pkgs. of 10				189424	Case	11.31	6.56	8.20
189145	Shim	ea. .03	.02	.03	189427	Gage (E)	2.85	1.54	2.00
	In Pkgs. of 10				189443	Crank	.30	.19	.24
189146	Shim	ea. .03	.02	.03	189462	Body	5.91	3.55	4.43
	In Pkgs. of 10				189518	Screw	.12	.07	.09
189163	Gasket	ea. .06	.03	.04	189521	Shaft	37.80	20.79	25.98
	In Pkgs. of 10				189524	Strap	.46	.28	.35
189165	Link	2.01	1.20	1.50	189534	Plate	2.73	1.64	2.05
189167	Plate	1.54	.93	1.16	189536	Outlet	1.39	.83	1.04
189213	Hanger	1.59	1.03	1.29	189537	Screw	.17	.09	.11
189214	Hanger	1.59	1.03	1.29	189539	Pipe	.57	.29	.36
189215	Stud	.25	.15	.19	189540	Pipe	.93	.46	.58
189216	Rod	ea. .36	.22	.27	189542	Hanger	.12	.07	.09
	In Pkgs. of 10				189543	Clamp	.17	.10	.13
189218	Shaft	1.95	1.17	1.47	189559	Spring	.20	.12	.15
189224	Use 191239 & 191223				189580	Hose	.46	.24	.30
189226	Spring	.05	.03	.04	189585	Housing	13.47	8.07	10.09
189232	Shaft	1.80	1.08	1.35	189588	Fitting	1.03	.62	.77
189233	Shaft	1.80	1.08	1.35	189592	Spacer	.12	.07	.09
189234	Washer	.02	.01	.01	189595	Bolt	.17	.10	.13
189236	Bracket	1.03	.62	.77	189600	Bracket	1.95	1.28	1.59
189241	Washer	.05	.03	.04	189601	Bracket	1.95	1.28	1.59
189246	Rod	.36	.22	.27	189604	Bushing	.10	8/.40	8/.50
189249	Spacer	.12	.07	.09	189607	Link	.25	.15	.19
189250	Bolt	.20	.12	.15	189610	Gear	9.00	5.40	6.75
189252	Use 525965				189611	Shaft	4.63	2.78	3.48
189254	Member	3.60	2.35	2.93	189614	Cap	2.47	1.48	1.85
189255	Shaft	1.13	.68	.85	189621	Plate	.93	.56	.70
189258	Flange	3.34	2.01	2.51	189630	Core	45.00	22.50	29.25
189259	Rod	.31	.19	.24	189631	Spring	ea. .05	.03	.04
189262	Clevis (E)	.30	.18	.21		In Pkgs. of 10			
189301	Neck	2.06	1.23	1.54	189651	Engine	See Green Section		
189310	Housing	9.21	5.52	6.90	189660	Screw	.17	.09	.11
189316	Slinger	ea. .12	.07	.09	189671	Grommet	.10	5/.25	5/.31
	In Pkgs. of 10				189673	Bracket	1.34	.87	1.09
189318	Cable	3.03	1.67	2.09	189674	Bracket	1.34	.87	1.09
189319	Cover	3.34	2.01	2.51	189680	Cylinder	101.00	70.70	83.33
189326	Gasket	.05	5/.15	5/.19	189686	Cap	.67	.34	.42
189327	Plate	.46	.28	.35	189687	Flange	2.88	1.73	2.16
189328	Head	16.46	9.87	12.34	189689	Flange	4.32	2.59	3.24
189331	Pipe	3.50	1.93	2.41	189694	Grommet	.17	.10	.13
					189696	Screw (E)	.38	.23	.27
					189697	Tube	.20	.12	.15

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
189698	Use 1 ea. 523137, 525945 and 2-522144				190019	Pipe	3.50	1.93	2.41
189700	Shaft & Core (E)	3.60	1.94	2.52	190020	Switch	8.28	4.97	6.21
189706	Manifold	8.74	5.69	7.11	190027	Gear Set	31.89	18.49	23.12
189717	Drum	8.60	4.73	5.91	190030	Gear Set	31.89	18.49	23.12
189718	Cap	2.31	1.28	1.59	190032	Cup	2.46	1.17	1.48
189728	Tube	1.65	.99	1.23	190033	Cone	4.15	1.97	2.49
189730	Shaft	12.34	8.02	10.03	190035	Cup	3.15	1.50	1.89
189731	Shaft	12.34	8.02	10.03	190036	Cone	5.54	2.63	3.32
189738	Seal	ea. .01	2/.01	.01	190037	Spacer	1.03	.62	.77
	In Pkgs. of 10				190038	Shim	.05	4/.12	4/.15
189751	Bushing	.72	.40	.50	190039	Shim	.05	4/.12	4/.15
189760	Fitting (E)	.44	.26	.31	190040	Shim	.05	4/.12	4/.15
189762	Bushing	.77	.42	.52	190041	Shim	.05	4/.12	4/.15
189765	Thermostat	3.95	2.37	2.96	190043	Use 183616			
189774	Cylinder with Pistons	147.60	95.94	119.93	190047	Cup	3.60	1.71	2.16
189784	Bar	1.70	1.02	1.28	190048	Cone	5.67	2.69	3.40
189785	Bar	1.29	.77	.97	190053	Bracket	.20	.12	.15
189789	Wheel	6.69	4.01	5.02	190055	Lever (E)	.77	.46	.55
189790	Rod	.36	.22	.27	190063	Knuckle	11.83	7.10	8.88
189791	Support	9.77	5.86	7.33	190069	Knuckle	11.83	7.10	8.88
189792	Support	9.77	5.86	7.33	190073	Support	9.77	5.86	7.33
189808	Shoes (E)	5.70	3.42	3.99	190074	Support	9.77	5.86	7.33
189813	Cap	.30	.15	.19	190085	Relay	1.54	.77	.93
189819	Spring	ea. .20	.11	.14	190093	Spacer	.05	4/.12	4/.15
	In Pkgs. of 20				190099	Pipe	.87	.44	.56
189820	Valve	ea. 1.46	.73	.91	190103	Use 525809			
	In Pkgs. of 6				190107	Button	.67	.40	.50
189823	Gage	.51	.31	.39	190110	Block	1.03	.62	.77
189826	Ring	.31	.19	.24	190111	Harness	.30	.15	.19
189848	Cable	3.09	1.70	2.12	190113	Nut	.07	.04	.05
189852	Cable	.51	.31	.39	190117	Pipe	.62	.37	.46
189853	Plate	.57	.34	.42	190136	Cup	4.21	2.00	2.53
189855	Spring	.05	.03	.04	190138	Housing	40.63	26.41	33.02
189856	Cup	.05	.03	.04	190150	Thermostat	.57	.34	.42
189857	Cap	.05	.03	.04	190152	Button	.46	.28	.35
189858	Spring	.07	.04	.05	190153	Harness	5.40	3.24	4.05
189859	Cap	.10	.06	.08	190160	Harness	2.11	1.27	1.58
189863	Bumper	.36	.22	.27	190163	Harness	2.11	1.27	1.58
189865	Button	.67	.40	.50	190164	Pipe	.46	.24	.30
189866	Button	.93	.56	.70	190173	Clip	.12	.07	.09
189888	Coupling	ea. 1.10	.55	.66	190176	Rod	1.65	.99	1.23
	In Pkgs. of 5				190177	Harness	4.37	2.62	3.28
189941	Radimeter (E)	5.40	2.92	3.78	190179	Rod	8.74	4.81	6.02
189942	Ammeter (E)	1.95	1.05	1.37	190180	Rod	8.74	4.81	6.02
189943	Ammeter (E)	2.42	1.31	1.69	190188	Rod	7.97	4.38	5.48
189944	Gage (E)	3.20	1.73	2.24	190195	Cleaner	3.86	2.31	2.89
189945	Gage (E)	3.35	1.81	2.35	190196	Bolt	.20	.12	.15
189946	Gage (E)	2.26	1.22	1.58	190206	Sleeve	6.07	3.64	4.56
189947	Gage (E)	2.42	1.31	1.69	190216	Cable	.62	.37	.46
189951	Arm	4.37	2.62	3.28	190217	Ring	.07	.04	.05
189952	Cover	2.06	1.23	1.54	190224	Flange	3.86	2.31	2.89
189958	Pipe	3.60	1.99	2.48	190228	Button & Wire	.72	.43	.55
189963	Pipe	.51	.26	.32	190231	Sleeve & Tube	1.29	.77	.97
189965	Use 520-05				190238	Support	1.08	.70	.87
189966	Nipple	.12	.07	.09	190256	Gasket	ea. .05	.03	.04
189968	Tube	.72	.43	.55		In Pkgs. of 10			
189975	Lock	.08	.04	.05	190257	Gear	8.74	5.25	6.56
189979	Pipe	2.06	1.23	1.54	190260	Arm	4.37	2.62	3.28
189983	Rod	2.98	1.65	2.06	190266	Cover	.82	.49	.62
189985	Seat	.17	.10	.13	190267	Gasket	ea. .05	.03	.04
189986	Plug	.01	2/.01	.01		In Pkgs. of 10			
189987	Sleeve	.31	.19	.24	190268	Shim	ea. .03	.02	.03
						In Pkgs. of 10			
190009	Clamp	.17	.10	.13	190269	Shim	ea. .03	.02	.03
190010	Hanger	.25	.15	.19		In Pkgs. of 10			
190013	Sleeve & Tube	1.29	.77	.97	190271	Use 680209			
190015	Switch	1.54	.93	1.16	190272	Use 680209			
					190274	Gasket	.03	5/.10	5/.13

## PARTS PRICE LIST

190 910

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
190275	Cup	.60	.36	.45	190574	Cam	8.69	4.78	5.98
190276	Retainer	.46	.28	.35	190578	Washer	.02	.01	.01
190277	Screw	.36	.22	.27	190579	Button	.57	.34	.42
190280	Cover	.46	.28	.35	190580	Lock & Keys	1.54	.93	1.16
190282	Post & Worm	11.31	7.35	9.20	190581	Ring	1.65	.99	1.23
190283	Shaft	6.94	4.17	5.20	190583	Washer	.03	.02	.03
190287	Pinion	12.86	7.71	9.65	190597	Ring	.15	.09	.11
190318	Cup	.85	.51	.64	190601	Spring	.03	.01	.01
190323	Housing	7.97	5.18	6.48	190605	Spring	.15	.09	.11
190325	Post & Worm	9.51	6.17	7.71	190606	Bushing	.80	.48	.60
190326	Post & Worm	9.51	6.17	7.71	190625	Pipe	3.60	1.99	2.48
190327	Post & Worm	9.51	6.17	7.71	190629	Hub	6.69	4.32	5.40
190332	Arm	4.63	2.78	3.48	190632	Hub & Drum	18.26	10.04	12.55
190335	Spring	.08	.05	.06	190633	Hub & Drum	18.26	10.04	12.55
190363	Lock & Cable	4.73	2.84	3.55	190646	Arm	2.73	1.64	2.05
190364	Lock & Cable(E)	5.80	3.13	4.06	190649	Control	1.03	.62	.77
190375	Spring	20.21	11.17	13.97	190652	Pinion	1.75	1.05	1.31
190376	Spring	22.37	12.30	15.38	190653	Pinion	1.75	1.05	1.31
190380	Leaf	4.99	2.75	3.44	190667	Member	.93	.61	.76
190384	Rod	.31	.19	.24	190669	Shaft (E)	3.10	1.67	2.17
190385	Spring	.05	.03	.04	190671	Key	.20	.12	.15
190390	Shaft	13.89	8.33	10.42	190714	Rod	6.94	3.82	4.77
190391	Pin	.05	4/.12	4/.15	190715	Rod	9.26	5.09	6.37
190395	Gear	9.77	5.86	7.33	190716	Rod	1.13	.68	.85
190400	Shield	.36	.20	.23	190740	Seat	.87	.52	.66
190403	Armature	12.34	8.02	9.26	190742	Clip	.51	.29	.36
	Add \$1.00 net charge pending return of old armature				190743	Ring	1.08	.65	.81
190411	Use 196301				190744	Ring	1.18	.71	.88
190414	Armature (E)	13.35	7.21	9.35	190798	Shaft & Impeller	2.31	1.16	1.46
	Add \$1.00 net charge pending return of old armature				190800	Gasket	ea. .07	.04	.05
190415	Bolt (E)	.16	.09	.11		In Pkgs. of 10			
190426	Clutch	4.63	2.55	3.01	190801	Impeller	1.34	.67	.83
190431	Boot	.20	.11	.13	190802	Plate	.57	.34	.42
190434	Armature (E)	13.35	7.21	9.35	190803	Gasket	ea. .07	.04	.05
	Add \$1.00 net charge pending return of old armature					In Pkgs. of 10			
190443	Modifier	1.70	1.10	1.28	190816	Plate	.17	.10	.13
190447	Switch (E)	1.59	.86	1.11	190817	Gasket	.05	2/.05	.03
190448	Housing (E)	3.50	1.89	2.45	190820	Plate	1.54	.93	1.16
190457	Nut	.02	10/.12	2/.03	190832	Plate	7.71	4.63	5.79
190458	Washer	.01	2/.01	.01	190836	Washer	.67	.40	.50
190459	Spacer	.01	20/.10	20/.13	190842	Shaft & Gears	27.67	16.29	20.37
190460	Spacer	.01	20/.10	20/.13	190843	Shaft	13.11	7.87	9.83
190467	Gear	14.14	8.49	10.60	190844	Shaft & Gears	26.13	15.37	19.21
190470	Clip	.05	.03	.04	190845	Shaft	11.57	6.94	8.68
190471	Gear	5.14	3.09	3.86	190849	Bushing	.03	5/.10	5/.13
190473	Bushing	.30	.18	.23	190850	Spring	11.16	6.14	7.67
190475	Plunger	.17	.10	.13	190851	Spring	20.16	11.09	13.87
190480	Gasket	.03	.02	.03	190852	Clip	.57	.31	.39
190482	Terminal	.02	.01	.01	190872	Wheel	7.21	4.32	5.40
190485	Use 587-04				190877	Housing	10.29	6.69	8.36
190489	Shim	.05	.03	.04	190878	Gasket	ea. .05	.03	.04
190492	Oil Seal	1.23	.62	.77		In Pkgs. of 5			
190497	Spacer	.15	.08	.10	190879	Plate	6.43	3.86	4.82
190507	Seat	.17	.10	.13	190880	Gasket	ea. .03	.02	.03
190508	Washer	.82	.45	.57		In Pkgs. of 10			
190509	Gasket	.05	.03	.04	190883	Ring	.07	.04	.05
190519	Hub & Drum	15.07	8.29	10.35	190885	Cage	24.17	14.50	18.13
190520	Hub & Drum	15.07	8.29	10.35	190893	Gear	15.17	9.10	11.38
190521	Hub & Drum	12.86	7.08	8.85	190895	Ring	.15	2/.18	2/.22
190522	Hub & Drum	12.86	7.08	8.85	190896	Ring	.15	2/.18	2/.22
190524	Spring	.15	.09	.11	190897	Ring	.15	2/.18	2/.22
190529	Bumper	.36	.22	.27	190900	Bushing	.60	.36	.45
190534	Ring	1.18	.71	.88	190901	Washer	.67	.40	.50
190545	Disc	.46	.28	.35	190904	Spring	.12	.07	.09
190556	Glass	.12	.07	.09	190907	Fork	2.21	1.33	1.66
					190908	Rod	1.03	.62	.77
					190909	Spring	.12	.07	.09
					190910	Retainer	.05	.03	.04

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
190912	Screw	.07	.04	.05	191291	Gasket In Pkgs. of 5	ea. .87	.44	.52
190914	Screw	.05	.03	.04	191310	Flywheel	5.14	3.09	3.86
190915	Plunger	.62	.37	.46	191311	Use 191600			
190917	Roller	12/.75	12/.45	12/.56	191313	Plate	.41	.25	.31
190918	Use 521443				191320	Pulley	5.14	3.34	4.18
190919	Ring	.07	4/.16	4/.20	191366	Washer	.03	10/.20	10/.25
190926	Ring	.10	2/.12	2/.15	191369	Block	.41	.25	.31
190927	Ring	.10	2/.12	2/.15	191390	Rod	.77	.46	.58
190928	Ring	.10	2/.12	2/.15	191393	Bushing	.17	.09	.11
190929	Ring	.10	2/.12	2/.15	191409	Washer In Pkgs. of 20	ea. .05	.03	.04
190963	Core (E)	1.03	.56	.72	191410	Use 512731			
190965	Eccentric (E)	.26	.16	.18	191427	Head	16.46	9.87	12.34
190973	Plate (E)	4.85	2.91	3.40	191454	Lever	.25	.15	.19
190976	Plate (E)	4.85	2.91	3.40	191460	Cable	2.98	1.65	2.06
190977	Plate	.17	.10	.13	191483	Bar	10.00	4.00	5.50
190983	Weight	.17	.10	.13	191488	Wheel	16.87	10.12	12.65
190984	Weight	.25	.15	.19	191489	Use 185832			
190985	Weight	.25	.15	.19	191513	Pump	14.91	8.95	11.19
190993	Stove	.68	.41	.51	191514	Shaft	1.90	1.13	1.42
190994	Ball Stud	.15	.09	.11	191516	Gear	1.50	.85	1.07
190995	Rod	.25	.15	.19	191517	Shaft	1.85	1.11	1.39
191023	Washer In Pkgs. of 10	ea. .12	.06	.08	191554	Starter	41.14	26.74	30.86
191032	Manifold	11.31	7.35	9.20	191561	Flywheel	14.50	8.70	10.88
191037	Shaft	9.77	5.67	7.09	191564	Plate	3.09	1.85	2.31
191042	Seal	.93	.56	.70	191565	Plate	3.09	1.85	2.31
191047	Cover	3.50	2.10	2.63	191569	Housing	10.54	6.85	8.57
191078	Switch	.85	.47	.57	191573	Clutch	22.11	13.27	16.59
191079	Ferrule	.07	.04	.05	191575	Hub & Drum	15.00	8.25	10.31
191088	Bracket	2.31	1.16	1.39	191576	Hub & Drum	15.00	8.25	10.31
191092	Knuckle	12.09	7.25	9.06	191577	Hub & Drum	12.90	7.10	8.88
191093	Knuckle	12.09	7.25	9.06	191578	Hub & Drum	12.90	7.10	8.88
191117	Use 525407				191579	Wheel	16.25	9.75	12.19
191130	Support	9.77	5.86	7.33	191588	Use 192183			
191131	Support	9.77	5.86	7.33	191600	Cover	.25	.13	.16
191135	Pin	1.03	.57	.71	191616	Bolt	.35	.21	.26
191136	Pin	1.03	.57	.71	191617	Bracket	.51	.31	.46
191149P	Wheel-Prime	13.60	7.48	9.35	191618	Turnbuckle In Pkgs. of 20	ea. .35	.21	.26
191150P	Wheel-Prime	15.35	8.44	10.55	191619	Nut In Pkgs. of 10	ea. .02	10/.12	3/.02
191154	Support	1.65	1.07	1.34	191622	Rod	.36	.22	.27
191158	Valve (E)	8.70	5.22	6.09	191623	Rod In Pkgs. of 20	ea. .31	.19	.24
191202	Slinger	.25	.15	.19	191625	Tube	.57	.34	.42
191203	Arm	9.00	5.40	6.75	191630	Pipe	3.50	1.93	2.41
191207	Washer In Pkgs. of 5	ea. .17	.09	.10	191640	Hanger	1.39	.91	1.13
191210	Elbow	.36	.19	.24	191641	Hanger	1.39	.91	1.13
191211	Nipple	.25	.13	.16	191645	Hub & Cups	7.20	3.96	4.95
191212	Shaft & Gears	27.67	16.29	20.37	191646	Hub & Cups	7.20	3.96	4.95
191213	Shaft & Gears	26.13	15.37	19.21	191647	Crank	.31	.19	.24
191222P	Wheel-Prime	15.35	8.44	10.55	191648	Rod	.31	.19	.24
191223	Screw	.40	.24	.30	191649	Rod	.36	.22	.27
191227	Tube	.98	.59	.72	191651	Spring	.08	.05	.06
191231	Cover	1.29	.77	.97	191658	Bracket	1.03	.62	.77
191233	Screw	.17	.10	.13	191659	Bracket	1.03	.62	.77
191235	Cushion	.20	.12	.15	191661	Use 523144			
191236	Screw	.40	.24	.30	191662	Gasket In Pkgs. of 5	ea. .15	.08	.10
191239	Lever	1.49	.89	1.12	191669	Gear	2.50	1.50	1.88
191240	Strap	.41	.25	.31	191670	Head	20.57	12.34	15.43
191242	Strap	.57	.34	.42	191671	Outlet	1.39	.83	1.04
191247	Cover	3.34	2.01	2.51	191672	Gasket	.07	5/.18	5/.23
191261	Gasket In Pkgs. of 10	ea. .20	.10	.12	191674	Plate	6.43	3.86	4.82
191262	Gasket In Pkgs. of 10	ea. .12	.06	.08	191676	Use 193116			
191279	Bolt	1.30	.72	.90	191677	Washer	.62	.37	.46
191281	Body	9.00	5.40	6.75	191678	Baffle	.15	.09	.11
191282	Cover	3.09	1.85	2.31					

## PARTS PRICE LIST

192 239

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
191679	Pin	1.49	.89	1.12	191895	Sector	1.54	.93	1.16
191682	Cage	24.17	14.50	18.13	191896	Latch	.35	.21	.26
191686	Hanger	.17	.10	.13	191913	Nut	.05	.03	.04
191689	Housing	55.03	35.77	44.72	191921	Brush Set (E)	1.02	.55	.71
191691	Drum	8.35	4.59	5.74	191922	Brush Set (E)	1.02	.55	.71
191692	Drum	8.25	4.54	5.68	191924	Link	3.34	2.01	2.51
191697	Hub & Drum	18.25	10.04	12.55	191929	Starter (E)	43.50	23.49	30.45
191698	Hub & Drum	18.25	10.04	12.55	191933	Use 527057			
191699	Hub & Drum	14.80	8.14	10.18	191939	Switch	1.90	1.14	1.43
191700	Hub & Drum	14.80	8.14	10.18	191942	Distributor (E)	17.50	9.45	12.25
191703	Washer	.50	.25	.30	191956	Bolt	.12	.07	.09
191704	Screw	.25	.15	.19	191968	Arm	3.03	1.82	2.27
191705	Screw	.25	.15	.19	191971	Bracket	1.70	1.03	1.29
191707	Shaft	10.25	5.95	7.44	191972	Hose	.87	.44	.56
191709	Gage	.51	.31	.39	191975	Core	60.00	36.00	45.00
191713	Clamp	.17	.10	.13	191976	Core	55.00	27.50	35.72
191714	Spacer	ea. .03	.02	.03	191981	Outlet	1.39	.83	1.04
	In Pkgs. of 15				191982	Extension	.57	.34	.42
191715	Nut	.06	4/.12	4/.15	191984	Hose	.62	.31	.39
191720	Clamp	.17	.10	.13	191990	Pad	.93	.56	.70
191721	Shaft & Gears	27.77	16.35	20.45	191991	Pad	.93	.56	.70
191722	Shaft	12.60	7.56	9.45					
191723	Shim	.05	5/.15	5/.19	192005	Cylinder	163.40	114.38	134.81
191724	Shim	.05	5/.15	5/.19	192017	Connector	.12	.07	.09
191725	Shim	.05	5/.15	5/.19	192033	Steering Gear	30.86	20.06	25.08
191726	Shim	.10	5/.30	5/.38	192034	Steering Gear	28.29	18.39	22.99
191736	Gear	8.74	5.25	6.56	192056	Pipe	.41	.21	.26
191737	Synchronizer	18.00	10.80	13.51	192057	Washer	.02	10/.10	10/.13
191738	Ring	3.34	2.01	2.51	192060	Pipe	.87	.44	.56
191741	Synchronizer	14.40	7.92	9.91	192085	Rod	See Green Section		
191744	Pedal	1.03	.62	.77	192086	Rod	See Green Section		
191757	Hub	4.35	2.39	2.99	192087	Rod	See Green Section		
191758	Hub	4.50	2.48	3.10	192088	Rod	See Green Section		
191766	Pipe	3.50	1.93	2.41	192089	Rod	See Green Section		
191767	Spring	.03	.02	.03	192090	Rod	See Green Section		
191769	Bolt	.67	.37	.46	192093	Bolt	.05	.03	.04
191770	Bracket	.51	.31	.39	192097	Neck	2.06	1.23	1.54
191779	Bracket	.98	.64	.80	192105	Gasket	ea. .12	.06	.07
191780	Rod (E)	.26	.16	.18		In Pkgs. of 5			
191781	Valve (E)	9.85	5.91	6.90	192107	Manifold	9.50	6.18	7.60
191782	Lever (E)	.67	.40	.47	192111	Pipe	.46	.24	.30
191784	Bracket	.93	.61	.76	192119	Spacer	.12	.07	.09
191786	Shaft	1.85	1.11	1.39	192124	Plug	.08	.05	.06
191787	Rod	.31	.19	.24	192125	Gasket	.02	10/.10	10/.13
191788	Tube	3.34	2.17	2.72	192136	Valve	ea. .17	.09	.11
191789	Shaft	1.29	.77	.97		In Pkgs. of 25			
191804	Pin	ea. .77	.46	.58	192140	Cap	.62	.31	.39
	In Pkgs. of 10				192163	Bolt	.17	.09	.11
191805	Washer	ea. .08	5/.24	5/.29	192165	Spring	ea. .06	.04	.05
	In Pkgs. of 5					In Pkgs. of 5			
191806	Washer	.03	.02	.03	192176	Sector	1.54	.93	1.16
191824	Stud	.31	.19	.24	192181	Lever	1.54	.93	1.16
191825	Stud	.31	.19	.24	192183	Bar	10.00	4.00	5.50
191826	Support	.17	.10	.13	192184	Use 192185			
191827	Support	.17	.10	.13	192185	Bar	1.70	1.03	1.28
191828	Spring	ea. .15	.09	.11	192186	Bar	1.39	.83	1.04
	In Pkgs. of 5				192188	Bar	10.00	4.00	5.50
191829	Gasket	ea. 2.50	1.37	1.63	192189	Bar	1.70	1.03	1.28
	In Pkgs. of 10				192190	Bar	1.29	.77	.97
191833	Arm	2.73	1.64	2.05	192200	Pipe	.62	.31	.39
191843	Use 523702				192201	Cover	17.35	9.54	11.93
191844	Stud	.12	.07	.09		See Green Section			
191845	Stud	.23	.14	.18	192202	Plate	12.65	6.95	8.69
191846	Stud	.23	.14	.18	192203	Facing	1.29	.65	.81
191883	Member	.93	.61	.76	192215	Rivet	.01	2/.01	.01
191884	Support	1.03	.62	.77	192234	Pan	1.23	.80	1.01
191885	Arm	3.03	1.82	2.27	192238	Cup	3.07	1.46	1.84
191891	Use 196406				192239	Cone	4.47	2.12	2.68

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
192241	Bracket	.72	.43	.55	192537	Cable	2.83	1.55	1.94
192245	Cap	.10	.06	.08	192543	Cable	.30	.15	.19
192247	Plate	.57	.34	.42	192545	Connector	.08	5/.23	5/.29
192249	Spring	.05	.03	.04	192546	Connector	ea. .12	.07	.09
192250	Spring	.05	.03	.04		In Pkgs. of 5			
192253	Cup	.07	.04	.05	192547	Connector	ea. .17	.10	.13
192254	Shaft & Impeller	1.90	.96	1.19		In Pkgs. of 5			
192257	Shaft	.77	.39	.49	192550	Sleeve & Tube	1.54	.93	1.16
192258	Pump	11.31	6.22	7.54	192559	Switch	1.39	.83	1.04
192260	Pipe	.62	.37	.46	192560	Post	9.51	6.17	7.71
192268	Rod	1.13	.68	.85	192561	Use 521194			
192275	Elbow	.30	.16	.20	192562	Cable	.51	.31	.39
192276	Gear	2.50	1.50	1.88	192567	Post	12.25	7.96	9.95
192279	Bracket	.41	.25	.31	192575	Shaft & Core(E)	3.60	1.94	2.52
192282	Gasket	ea. .10	.05	.06	192576	Core (E)	1.03	.56	.72
	In Pkgs. of 5				192591	Link	1.10	.66	.83
192283	Sleeve	8.74	5.25	6.56	192592	Stud	.77	.46	.58
192289	Ring	3.45	2.07	2.58	192599	Switch	1.00	.60	.75
192294	Plate	1.08	.65	.81	192600	Switch	.77	.46	.58
192295	Plate	1.08	.65	.81	192601	Socket & Cable	.25	.15	.19
192302	Bearing	4.65	2.21	2.76	192605	Bracket	1.70	1.10	1.38
192306	Gasket	ea. .05	.03	.04	192610	Switch	.51	.31	.39
	In Pkgs. of 5				192611	Housing	7.20	4.68	5.85
192307	Pipe	4.25	2.34	2.93	192612	Housing	7.97	5.18	6.48
192314	Piston	5.40	2.97	3.71	192613	Washer	.06	.03	.05
192315	Piston	5.40	2.97	3.71	192614	Washer	.06	.03	.05
192319	Piston	5.40	2.97	3.71	192627	Clevis	.25	.15	.19
192320	Piston	5.40	2.97	3.71	192633	Clevis	.25	.15	.19
192349	Rod	.36	.22	.27	192635	Bumper	2.06	1.23	1.54
192351	Rod	3.60	2.16	2.71	192645	Busing	.15	.09	.11
192353	Pipe	.98	.49	.62	192652	Cable	.46	.24	.30
192354	Use 196649				192659	Cable	.51	.31	.39
192355	Sleeve & Tube	1.29	.77	.97	192667	Synchronizer	23.91	14.35	17.94
192363	Plate (E)	5.50	3.30	3.86	192670	Shoe Set (E)	5.35	3.21	3.75
192364	Plate (E)	5.50	3.30	3.86	192682	Bracket	2.31	1.39	1.74
192365	Plate (E)	5.50	3.30	3.86	192688	Cap	2.57	1.42	1.78
192366	Plate (E)	5.50	3.30	3.86	192689	Cap	2.73	1.50	1.88
192379	Tube	.57	.34	.42	192696	Head	26.18	15.71	19.64
192380	Tube	.72	.43	.55	192701	Spring	32.14	17.68	22.10
192381	Cable	3.03	1.67	2.09	192705	Spring	28.03	15.43	19.29
192395	Clamp (E)	.12	.07	.08	192706	Cover	1.49	.82	1.03
192408	Bearing	.75	.45	.56	192710	Use 520941			
192414	Seat	ea. .05	.03	.04	192716	Use 520941			
	In Pkgs. of 4				192774	Use 519429			
192415	Spring	.05	.03	.04	192797	Joint	.77	.46	.58
192444	Gear	13.11	7.87	9.83	192825	Shaft (E)	3.40	1.84	2.38
192452	Pinion	1.75	1.05	1.31	192826	Core (E)	.98	.53	.69
192453	Pinion	1.75	1.05	1.31	192844	Cleaner	5.35	3.21	4.01
192466	Use 517930				192845	Shaft	.17	.10	.13
192474	Harness	5.91	3.55	4.43	192855	Head	20.57	12.34	15.43
192475	Harness	5.91	3.55	4.43	192859	Boot	.31	.19	.24
192479	Use 194021P				192874	Boot	.20	.12	.15
192480	Coil (E)	7.40	4.00	5.18	192876	Joint	.90	.54	.68
192483	Coil	4.89	3.18	3.66	192883	Shaft (E)	3.00	1.62	2.10
192484	Switch	1.03	.51	.62	192884	Core (E)	.87	.47	.61
192485	Absorber	See Green Section			192887	Shaft	12.34	8.02	10.03
192486	Absorber	See Green Section			192888	Screw	.12	.07	.09
192487	Link	1.10	.66	.83	192889	Shaft	12.34	8.02	10.03
192490	Spacer	.07	.04	.05	192895	Nut	.57	.34	.42
192508	Cylinder (E)	4.19	2.10	2.72	192896	Joint	10.13	6.08	7.60
192509	Cylinder (E)	4.19	2.10	2.72	192903	Cover	ea. .12	.07	.09
192513	Link (E)	.47	.28	.33		In Pkgs. of 10			
192516	Tube	.65	.39	.49	192907	Use 520346			
192517	Bolt	.17	.09	.11	192912	Cleaner	4.73	2.84	3.55
192518	Brush Set (E)	.57	.31	.40	192913	Cleaner	12.86	7.71	9.65
192519	Pipe	.57	.29	.36	192916	Clip	.51	.29	.36
192535	Cable	.25	.13	.16	192930	Bracket	.25	.15	.19
192536	Tube	.65	.39	.49	192931	Hanger	.17	.10	.13

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

193 687

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
192956	Spring	ea. .25	.15	.19	193164	Weight (E)	.40	.22	.28
	In Pkgs. of 5				193165	End Plate (E)	2.25	1.22	1.58
192957	Gage (E)	2.85	1.54	2.00	193166	Housing (E)	3.90	2.11	2.73
192963	Bolt	.17	.09	.11	193167	Plate (E)	6.15	3.32	4.31
192967	Gasket (E)	ea. .10	.05	.06	193168	Use 198794			
	In Pkgs. of 10				193170	Spring (E)	.08	4/.17	4/.22
192968	Screw	.25	.15	.19	193171	Arm	.03	.02	.03
192969	Gasket (E)	.07	4/.16	4/.20	193172	Shield (E)	.18	.10	.13
192976	Spring	20.16	11.09	13.87	193212	Spring	.15	.09	.11
192977	Nut	.12	.07	.09	193213	Pin	.15	.09	.11
192978	Bolt	.12	.07	.09	193214	Lever	4.22	2.53	3.17
192981	Leaf	4.37	2.41	3.01	193215	Manifold	.77	.46	.58
192982	Leaf	3.65	2.01	2.51	193216	Manifold	.77	.46	.58
192989	Screw	.03	.02	.03	193219	Shaft	14.61	8.03	10.04
					193220	Shaft	19.03	10.47	13.09
193011	Wheel	7.20	4.32	5.40	193228	Rod	.36	.22	.27
193028	Shackle	.93	.51	.65	193229	Rod	.36	.22	.27
193032	Switch	.85	.47	.57	193234	Spring	.25	.15	.19
193033	Clip	ea. .03	.02	.03	193244	Use 198378			
	In Pkgs. of 5				193248	Jacket	3.55	2.13	2.66
193034	Cable	2.06	1.23	1.54	193293	Post	9.77	6.36	7.95
193040	Cable	1.65	.99	1.23	193295	Cover	.87	.52	.66
193046	Washer	.03	.02	.03	193297	Housing	7.20	4.68	5.85
193047	Reinforcement	.41	.25	.31	193299	Use 198437			
193049	Washer & Retainer	.90	.45	.56	193324	Hose	.17	.09	.11
193058	Gear	4.47	2.46	3.08	193329	Clip	.10	.06	.08
193060	Flange	2.35	1.41	1.76	193341	Ring	.66	.33	.40
193063	Bumper	.36	.22	.27	193383	Rod	7.15	3.93	4.92
193065	Sleeve & Tube	1.29	.77	.97	193384	Rod	7.15	3.93	4.92
193066	Button & Wire	1.03	.62	.77	193385	Rod	7.15	3.93	4.92
193067	Wire & Tube	.25	.15	.19	193386	Rod	7.15	3.93	4.92
193083	Shaft	12.60	6.93	8.67	193399	Flange	2.88	1.73	2.16
193089	Slinger	.07	.04	.05	193407	Seal	.41	.25	.31
193096	Cable	3.34	1.84	2.30	193408	Lever	2.11	1.27	1.58
193101	Flange	3.03	1.82	2.27	193412	Fork	3.03	1.82	2.27
193102	Gasket	ea. .03	.02	.03	193430	Ball Joint	.62	.40	.50
	In Pkgs. of 5				193434	Shaft	.41	.25	.31
193104	Shaft	13.63	7.50	9.37	193446	Hose	.41	.25	.31
193108	Gasket	ea. .05	.03	.04	193455	Housing	4.11	2.67	3.09
	In Pkgs. of 5				193464	Bracket	.46	.28	.35
193109	Plate	6.43	3.86	4.82	193466	Bracket	.17	.10	.13
193110	Gasket	ea. .05	.03	.04	193467	Sleeve	13.89	8.33	10.42
	In Pkgs. of 5				193473	Use 192701			
193112	Rod	1.29	.77	.97	193520	Jet	.35	.21	.26
193113	Cam	1.49	.89	1.12	193523	Speedometer (E)	15.40	8.30	10.78
193114	Shaft	2.01	1.20	1.50	193543	Rod	.31	.19	.24
193115	Plunger	.62	.37	.46	193549	Pad	.93	.56	.70
193116	Gear	4.63	2.78	3.48	193550	Pad	.93	.56	.70
193117	Washer	.12	.06	.08	193610	Strap	.46	.28	.35
193119	Shaft & Gears	29.06	15.98	19.99	193617	Spacer	.36	.22	.27
193120	Gear	9.51	5.24	6.54	193628	Yoke	2.73	1.64	2.05
193121	Gear	6.94	3.82	4.77	193629	Yoke	2.73	1.64	2.05
193122	Cluster	17.74	9.76	12.20	193636	Clip	.17	.09	.11
193123	Pinion	13.37	8.02	10.03	193637	Arm	2.57	1.54	1.93
193129	Spring (E)	ea. .25	.15	.18	193638	Arm	2.57	1.54	1.93
	In Pkgs. of 5				193643	Pin	5.14	3.09	3.86
193134	Rod	7.20	3.96	4.95	193656	Plate (E)	2.25	1.22	1.58
193135	Rod	7.20	3.96	4.95	193664	Washer	ea. .12	.07	.09
193139	Use 192705					In Pkgs. of 5			
193144	Gage (E)	2.26	1.22	1.59	193684	Shim	ea. .03	.02	.03
193145	Ammeter (E)	2.05	1.11	1.44		In Pkgs. of 5			
193146	Gage (E)	3.00	1.62	2.10	193685	Shim	ea. .03	.02	.03
193147	Radimeter (E)	4.10	2.21	2.87		In Pkgs. of 5			
193159	Washer	.01	2/.01	.01	193686	Shim	ea. .03	.02	.03
193160	Plug	ea. .02	.01	.01		In Pkgs. of 5			
	In Pkgs. of 5				193687	Shim	ea. .03	.02	.03
193162	Camshaft	2.11	1.14	1.48		In Pkgs. of 5			

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
193688	Shim	ea. .03	.02	.03	194241	Bearing	1.05	.52	.63
	In Pkgs. of 5				194247	Bushing	ea. .20	.10	.13
193698	Lifter	ea. 1.03	.57	.71		In Pkgs. of 4			
	In Pkgs. of 6				194257	Bearing	.85	.42	.51
193723	Link	2.31	1.39	1.74	194263	Use 513005			
193728	Shim	ea. .05	.03	.04	194264	Washer	.20	.12	.15
	In Pkgs. of 5				194269	Bushing	.30	.18	.23
193744	Frame	90.47	58.81	73.50	194272	Ring	.08	2/.10	2/.12
193802	Insulator	2/.01	4/.01	3/.01	194273	Ring	.03	5/.10	5/.13
193804	Condenser	ea. .72	.36	.43	194274	Bearing	.85	.43	.51
	In Pkgs. of 5				194275	Ring	ea. .07	.04	.05
193830	Pulley (E)	1.59	.86	1.11		In Pkgs. of 4			
193831	Cover	.05	.03	.04	194276	Ring	.08	2/.10	2/.12
193832	Washer	.05	.03	.04	194283	Cover	.07	.04	.05
193876	Spacer	ea. .07	.04	.05	194284	Washer	ea. .15	.08	.10
	In Pkgs. of 10					In Pkgs. of 5			
193878	Grommet	ea. .08	.04	.05	194285	Catcher	.25	.14	.18
	In Pkgs. of 8				194288	Washer	.40	.20	.24
193884	Bushing	.30	.18	.23	194289	Washer	ea. .17	.09	.10
193905	Bolt	.15	.09	.11		In Pkgs. of 2			
193906	Arm	3.03	1.82	2.27	194290	Cap	.12	.07	.09
193983	Spacer	1.03	.62	.77	194291	Washer	.06	.03	.04
193987	Arm	9.00	5.40	6.75	194292	Nut	ea. .08	.05	.06
193988	Arm	9.00	5.40	6.75		In Pkgs. of 10			
194007	Spring	30.86	16.97	21.22	194312	Armature (E)	13.35	7.21	9.35
194015	Bolt	.12	.07	.09		Add \$1.00 net charge pending return of old armature			
194016	Spacer	.93	.56	.70	194313	Plate (E)	6.00	3.24	4.20
194017	Spacer	.93	.56	.70	194314	Use 196330			
194018	Clip	.51	.29	.36	194318	Knuckle	10.80	6.48	8.11
194021P	Lock & Cable(E)	6.15	3.32	4.31	194319	Knuckle	10.80	6.48	8.11
194022P	Lock & Cable	5.76	3.46	4.32	194323	Steering Gear	24.17	15.72	19.65
194030	Point Set	1.49	.75	.89	194324	Gear	2.57	1.54	1.93
194031	Point Set	1.49	.75	.89	194334	Use S-346			
194032	Point Set	3.03	1.55	1.85	194335	Use S-346			
194033	Point Set	3.03	1.55	1.85	194347	Bushing	.23	4/.50	4/.63
194034	Point Set	1.49	.75	.89	194348	Bearing	.17	4/.36	4/.45
194035	Point Set (E)	1.23	.66	.86	194350	Use 527420			
194036	Point Set (E)	1.23	.66	.86	194359	Guide	.38	.19	.23
194037	Plate	3.60	2.16	2.71	194373	Washer	ea. .06	.04	.05
194041	Nut	.05	5/.15	5/.19		In Pkgs. of 10			
194062	Use 525810				194374	Use 525956			
194077	Washer	.57	.34	.42	194379	Bumper	.60	.36	.45
194078	Shim	.04	5/.10	5/.13	194383	Spring	.05	.03	.04
194132	Bushing	.30	.15	.19	194392	Bushing	.17	4/.36	4/.45
194152	Axle	123.43	80.23	100.29	194395	Lock	.08	4/.16	4/.20
194153	Axle	123.43	80.23	100.29	194401	Clip	.36	.20	.25
194166	Plug	.10	4/.24	4/.30	194402	Bushing	.25	.13	.16
194176	Hub	6.50	3.58	4.48	194405	Shim	.03	20/.40	20/.50
194180	Retainer	.12	.07	.09	194406	Shim	ea. .03	.02	.03
194182	Wheel-Prime	14.00	7.70	9.63		In Pkgs. of 20			
194194	Gasket	.02	10/.10	10/.13	194407	Shim	ea. .03	.02	.03
194197	Knob	.31	.19	.24		In Pkgs. of 20			
194202	Ring	ea. .02	.01	2/.03	194408	Shim	ea. .03	.02	.03
	In Pkgs. of 10					In Pkgs. of 20			
194208	Valve	8.43	5.06	6.33	194409	Shim	.03	.02	.03
194211	Cup	2.38	1.13	1.43		In Pkgs. of 5			
194212	Cone	3.67	1.74	2.20	194412	Gasket	.05	10/.25	10/.31
194214	Cup	1.83	.87	1.10	194414	Use 140706			
194215	Cone	2.90	1.38	1.74	194453	Knuckle	8.74	5.25	6.56
194216	Valve	ea. .86	.43	.54	194454	Knuckle	8.74	5.25	6.56
	In Pkgs. of 6				194459	Screw	.10	4/.20	4/.25
194217	Valve	ea. 1.20	.60	.75	194461	Cap	1.39	.83	1.04
	In Pkgs. of 6				194467	Gasket	.03	10/.15	10/.19
194219	Gasket	ea. .20	.10	.12	194483	Nut	.03	.02	.03
	In Pkgs. of 10				194484	Gasket	.17	5/.43	5/.54
194225	Use 519077				194493	Hub	1.03	.62	.77
194228	Plate	ea. .57	.34	.42					
	In Pkgs. of 12								



## PARTS PRICE LIST

195 021

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
194496	Spacer In Pkgs. of 25	ea. .12	.07	.09	194747	Plate	2.78	1.67	2.09
194505	Retainer In Pkgs. of 10	ea. .06	.04	.05	194750	Use 526119			
194507	Bracket	.46	.28	.35	194751	Use 192701			
194510	Motor	10.29	6.17	7.71	194752	Use 195746			
194511	Support	.37	.22	.27	194753	Spring	19.80	10.89	13.62
194512	Fan	.72	.43	.55	194754	Use 520951			
194520	Support	2.11	1.27	1.58	194755	Cover	1.65	.91	1.13
194521	Core	12.09	7.25	9.06	194774P	Jacket	3.55	2.13	2.66
194525	Hub & Drum	14.35	7.89	9.86	194777	Head	14.66	8.79	11.00
194526	Hub & Drum	14.35	7.89	9.86	194778	Seat In Pkgs. of 4	ea. .05	.03	.04
194537	Use 680291				194779	Cap In Pkgs. of 10	ea. .36	.22	.27
194542	Bolt	.10	4/.24	4/.30	194782	Member	10.29	6.69	8.36
194551	Boot	.41	.25	.31	194802	Use 523511			
194555	Pedal	2.31	1.39	1.74	194803	Retainer In Pkgs. of 25	ea. .03	.02	.03
194557	Bushing In Pkgs. of 4	ea. .07	.04	.05	194805	Ferrule In Pkgs. of 20	ea. .17	.10	.13
194561	Shaft	.72	.43	.55	194817	Gear	2.65	1.59	1.99
194562	Grommet In Pkgs. of 5	ea. .12	.07	.09	194823	Retainer	.03	.02	.03
194567	Rod	.77	.46	.58	194826	Cone	3.45	1.64	2.07
194570	Spring In Pkgs. of 5	ea. .03	.02	.03	194831	Pipe	.98	.49	.62
194574	Ferrule	.05	.03	.04	194835	Shaft	1.03	.60	.75
194576	Cable	.46	.28	.35	194836	Washer In Pkgs. of 10	ea. .15	.09	.11
194592	Washer In Pkgs. of 20	ea. .06	.04	.05	194837	Gasket	.12	5/.30	5/.38
194601	Rod In Pkgs. of 20	ea. .20	.12	.15	194838	Washer In Pkgs. of 10	ea. .15	.09	.11
194603	Turnbuckle	.30	.18	.23	194839	Cover	1.49	.89	1.12
194604	Nut	.02	25/.25	25/.31	194840	Shaft	9.25	5.37	6.71
194611	Shim	.03	.02	.03	194841	Key	.15	5/.40	5/.50
194621	Arm	3.34	2.01	2.51	194842	Regulator (E)	10.10	5.45	7.07
194635	Joint	2.73	1.64	2.05		See Green Section			
194640	Stud	.36	.22	.27	194843	Shim In Pkgs. of 4	ea. .05	.03	.04
194641	Screw	.12	.07	.09	194844	Shim In Pkgs. of 4	ea. .05	.03	.04
194643	Sleeve	.45	.27	.35	194845	Shim In Pkgs. of 4	ea. .05	.03	.04
194644	Shaft	1.70	1.03	1.29	194846	Shim Set In Pkgs. of 4	ea. .07	.04	.05
194649	Drum	7.75	4.26	5.33	194850	Gear Set	29.50	17.11	21.39
194650	Shaft	1.03	.62	.77	194851	Pipe	.67	.34	.42
194658	Gasket	.03	10/.15	10/.18	194854	Block	.93	.56	.70
194660	Gasket	.05	5/.13	5/.15	194873	Pipe	.87	.44	.56
194665	Plug	.10	.06	.08	194874	Pipe	.57	.29	.36
194671	Use 526020				194879	Pipe	1.03	.51	.65
194672	Hanger	.17	.10	.13	194880	Pipe	1.03	.51	.65
194676	Clamp	.12	.07	.09	194884	Flywheel	12.00	7.20	9.00
194680	Block	73.80	51.66	60.89	194893	Tee (E)	.36	.22	.26
194682	Spring In Pkgs. of 5	ea. .20	.12	.15	194894	Cap	2.57	1.42	1.78
194683	Clip	.03	.02	.03	194903	Hanger	.17	.10	.13
194686	Shaft	.93	.56	.70	194911	Use 1 ea. 196778, 196782 & 2-196779			
194695	Hose (E)	1.86	.93	1.12	194955	Shaft	1.39	.83	1.04
194697	Tee (E)	.38	.23	.27	194978	Support	1.18	.77	.97
194700	Nut (E)	.05	.03	.04	194994	Member	10.85	7.06	8.83
194701	Use 675466				194998	Bracket	.46	.28	.35
194702	Clip	.03	.02	.03					
194708P	Shaft	4.06	2.44	3.04	195001	Elbow	.40	.24	.30
194716	Cover	.25	.15	.19	195011	Ring In Pkgs. of 6	ea. .96	.48	.58
194717	Gasket In Pkgs. of 5	ea. .05	.03	.04	195015	Bar	6.50	2.60	3.57
194718	Spring	.05	.03	.04	195016	Bar	1.23	.74	.93
194722	Screw	.03	.02	.03	195017	Bar	1.23	.74	.93
194725	Clip	.12	.07	.09	195018	Bar	1.23	.74	.93
194726	Washer In Pkgs. of 20	ea. .03	.02	.03	195019	Bar	1.23	.74	.93
194728	Key	.02	.01	.01	195021	Bar	1.13	.68	.85
194738	Clevis	.25	.15	.19					

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
195022	Bar	1.13	.68	.85	195407	Clip	.15	.09	.11
195023	Bar	1.13	.68	.85	195426	Wheel	16.25	9.75	12.19
195024	Bar	1.13	.68	.85	195428	Tube	.93	.56	.70
195032	Bracket	.72	.43	.55	195429	Lock	.08	.04	.05
195058	Brush Set	.30	.15	.18	195430	Shaft	14.61	8.03	10.04
195059	Brush Set	.72	.36	.43	195433	Pipe	3.90	2.15	2.54
195087	Cradle	1.70	1.10	1.38	195448	Rod	.62	.37	.46
195090	Shield	.62	.40	.50	195450	Rod	.46	.28	.35
195094	Use 514572 LHC or 514573 RHC				195452	Crank	.36	.22	.27
195116	Neck	2.06	1.23	1.54	195453	Bracket	1.18	.71	.88
195117	Case	12.24	7.10	8.36	195458	Tube	.93	.56	.70
195121	Rod	3.60	2.16	2.71	195460	Plate	1.29	.77	.97
		See Green Section			195461	Spring	.05	.03	.04
195122	Rod	3.60	2.16	2.71	195462	Ring	.12	.07	.09
		See Green Section			195463	Arm	3.03	1.82	2.27
195124	Shaft & Weights (E)	4.65	2.51	3.26	195465	Gage	2.83	1.70	2.13
195155	Cap	1.08	.65	.81	195467	Pipe	1.08	.55	.68
195156	Cap	1.08	.65	.81	195470	Fitting (E)	.38	.23	.27
195157	Cap	2.31	1.39	1.74	195475	Valve (E)	9.85	5.91	6.90
195165	Cylinder (E)	4.19	2.10	2.72	195476	Valve (E)	9.85	5.91	6.90
195166	Cylinder (E)	4.19	2.10	2.72	195489	Lock & Keys	1.54	.93	1.16
195167	Plate (E)	6.20	3.72	4.34	195491	Sockets & Cable	.67	.40	.50
195168	Plate (E)	6.20	3.72	4.34	195492	Bumper	2.21	1.49	1.82
195177	Flange	.46	.28	.35	195496	Plate	2.31	1.39	1.74
195194	Arm	2.31	1.39	1.74	195497	Plate	2.31	1.39	1.74
195195	Arm	2.31	1.39	1.74	195498	Plate	2.31	1.39	1.74
195208	Pin	.25	.15	.19	195500	Use 513141			
195211	Washer	ea. .02	.01	.01	195501	Use 513141			
	In Pkgs. of 20				195502	Pinion	1.75	1.05	1.31
195227	Screw	.08	.05	.06	195503	Pinion	1.75	1.05	1.31
195228	Shaft	1.29	.77	.97	195504	Pinion	1.75	1.05	1.31
195230	Cover	16.00	8.80	11.00	195505	Switch	1.18	.71	.88
195231	Rod	.36	.22	.27	195506	Clevis	.35	.21	.26
195233	Member	.93	.61	.76	195511	Flywheel	13.37	8.02	10.03
195235	Bolt	.05	.03	.04	195513	Cap	.12	.07	.09
195236	Bracket	.31	.19	.24	195515	Use 196631			
195238	Use 197299				195518	Use 196631			
195263	Bar	10.00	4.00	5.50	195528	Flange	5.14	3.09	3.86
195265	Bar	1.70	1.02	1.28	195531	Fan Blades	1.54	.93	1.16
195266	Bar	1.59	.96	1.19	195542	Cover	1.19	.71	.83
195268	Pin	ea. .62	.31	.39	195548	Nut	ea. .07	.04	.05
	In Pkgs. of 24					In Pkgs. of 4			
195275	Washer	ea. .03	.02	.03	195551	Rod	ea. .20	.12	.15
	In Pkgs. of 10					In Pkgs. of 10			
195278	Link	1.00	.60	.75	195567	Clip	.03	.02	.03
195279	Fitting (E)	.38	.23	.27	195568	Hose (E)	1.86	.93	1.12
195280	Plate	1.23	.74	.93	195569	Gasket (E)	ea. .03	.02	.03
195282	Use 519636					In Pkgs. of 10			
195283	Bracket	1.39	.83	1.04	195572	Switch	.72	.43	.55
195284	Bushing	.12	8/.48	8/.50	195573	Bolt	ea. .20	.10	.13
195285	Use 523300					In Pkgs. of 10			
195286	Seat	.09	12/.60	12/.75	195574	Bolt	.20	.10	.13
195287	Use 679074				195575	Use 197402			
195297	Use 199695				195587	Use 513229			
195298	Use 521999				195592	Switch	.87	.52	.66
195299	Cover	.72	.43	.55	195593	Switch	1.00	.60	.75
195304	Gasket	.04	10/.20	10/.25	195594W	Nut	ea. .12	.07	.09
195305	Gasket	.04	10/.20	10/.25		In Pkgs. of 20			
195319	Tube	.62	.37	.46	195595	Knob	.31	.19	.24
195385	Spacer	.12	.07	.09	195596	Switch	1.00	.60	.75
195394	Use 197167				195597	Switch	.77	.46	.58
195398	Cover	8.13	4.47	5.60	195600	Gasket	ea. .03	10/.15	.02
195400	Spring	.05	.03	.04		In Pkgs. of 20			
195401	Screw	.05	.03	.04	195603	Filter (E)	See Pink Sheet On Fram Filters		
195402	Bearing & Collar	4.60	2.30	2.76	195611	Bracket	.20	.12	.15
195405	Use 532125 or 532126				195613	Generator (E)	38.75	20.93	27.13
195406	Shaft	.20	.12	.15					

## PARTS PRICE LIST

196 019

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
195616	Spring In Pkgs. of 12	ea. .06	.04	.05	195829	Core	1.65	.99	1.24
195618	Furnished Only In Set 526223				195830	Harness	5.91	3.55	4.43
195619					195832	Harness	5.91	3.55	4.43
195620					195835	Leaf	4.11	2.26	2.83
195621					195852	Rod	.46	.28	.35
195626	Absorber	7.50	4.90	5.90	195859	Block	.95	.57	.71
		See Green Section			195873	Pin In Pkgs. of 24	ea. .62	.31	.39
195627	Absorber	7.50	4.90	5.90	195874	Pin	.62	.31	.39
		See Green Section			195875	Rod	3.60	2.16	2.71
195629	Bracket	3.35	2.01	2.51			See Green Section		
195634	Absorber	10.50	6.70	8.15	195876	Rod	3.60	2.16	2.71
		See Green Section					See Green Section		
195635	Absorber	10.50	6.70	8.15	195877	Rod	3.60	2.16	2.71
		See Green Section					See Green Section		
195636	Absorber	10.50	6.70	8.15	195878	Rod	3.60	2.16	2.71
		See Green Section					See Green Section		
195640	Link	1.50	.90	1.13	195891	Bolt	.25	.13	.15
195641	Link	1.50	.90	1.13	195892	Crank	.36	.22	.27
195643	Bracket	1.00	.60	.75	195893	Nut	.03	.02	.03
195655	Regulator (E)	12.35	6.67	8.65	195894	Gage	.51	.31	.39
		See Green Section			195895	Gage	.51	.31	.39
195660	Use 196970				195897	Pin	1.13	.63	.78
195669	Pin	.15	.09	.11	195898	Fitting In Pkgs. of 10	ea. .12	.07	.09
195670	Pipe	.67	.34	.42	195906P	Lever	2.31	1.39	1.74
195671	Pipe	.36	.19	.24	195910	Latch	.35	.21	.26
195674	Stud In Pkgs. of 20	ea. .12	.07	.09	195911	Plug In Pkgs. of 20	ea. .02	.01	.01
195675	Knob	.31	.19	.24	195912	Blower	9.00	5.40	6.75
195676	Knob	.31	.19	.24	195913	Cable	1.80	1.08	1.35
195711	Rod	.36	.22	.27	195914	Cable	.12	.06	.08
195714	Bar	10.00	4.00	5.50	195916	Outlet	.77	.46	.58
195715	Swivel	.20	.12	.15	195919	Cover	.87	.52	.66
195716	Swivel	.20	.12	.15	195920	Bracket	.93	.56	.70
195717	Spring	.05	.03	.04	195922	Pedal	1.09	.65	.81
195720	Rod	.25	.15	.19	195922AB	Use 195922			
195726	Bracket	.17	.10	.13	195923	Rod	.25	.15	.19
195731	Use 532127, or 532128				195924	Hose	1.50	.83	.98
195736	Cover	1.49	.82	1.03	195926	Screw (E)	.36	.22	.25
195737	Cover	1.49	.82	1.03	195927	Bracket	.41	.25	.31
195744	Spring	18.51	10.18	12.73	195935	Fork & Lever	1.13	.68	.85
195745	Use 520941				195941	Rod	.50	.30	.38
195746	Spring	18.51	10.18	12.73	195944	Knob	.31	.19	.24
195747	Use 520951				195945	Knob	.31	.19	.24
195748	Strip	.30	.17	.21	195946	Knob	.31	.19	.24
195751	Cover	1.65	.91	1.13	195947	Gasket In Pkgs. of 10	ea. .02	.01	2/.03
195769	Use 513449				195948	Switch (E)	1.85	1.00	1.30
195770	Bracket	.20	.12	.15	195949	Bracket	.17	.10	.13
195771	Arm	.17	.10	.13	195950	Plate	.08	.05	.06
195772	Spacer	.05	4/.12	4/.15	195963	Stud	.15	.09	.11
195774	Switch In Pkgs. of 10	ea. .87	.52	.66	195965	Rod	.31	.19	.24
195792	Fuse	.06	5/.17	5/.20	195970	Spacer	1.65	.99	1.23
195793	Retainer (E)	.07	.04	.05	195975	Crank	.31	.19	.24
195794	Harness	5.91	3.55	4.43	195978	Tube	.93	.55	.70
195800	Use 523099				195979	Stud	.15	.09	.11
195801	Cushion	.77	.39	.49	195981	Valve & Lever (E)	8.74	5.25	6.12
195802	Grommet	.12	.07	.09	195982	Lever & Guide (E)	.73	.44	.51
195803	Retainer	.12	.07	.09	195984	Sector	.77	.46	.58
195805	Cable	1.29	.71	.88	195999	Spring	.20	.12	.15
195806	Use 529408 x 19								
195809	Bearing	.75	.45	.56	196019	Pump	9.75		
195823	Spring	30.60	16.83	21.03		# Lots of 1 to 5		5.94	5.94
195824	Shaft	4.00	2.40	3.00		6 to 11		5.46	5.46
195825	Core	1.95	1.17	1.46		12 or more		4.97	4.97
195826	Shaft	4.00	2.40	3.00					
195827	Core	1.95	1.17	1.46					
195828	Shaft	3.50	2.10	2.63					

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
196022	Jacket	3.55	2.13	2.66	196182	Spring	.15	.09	.11
196025	Absorber	5.75	3.00	3.58	196183	Seal	.41	.25	.31
196026	Absorber	5.75	3.00	3.58	196184	Plate	1.49	.89	1.12
196029	Absorber	5.75	3.00	3.58	196185	Ring	.12	.07	.09
196030	Absorber	5.75	3.00	3.58	196186	Shaft	13.89	8.33	10.42
196036	Generator (E)	38.75	20.93	27.13	196191	Spring	.12	.07	.09
196037	Cushion	.40	.22	.28	196193	Cage	21.60	12.96	16.20
196046	Pin	1.03	.56	.71	196197	Washer	.05	.03	.04
196048	Washer	ea. .03	.02	.03	196198	Solenoid	9.77	5.86	7.33
	In Pkgs. of 6				196199	Base	.31	.19	.24
196049	Washer	ea. .03	.02	.03	196200	Gasket	ea. .03	.02	.03
	In Pkgs. of 10					In Pkgs. of 5			
196061	Crank	.31	.19	.24	196201	Gasket	ea. .03	.02	.03
196069	Gear	1.55	.85	1.06		In Pkgs. of 5			
196070	Pulley (E)	1.29	.70	.90	196213	Mask	.31	.19	.24
196074	Cable	.46	.28	.35	196215	Glass	.62	.37	.46
196080	Bushing & Retainer	.98	.59	.73	196219	Gage	3.09	1.85	2.31
196087	Spring	.08	.05	.06	196220	Insulator	.05	.03	.04
196088	Housing	10.29	6.69	8.36	196226	Radimeter	5.40	3.24	4.05
196090	Clamp	.12	.07	.09	196227	Glass	.77	.46	.58
196093	Bracket	.41	.25	.31	196236	Gage	2.31	1.39	1.74
196094	Lock & Cable (E)	5.05	2.73	3.54	196254	Lever	.36	.22	.27
196095	Lock & Cable	4.73	2.84	3.55	196255	Lever	.36	.22	.27
196096	Cover (E)	15.00	8.25	10.31	196272	Pulley	2.98	1.79	2.24
	See Green Section				196276	Gasket	ea. .17	10/.85	.10
						In Pkgs. of 10			
196110	Cap & Gage	.93	.56	.70	196284	Use 527171			
196123	Spring	.08	.05	.06	196286	Cup	3.51	1.67	2.11
196124	Switch (E)	1.44	.78	1.01	196287	Cone	4.49	2.13	2.67
196125	Cover	.46	.28	.35	196295	Armature (E)	14.80	7.99	10.36
196126	Gasket	ea. .22	.11	.13		Add \$1.00 net charge pending return of old armature			
	In Pkgs. of 10				196296	Bolt (E)	.09	.05	.06
196127	Use 1-0552				196297	Use 531761			
196128	Support	2.57	1.68	2.10	196299	Plate (E)	3.85	2.08	2.70
196130	Use 522159				196300	Cover (E)	.25	.14	.18
196131	Case	17.23	11.20	14.00	196301	Gasket	ea. .02	.01	.01
196134	Case	13.11	8.53	10.66		In Pkgs. of 10			
196137	Gasket	.10	.05	.06	196306	Housing & Carrier	48.34	31.42	39.28
196140	Shaft	14.14	7.78	9.72	196307	Resistance (E)	.16	.09	.11
196141	Shaft	12.60	6.93	8.67	196308	Nut	.10	5/.28	5/.35
196142	Baffle	.07	.04	.05	196309	Nut	.10	5/.28	5/.35
196143	Gear	9.51	5.24	6.54	196313	Case	9.15	5.31	6.63
196145	Gear	5.66	3.12	3.90	196314	Gear	2.50	1.50	1.88
196147	Plate	.30	.17	.21	196324	Bolt	.06	.04	.05
196148	Ring	ea. .08	.05	.06	196325	Use 720-04			
	In Pkgs. of 5				196327	Slinger	.12	.06	.08
196149	Ring	1.95	1.17	1.47	196328	Shim	ea. .05	.03	.04
196151	Seal	ea. .03	.02	.03		In Pkgs. of 4			
	In Pkgs. of 10				196330	Plate (E)	4.65	2.51	3.26
196152	Seal	.03	.02	.03	196332	Manifold	13.11	8.53	10.66
196154	Shaft	1.18	.71	.88	196333	Clamp	.12	.07	.09
196158	Link	1.18	.71	.88	196341	Fan	.51	.31	.36
196162	Lever	.17	.10	.13	196342	Pulley	4.63	3.00	3.45
196163	Rod & Fork	4.53	2.72	3.39	196348	Screw	.10	.06	.08
196167	Poppet	.10	2/.12	2/.15	196354	Spacer	.25	.15	.19
196168	Spring	ea. .03	.02	.03	196361	Retainer	.08	.05	.06
	In Pkgs. of 10				196378	Spring	ea. .07	.04	.05
196170	Plunger	.62	.37	.46		In Pkgs. of 4			
196171	Lever	.25	.15	.19	196383	Stud	.25	.15	.19
196172	Housing	13.89	9.03	11.29	196384	Cable	2.31	1.39	1.74
196173	Plate	7.71	4.63	5.79	196385	Cable	2.31	1.39	1.74
196174	Gear	13.63	8.18	10.22	196386	Cable	.31	.19	.24
196175	Gear	5.40	3.24	4.05	196393	Shim	ea. .05	.03	.04
196176	Plate	5.91	3.55	4.43		In Pkgs. of 4			
196177	Spring	.12	.07	.09	196394	Use 521825			
196178	Ring	2.16	1.30	1.63	196395	Bracket	1.29	.77	.97
196179	Pawl	1.75	1.05	1.32					
196181	Rod	.77	.46	.58					

## PARTS PRICE LIST

196 663

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
196396	Bracket	1.39	.83	1.04	196560	Seat(E)	.26	.16	.18
196400	Guard	.08	.05	.06	196561	Plug (E)	1.05	.63	.74
196401	Wheel	14.91	8.95	11.19	196562	Gasket (E)	ea. .11	.07	.09
196404	Plate	1.23	.74	.93		In Pkgs. of 10			
196405	Cap	.08	.05	.06	196563	Use 1 ea. 525031 & 525032			
196406	Flange	5.14	3.09	3.60	196567	Bolt	.20	4/.40	4/.50
196408	Bracket	.12	.07	.09	196570	Hanger	.72	.47	.60
196413	Cover	.62	.37	.46	196571	Yoke	2.57	1.54	1.93
196414	Gasket	.17	5/.43	5/.51	196572	Yoke	2.57	1.54	1.93
196420	Bolt	.15	.09	.11	196573	Clevis	.41	.25	.29
196432	Use 678781				196574	Plate	.77	.46	.56
196437	Sleeve & Tube	.46	.28	.35	196575	Ring	ea. .66	.33	.40
196438	Button & Wire	.41	.25	.31		In Pkgs. of 6			
196441	Shaft	3.85	1.93	2.31	196576	Bolt	.67	.37	.46
196443	Button	1.18	.71	.88	196578	Clip	.51	.29	.36
196446	Jacket	3.55	2.13	2.66	196580	Bushing	.40	.22	.28
196447	Jacket	3.55	2.13	2.66	196582	Support	.25	.15	.19
196448	Jacket	3.55	2.13	2.66	196584	Bolt	ea. .20	.12	.15
196450	Spring	9.77	5.38	6.73		In Pkgs. of 10			
196451	Hanger	1.59	1.03	1.29	196585	Use 527058			
196459	Use 734-04				196586	Bolt	ea. .12	.07	.09
196471	Shim	.05	8/.24	8/.30		In Pkgs. of 10			
196472	Shim	.05	4/.12	4/.15	196589	Washer	ea. .12	.07	.09
196473	Shim	.05	4/.12	4/.15		In Pkgs. of 25			
196474	Shim	.05	4/.12	4/.15	196591	Washer	.06	5/.18	5/.23
196475	Plate (E)	4.30	2.58	3.01	196592	Bushing	.35	.21	.26
196476	Plate (E)	4.30	2.58	3.01	196593	Arm	2.73	1.64	2.05
196482	Plate (E)	4.19	2.51	2.93	196595	Arm	3.03	1.82	2.27
196483	Plate(E)	4.19	2.51	2.93	196596	Ring	ea. .66	.33	.40
196492	Link	4.40	2.64	3.30		In Pkgs. of 6			
196497	Eccentric(E)	.23	.14	.16	196598	Bumper	2.21	1.49	1.82
196498	Pin (E)	.23	.14	.16	196614	Ring	ea. .66	.33	.40
196500	Link & Slide (E)	.47	.28	.33		In Pkgs. of 6			
196506	Bolt	.08	.05	.06	196615	Ring	ea. .66	.33	.40
196507	Bolt	.20	.12	.15		In Pkgs. of 6			
196508	Bracket	.15	.09	.11	196617	Ring	ea. .66	.33	.40
196510	Rod	.31	.19	.24		In Pkgs. of 6			
196511	Bell Crank	.31	.19	.24	196618	Ring	ea. .66	.33	.40
196512	Rod	.25	.15	.19		In Pkgs. of 6			
196514	Rod	.25	.15	.19	196620	Ring	ea. .96	.48	.58
196515	Swivel	.20	.12	.15		In Pkgs of 6			
196516	Cover (E)	ea. .06	.04	.05	196621	Use 527272			
	In Pkgs. of 10				196623	Bracket	1.03	.62	.77
196519	Wheel	5.91	3.55	4.43	196626	Bracket	1.13	.68	.85
196521	Button	.93	.56	.70	196627	Bracket	1.13	.68	.85
196523	Use 192057				196631	Button	1.29	.77	.97
196528	Arm	9.51	5.71	7.14	196633	Clamp	.12	.07	.09
196530	Lifter	ea. 1.03	.57	.71	196638	Bumper	.36	.22	.27
	In Pkgs. of 6				196639	Shaft	34.20	18.81	23.51
196531	Lifter	ea. 1.03	.57	.71	196640	Pipe	.62	.31	.39
	In Pkgs. of 6				196643	Bushing	.15	8/.56	8/.70
196538	Screw	.12	.07	.09	196644	Bolt	.25	.14	.18
196539	Screw	.10	.06	.08	196646	Cartridge (E)	See Pink Sheet on Fram Filters		
196540	Knob	.31	.19	.24	196648	Shaft	15.33	8.43	10.54
196541	Knob	.31	.19	.24	196649	Pipe	1.75	.87	1.09
196542	Knob	.31	.19	.24	196651	Bearing	ea. .89	.49	.61
196543	Knob	.31	.19	.24		In Pkgs. of 4			
196547	Cup (E)	ea. .34	.17	.20	196653	Cap	.30	.17	.21
	In Pkgs. of 10				196655	Valve & Shaft	1.08	.65	.81
196548	Use 523924				196658	Spacer	ea. .05	.03	.04
196549	Piston (E)	.88	.44	.53		In Pkgs. of 4			
196551	Cup (E)	.34	.20	.24	196660	Pin	ea. .03	.02	.03
196552	Ring (E)	.10	.06	.07		In Pkgs. of 5			
196553	Use 523925				196661	Thermostat	ea. .51	.31	.39
196554	Stop (E)	.11	.07	.08		In Pkgs. of 10			
196557	Use 1 ea. 525031 & 525032				196662	Balance	.41	.25	.31
196558	Cup (E)	.26	.16	.18	196663	Screw	.05	.03	.04

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
196664	Clamp	.12	.06	.08	196882	Speedometer (E)	14.20	7.67	9.94
196667	Use 529408X19				196884	Gage & Radimeter (E)	6.35	3.43	4.45
196668	Use 529410X35				196885	Gage & Ammeter (E)	5.40	2.92	3.78
196673	Cup	.08	.05	.06	196888	Glass	.12	.07	.09
196674	Yoke	6.02	3.31	4.15	196891	Radimeter (E)	4.10	2.21	2.87
196675	Clamp	.62	.37	.46	196895	Glass	.36	.22	.27
196685	Nut	.05	4/.12	4/.15	196897	Gage (E)	3.10	1.67	2.17
196689	Cover	.51	.31	.39	196898	Ammeter (E)	1.95	1.05	1.37
196690	Rod	.25	.15	.19	196899	Gage (E)	1.90	1.03	1.33
196692	Pipe	3.25	1.79	2.24	196900	Lock & Keys	1.54	.93	1.16
196693	Gasket ea. .55		.28	.33	196903	Key	.30	.15	.19
	In Pkgs. of 10				196906	Coil (E)	6.85	3.70	4.80
196694	Bracket	.08	.05	.06	196910	Lock & Cable (E)	4.65	2.51	3.26
196695	Clip	.17	.10	.13	196911	Belt	1.75	.88	1.05
196696	Guide	.12	.07	.09	196912	Rod	.77	.46	.58
196699	Cock	.30	.15	.19	196918	Gear	2.50	1.50	1.88
196701	Cable	2.57	1.42	1.78	196922	Gasket	.03	10/.15	10/.19
196704	Clevis	.35	.21	.26	196923	Pipe	3.25	1.79	2.24
196705	Outlet	1.40	.84	1.05	196930	Stud	.12	5/.35	5/.44
196707	Screw	.17	.09	.11	196931	Stud	.12	5/.35	5/.44
196709	Spacer	.20	.12	.15	196937	Harness	2.06	1.23	1.54
196710	Nut	2/.03	48/.37	48/.46	196938	Harness	2.06	1.23	1.54
196711	Clip	.62	.34	.42	196939	Use 525407			
196712	Clip	.62	.34	.42	196940	Clamp	.12	.07	.09
196713	Clip	.62	.34	.42	196941	Pinion	1.75	1.05	1.31
196714	Clip	.62	.34	.42	196947X1	Pedal	1.25	.75	.94
196715	Cable	3.03	1.67	2.09	196952	Spring ea. .05		.03	.04
196717	Insulator	1.65	.83	.99		In Pkgs. of 10			
196718	Member	2.42	1.57	1.96	196953	Use 519079			
196726	Rod	.25	.15	.19	196954	Use 519080			
196727	Washer ea. .03		.02	.03	196964P	Bracket	.67	.40	.50
	In Pkgs. of 5				196965	Washer	.06	5/.17	5/.21
196734	Support	.12	.06	.08	196967	Use 513141			
196736	Shaft	.72	.43	.55	196968	Use 513141			
196741	Harness	6.00	3.60	4.50	196969	Hose	.41	.25	.31
196745	Fork & Lever	1.13	.68	.85	196970	Hose	1.34	.80	1.01
196752	Clevis	.35	.21	.26	196971				
196754	Bushing	.08	.05	.06	196972	Furnished Only			
196755	Lever	1.54	.93	1.16	196973	In Set			
196774	Support	.31	.19	.24	196974	526224			
196778	Tee (E)	.32	.19	.22	196997	Bearing	3.55	1.95	2.44
196779	Washer (E)	.03	.02	.03	196998	Bearing	3.55	1.95	2.44
196782	Screw (E)	.32	.19	.22	196999	Bearing	3.55	1.95	2.44
196783	Horn	5.14	3.34	3.86					
196788	Cylinder (E)	9.14	4.57	5.94	197004	Use 519284			
196805	Pipe	.72	.36	.45	197005	Use 519286			
196806	Pipe	.87	.44	.56	197006	Use 519287			
196807	Pipe	.82	.41	.51	197007	Use 519288			
196808	Pipe	.46	.24	.30	197008	Use 196543			
196813	Connector (E)	.36	.22	.25	197009	Switch	1.03	.62	.77
196821	Nut	.12	.07	.09	197011	Switch	.57	.34	.42
196822	Clip	.05	.03	.04	197024	Blower	9.00	5.40	6.75
196830	Use 529408X30				197027	Knob	.31	.19	.24
196840	Pipe	.41	.21	.26	197028	Blades	1.54	.93	1.16
196843	Pipe	.87	.44	.56	197029	Ring	.05	.03	.04
196844	Pipe	.98	.49	.61	197031	Use 533257			
196859	Bearing ea. 1.00		.50	.60	197032	Bracket	.25	.15	.19
	In Pkgs. of 5				197034	Cleaner	3.55	2.13	2.66
196860	Spacer	.41	.25	.31	197035	Use 513155			
196865	Snap Ring	.12	.07	.09	197036	Leaf	4.55	2.50	3.13
196867	Sleeve & Tube	1.54	.93	1.16	197038	Use 197057			
196874	Spring ea. .15		.09	.11	197039	Leaf	3.35	1.84	2.30
	In Pkgs. of 5				197040	Use 516946			
196876	Switch	1.15	.69	.86	197041	Use 516945			
196878	Button & Wire	.41	.25	.31	197042	Screw	.12	.07	.09
196879	Sleeve & Tube	.46	.28	.35	197043	Wrench	.51	.31	.39
196880	Gage (E)	2.85	1.54	2.10	197046	Clip	.15	.08	.10

## PARTS PRICE LIST

197 273

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
197047	Clip	.12	.07	.09	197168	Lock & Cable(E)	4.65	2.51	3.26
197048	Cover	1.49	.82	1.03	197170	Lever	1.54	.93	1.16
197049	Cover	1.49	.82	1.03	197174	Pipe	.87	.44	.56
197051	Canvas	.30	.17	.21	197176	Use S-346			
197057	Spring	27.00	14.85	18.57	197177	Use S-346			
197058	Use 516944				197178	Oil Seal	.05	15/.39	15/.49
197063	Use 516945				197182	Use 196300			
197066	Use 516946				197183	Pan	1.23	.80	1.01
197070	Leaf Equip.	4.27	2.35	2.93	197189	Shackle	.62	.31	.39
197082	Washer	ea. .02	.01	.01	197190	Shackle	.25	.13	.16
197083	Washer	ea. .05	.03	.04	197192	Lever	.36	.22	.27
197090	Cover	.07	.04	.05	197207	Use 525962			
197093	Pin (E)	.32	.19	.22	197208	Tank	15.85	9.51	11.89
197094	Washer (E)	.03	10/.20	10/.25	197213	Washer & Retainer	.75	.38	.45
197095	Washer (E)	.06	.04	.05	197214	Retainer	.25	.15	.19
197096	Spring (E)	.25	.15	.18	197215	Cover	.12	.07	.09
197097	Fitting (E)	ea. .22	.13	.15	197216	Washer	.20	5/.50	5/.60
197098	Post	8.49	5.51	6.89	197219	Clevis	.41	.25	.31
197100	Ring	ea. .02	.01	.01	197220	Cam	1.49	.89	1.12
197101	Cup	.82	.49	.62	197221	Fork	2.31	1.39	1.74
197102	Shaft	5.66	3.68	4.61	197222	Shaft	1.80	1.08	1.35
197103	Shaft	5.66	3.68	4.61	197223	Gasket	ea. .06	.03	.04
197104	Use 680211				197225	Gasket	ea. .06	.03	.04
197105	Use 680211				197226	Lever	.31	.19	.24
197106	Retainer	.41	.25	.31	197227	Washer	.08	.05	.06
197107	Cover	.82	.49	.62	197230	Ring	.07	4/.16	4/.20
197108	Gasket	ea. .06	5/.17	.05	197231	Spring	ea. .12	.07	.09
197109	Shim	ea. .03	.02	.03	197232	Spring	.12	.07	.09
197110	Shim	ea. .03	.02	.03	197233	Gasket	.05	10/.30	10/.38
197111	Housing	7.05	4.58	5.72	197235	Ring	.05	.03	.04
197112	Housing	8.49	5.51	6.89	197236	Use 525972			
197114	Use 676260				197237	Rod	1.29	.77	.97
197116	Gasket	ea. .02	.01	.01	197238	Pawl	1.75	1.05	1.32
197117	Cover	.41	.25	.31	197239	Ring	.07	3/.12	3/.15
197118	Cylinder (E)	4.30	2.15	2.80	197240	Ring	.07	4/.16	4/.20
197120	Cylinder (E)	4.19	2.10	2.72	197241	Ring	.07	4/.16	4/.20
197122	Piston (E)	ea. .47	.28	.33	197242	Ring	.07	4/.16	4/.20
197123	Piston(E)	ea. .40	.24	.28	197246	Gasket	ea. .05	.03	.04
197124	Use 636747				197247	Bushing	ea. .25	.15	.19
197125	Spring (E)	.12	.07	.08	197248	Bushing	ea. .25	.15	.19
197126	Cup (E)	ea. .26	.13	.16	197249	Shaft	ea. .51	.31	.39
197127	Boot (E)	ea. .26	.13	.16	197250	Countershaft	1.03	.57	.71
197129	Plate (E)	6.90	3.80	4.75	197251	Shoe	ea. .77	.46	.58
197133	Lever (E)	ea. .36	.20	.25	197252	Fork	1.65	.99	1.23
197135	Strut (E)	.10	.06	.08	197255	Cover	.41	.25	.31
197136	Pin (E)	.05	4/.12	4/.15	197256	Gasket	ea. .10	.05	.06
197138	Spring	.17	.09	.11	197258	Hub	4.35	2.39	2.99
197143	Hanger	1.59	1.03	1.29	197259	Hub & Drum	13.25	7.29	9.11
197151	Relay Kit (E)	4.40	2.38	3.08	197260	Hub & Drum	13.25	7.29	9.11
197157	Rod	5.40	2.97	3.71	197263	Gear	3.96	2.18	2.73
197160	Rod	.87	.52	.66	197266	Solenoid	9.77	5.86	7.33
197163	Clamp	ea. .12	.07	.09	197267	Shaft	10.80	5.95	7.44
197164	Axle	136.29	88.59	110.74	197269	Oil Seal	1.10	.55	.66
197167	Filter	1.49	.89	1.12	197270	Baffle	ea. .10	.06	2/.15
					197271	Plate	.12	3/.21	3/.26
					197272	Plunger	.77	.46	.58
					197273	Bearing	.95	.47	.57

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
197275	Bearing	3.45	1.64	2.05	197376	Gear	6.50	3.58	4.48
197276	Bearing	3.75	1.78	2.23	197385	Washer	.03	5/.10	5/.13
197280	Flange	4.53	2.72	3.39	197387	Plate	.87	.52	.66
197281	Clip	.03	.02	.03	197388	Plate	.87	.52	.66
197285	Shaft	11.83	7.10	8.88	197389	Gasket	.03	10/.15	10/.19
197286	Shaft & Gears	35.23	19.38	24.22	197390	Joint	12.45	6.85	8.57
197287	Flange	2.15	1.29	1.61	197391	Shim	.04	5/.10	5/.13
197288	Gear	7.46	4.10	5.13	197392	Shim	.04	5/.10	5/.13
197292	Weight (E)	.40	.22	.28	197394	Button & Wire	.51	.31	.39
197293	Spring Set (E)	.31	.17	.22	197395	Button & Wire	.51	.31	.39
197295	Camshaft (E)	2.30	1.24	1.61	197396	Sleeve & Tube	.46	.28	.35
197299	Screw	.20	.11	.13	197398	Use 1 ea. 523092 & 523093			
197303	Housing	13.37	8.69	10.86	197401	Stop	.01	2/.01	.01
197304	Plug	.03	5/.10	5/.13	197402	Nut	.05	8/.22	8/.28
197305	Sleeve	4.63	2.55	3.19	197403	Facing	2/2.88	2/1.44	2/1.81
197306	Ring	1.49	.89	1.12	197409	Insulator	.03	.02	.03
197307	Brush (E) * In Pkgs. of 50	ea. .40	.22	.28	197412	Tube	.20	.12	.15
197309	Thrust Washer In Pkgs. of 10	ea. .01	2/.01	.01	197413	Muffler	7.50	4.13	4.88
197310	Armature (E)	9.75	5.27	6.83	197417	Pin	.46	.28	.35
197311	Plate (E)	2.05	1.11	1.44	197426	Pin	.41	.25	.31
197312	Shield (E)	.67	.36	.47	197433	Bracket	.46	.28	.35
197313	Drive (E)	5.55	3.33	3.89	197435	Lifter In Pkgs. of 6	ea. 1.03	.57	.71
197314	Spring (E)	.70	.38	.49	197436	Gasket	.06	5/.17	5/.21
197315	Pin	.02	10/.10	10/.13	197437	Grommet	.03	.02	.03
197316	Plate (E)	.23	.12	.16	197440	Pulley	1.20	.72	.90
197317	Ring	.05	4/.12	4/.15	197443	Use 197444			
197318	Shaft (E)	3.35	1.81	2.35	197444	Lifter In Pkgs. of 6	ea. 1.03	.57	.71
197319	Spring (E)	.16	.09	.11	197446	Wheel	14.91	8.95	11.19
197320	Pinion (E)	2.10	1.13	1.47	197449	Use 196443			
197321	Spring (E)	.16	.09	.11	197462	Cable (E)	.11	2/.12	2/.16
197322	Lock In Pkgs. of 4	ea. .05	.03	.04	197467	Spring (E)	.25	.14	.18
197323	Pinion In Pkgs. of 4	10.50	5.78	7.23	197468	Gear	2.50	1.50	1.88
197324	Cluster	15.17	8.34	10.43	197469	Pinion	1.75	1.05	1.31
197325	Plate	8.23	4.94	6.17	197470	Pinion	1.75	1.05	1.31
197329	Gasket In Pkgs. of 5	ea. .14	.08	.10	197471	Relay	1.39	.70	.83
197330	Valve	.34	.20	.25	197476	Spring In Pkgs. of 5	ea. .20	.12	.15
197331	Valve	.34	.20	.25	197480	Transmission	79.72	51.82	64.78
197335	Jet	.41	.25	.31	197482	Cartridge (E)	See Pink Sheet on Fram Filters		
197337	Plug	.14	.08	.10	197483	Support	.12	.07	.09
197338	Rod	.41	.25	.31	197485	Gasket (E) In Pkgs. of 10	ea. .10	.05	.06
197339	Rod	.41	.25	.31	197486	Cover	.51	.31	.39
197340	Rod	.41	.25	.31	197489	Bar	12.50	7.50	9.38
197343	Jet	.41	.25	.31	197491	Bar	1.90	1.14	1.43
197344	Jet	.37	.22	.28	197492	Bar	1.59	.96	1.19
197345	Jet	.27	.16	.20	197494	Bolt	.12	.07	.09
197346	Plunger	.95	.57	.71	197500	Lever	.36	.22	.27
197347	Spring	.14	.08	.10	197501	Lever	.36	.22	.27
197348	Jet	.27	.16	.20	197504	Matched Rods	21.60	12.96	16.20
197351	Link	.07	.04	.05			See Green Section		
197352	Rod	.34	.20	.25	197505	Rod	See Green Section		
197353	Link	.14	.08	.10	197506	Motor (E)	41.15	22.22	28.81
197354	Spring	.07	.04	.05	197508	Rod	.36	.22	.27
197355	Spring	.14	.08	.10	197511	Bracket	1.03	.62	.77
197357	Shaft	1.01	.61	.76	197513	Bracket	.62	.37	.46
197361	Screw	.03	.02	.03	197526	Armature (E)	10.40	5.62	7.28
197362	Body	2.97	1.78	2.23	197527	Plate (E)	2.25	1.22	1.58
197364	Spring	.14	.08	.10	197544	Spring	.13	.08	.09
197370	Gasket In Pkgs. of 5	ea. .08	.05	.06	197545	Oil Seal	.11	.07	.08
197371	Spacer	.47	.28	.35	197546	Retainer	.02	10/.10	10/.13
197374	Case	16.71	10.86	13.58	197547	Retainer	.02	.01	.01
					197551	Rod	.77	.46	.58
					197552	Use 520400			
					197553	Clevis	.41	.25	.31



## PARTS PRICE LIST

198 038

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
197558	Washer In Pkgs. of 10	ea. .03	.02	.03	197817	Ring In Pkgs. of 6	ea. .60	.30	.36
197561	Bracket	1.29	.83	1.04	197821	Ring In Pkgs. of 6	ea. .60	.30	.36
197563	Cover	2.83	1.56	1.95	197822	Ring In Pkgs. of 6	ea. .60	.30	.36
197565	Insulator In Pkgs. of 6	ea. .30	.18	.23	197823	Use 516003			
197566	Use 522329				197825	Ring	.85	.51	.60
197570	Shaft	10.25	5.95	7.44	197827	Use 516007			
197571	Housing	55.03	35.77	44.72	197830	Piston	5.40	2.97	3.71
197572	Neck	2.06	1.23	1.54	197837	Piston	5.40	2.97	3.71
197575	Hanger	1.39	.91	1.13	197838	Piston	5.40	2.97	3.71
197576	Hanger	1.39	.91	1.13	197839	Piston	5.40	2.97	3.71
197578	Hanger	.87	.57	.71	197840	Piston	5.40	2.97	3.71
197587	Leaf	4.30	2.37	2.96	197841	Piston	5.40	2.97	3.71
197591	Washer	.20	5/.50	5/.60	197842	Piston	5.40	2.97	3.71
197592	Slinger	.10	2/.12	2/.15	197853	Regulator	9.26	5.55	6.48
197595	Use 520949				197857	Button	1.29	.77	.97
197596	Spring	21.60	11.88	14.85	197859	Blades	3.03	1.82	2.27
197598	Spring	19.80	10.89	13.62	197861	Shaft	10.25	5.95	7.44
197599	Use 520941				197878	Float	1.08	.65	.81
197600	Wheel	7.20	4.32	5.40	197879	Valve	1.08	.65	.81
197602	Ring	3.50	2.10	2.63	197880	Gasket In Pkgs. of 5	ea. .14	.08	.10
197603	Pulley	3.15	1.89	2.36	197883	Spacer	.10	.06	.08
197619	Arm	.17	.10	.13	197889	Fork & Lever	1.13	.68	.85
197632	Shaft & Lever	4.32	2.59	3.24	197893	Bar	6.50	2.60	3.57
197636	Shaft & Lever	4.32	2.59	3.24	197894	Bar	1.44	.86	1.08
197644	Arm	.25	.15	.19	197895	Use 197896			
197645	Use 679789				197896	Bar	1.44	.86	1.08
197646	Wheel-Prime	13.95	7.67	9.59	197897	Housing	57.60	37.44	46.80
197650	Arm	2.31	1.39	1.74	197899	Bar	1.29	.77	.97
197651	Arm	2.42	1.45	1.81	197900	Bar	1.29	.77	.97
197654	Bushing	.25	.15	.19	197901	Rod	.62	.37	.46
197655	Pin	.25	.15	.19	197902	Rod	.62	.37	.46
197656	Cover Kit	3.86	2.31	2.89	197904	Bar	10.00	4.00	5.50
197665	Ring In Pkgs. of 4	ea. .07	.04	.05	197905	Bar	1.70	1.03	1.28
197666	Ring	.07	4/.16	4/.20	197906	Bar	1.23	.74	.93
197676	Hanger	.25	.15	.19	197911	Arm	4.37	2.62	3.28
197685	Frame	79.41	51.62	64.52	197912	Cover (E)	17.00	9.35	11.69
197689	Steering Gear	28.29	18.39	22.99		See Green Section			
197693	Use 523821				197918	Arm	2.73	1.64	2.05
197696	Jacket	3.55	2.13	2.66	197924	Bracket	1.70	1.03	1.29
197698	Jacket	3.55	2.13	2.66	197934	Switch	.87	.52	.66
197714	Cap	2.67	1.49	1.86	197936	Ring	.12	.07	.09
197723	Spacer (E)	.38	.23	.27	197941	Knob	.31	.19	.24
197724	Grommet (E)	.07	.04	.05	197942	Knob	.31	.19	.24
197730	Post & Worm	9.77	6.36	7.95	197963	Arm	2.57	1.54	1.93
197732	Post & Worm	9.51	6.17	7.71	197964	Arm	2.57	1.54	1.93
197733	Post & Worm	9.51	6.17	7.71	197968	Facing	2/2.52	2/1.29	2/1.60
197734	Arm	2.31	1.39	1.74	197969	Arm	2.57	1.54	1.93
197735	Arm	2.31	1.39	1.74	197988	Engine	See Green Section		
197736	Bracket	2.21	1.33	1.66	197992	Generator (E)	40.20	21.71	28.14
197737	Bracket	2.21	1.33	1.66					
197741	Bracket	.72	.43	.55	198004	Washer	.01	20/.10	20/.13
197744	Pin	4.63	2.78	3.48	198005	Arm	4.37	2.62	3.28
197745	Pin	4.63	2.78	3.48	198006	Adapter	1.70	1.03	1.28
197746	Yoke	2.57	1.54	1.93	198007	Nut	.02	.01	.01
197747	Yoke	2.57	1.54	1.93	198008	Bracket	1.25	.75	.94
197787	Adapter	1.70	1.02	1.28	198011	Rod	.62	.37	.46
197789	Insulator	.20	.10	.13	198020	Rod	1.13	.68	.85
197798	Member	3.60	2.35	2.93	198022	Use 523336			
197801	Arm	3.09	1.85	2.31	198023	Use 523337			
197802	Arm	3.09	1.85	2.31	198025	Use 523339			
197805	Housing	10.54	6.85	8.57	198034	Hub & Drum	18.95	10.42	13.03
197806	Use 527421				198035	Hub & Drum	18.95	10.42	13.03
197807	Bushing & Retainer	1.03	.62	.77	198036	Hub & Drum	15.00	8.25	10.31
197809	Bushing	.12	.07	.09	198037	Hub & Drum	15.00	8.25	10.31
					198038	Drum	9.50	5.23	6.54

The symbols used in this book are explained on Page III.

33

December 1, 1953 - Printed in U. S. A.

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
198039	Drum	8.50	4.68	5.85	198392	Gasket	.07	.04	.05
198061	Block	ea. .31	.19	.24	198393	Strainer	.14	.08	.10
	In Pkgs. of 10				198396	Clip	.15	.08	.10
198074	Arm	2.31	1.39	1.74	198405	Use 513448			
198076	Bushing	.30	.18	.23	198406	Use 513449			
198077	Shaft	.77	.46	.58	198408	Muffler	9.00	4.95	6.19
198078	Washer	.05	5/.15	5/.19	198413	Relay	1.50	.75	.90
198079	Washer	.03	5/.10	5/.13	198432	Housing	7.20	4.68	5.85
198082	Rod	.87	.52	.66	198434	Housing	7.46	4.84	6.06
198085	Speedometer	15.00	9.00	11.25	198436	Shaft	6.69	4.35	5.44
198091	Coil (E)	6.85	3.70	4.80	198437	Shaft	6.17	3.70	4.63
198099	Coil (E)	6.85	3.70	4.80	198439	Use 525907			
198110	Harness	5.91	3.55	4.43	198441	Gasket	.03	5/.09	5/.11
198111	Lock & Cable (E)	6.40	3.46	4.48	198444	Seal	.05	.03	.04
198113	Lock & Cable (E)	4.73	2.84	3.55	198466	Carbureter	23.50	12.93	16.16
198118	Bearing & Collar	4.50	2.25	2.70	198489	Rod	.55	.33	.41
198119	Washer	ea. .05	.03	.04	198490	Rod	.25	.15	.19
	In Pkgs. of 5				198493	Carbureter	35.00	19.25	24.06
198123	Arm	2.83	1.70	2.12	198503	Muffler	9.50	5.23	6.18
198125	Bumper	2.21	1.49	1.82	198510	Cleaner	5.35	3.21	4.01
198126	Bumper	2.21	1.49	1.82	198514	Gear	2.50	1.50	1.88
198127	Adapter	3.09	1.85	2.31	198515	Gear	2.50	1.50	1.88
198129	Core	48.50	24.25	31.53	198516	Pinion	1.75	1.05	1.31
198132	Core	55.00	27.50	35.75	198517	Pinion	1.75	1.05	1.31
198149	Switch	.57	.34	.42	198518	Shaft	1.29	.77	.97
198180	Rod	5.40	2.97	3.71	198520	Rod	.36	.22	.27
198181	Cable	.72	.43	.55	198526	Cylinder (E)	10.00	5.00	6.50
198189	Use 195944				198537	Shaft	3.60	2.16	2.71
198190	Knob	.31	.19	.24	198540	Bushing	.12	.07	.09
198193	Knob	.25	.15	.19	198547	Lever	.31	.19	.24
198195	Gage	2.83	1.70	2.13	198555	Shaft	4.32	2.59	3.24
198196	Frame	54.00	35.11	43.88	198557	Fork & Lever	1.13	.68	.85
198198	Frame	54.00	35.11	43.88	198567	Bracket	.31	.19	.24
198202	Arm	2.83	1.70	2.12	198579	Rod Assy.	6.43	3.54	4.42
198204	Knob	.31	.19	.24	198580	Rod Assy.	6.43	3.54	4.42
198208	Adapter	3.09	1.85	2.31	198588	Rod	5.15	2.83	3.54
198213	Button & Wire	.41	.25	.31	198605	Armature (E)	14.80	7.99	10.36
198214P	Bracket	.25	.15	.19		Add \$1.00 net charge pending return of old armature			
198215P	Bracket	.62	.37	.46	198607	Plate (E)	3.60	1.94	2.52
198243	Harness	5.91	3.55	4.43	198608	Plate (E)	5.05	2.73	3.54
198257	Bracket	.20	.12	.15	198611	Use 196296			
198258	Rod	1.13	.68	.85	198612	Resistance (E)	.16	.09	.11
198268	Bracket	.31	.19	.24	198648	Coil	3.86	2.31	2.89
198274	Screw	.25	.15	.19	198649	Gasket	ea. .03	.02	.03
198276	Seal (E)	ea. .12	.06	.08		In Pkgs. of 5			
	In Pkgs. of 10				198650	Cover	.17	.10	.13
198277	Washer	.05	.03	.04	198651	Stud	.15	.09	.11
198294	Plate	.05	.03	.04	198653	Tee	.30	.18	.23
198305	Horn	5.14	3.34	3.86	198667	Terminal	.02	20/.20	20/.25
198306	Horn	5.66	3.68	4.25	198685	Bushing	.12	8/.48	8/.50
198307	Horn	5.66	3.68	4.25					
198330	Harness	6.25	3.75	4.69	198694	Radimeter	4.89	2.93	3.66
198331	Harness	5.40	3.24	4.05	198701	Glass	.41	.25	.31
198353	Shaft	4.32	2.59	3.24	198702	Gage	2.31	1.39	1.74
198360	Gasket	ea. .06	.04	.05	198703	Ammeter	1.80	1.08	1.35
	In Pkgs. of 4				198704	Gage	3.45	2.07	2.59
198371	Shaft	4.32	2.59	3.24	198705	Glass	1.34	.80	1.00
198377	Lever	1.54	.93	1.16	198739	Pipe	.57	.34	.42
198378	Manifold	15.69	10.19	12.74	198740	Rod	.77	.46	.58
198380	Cleaner	4.99	2.99	3.74	198750	Plate	.12	5/.35	5/.44
198382	Element	.77	.46	.58	198765	Strap	.25	.15	.19
198383	Element	.87	.52	.66	198769	Rod	.20	4/.48	4/.60
198384	Element	.74	.51	.51	198770	Rod	.20	4/.48	4/.60
198385	Cover	.51	.31	.39	198771	Use 525510			
198386	Cover	.72	.43	.55	198772	Pulley (E)	3.40	1.84	2.38
198388	Seal	.50	.25	.30	198777	Cover	.17	.10	.13
198391	Nut	.36	.22	.28	198778	Flange	2.57	1.54	1.93

## PARTS PRICE LIST

199 135

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
198779	Seal	1.10	.55	.66	198959	Washer	.05	.03	.04
198784	Shaft	10.29	5.66	7.08	198962	Case	14.40	9.36	11.71
198788	Rod (E)	.47	.28	.33	198963	Cover	.46	.28	.35
198793	Plate (E)	3.60	1.94	2.52	198964	Gasket	ea. .10	.05	.06
198794	Cover (E)	.10	.05	.07		In Pkgs. of 5			
198795	Plate (E)	5.10	2.75	3.57	198965	Shaft & Gears	36.00	19.80	24.75
198804	Shaft & Gears	33.94	18.67	23.34	198966	Shaft & Gears	34.46	18.96	23.70
198810	Shaft	12.24	6.74	8.42	198967	Gear	5.66	3.12	3.9
198816	Shaft	1.23	.74	.93	198968	Sleeve	5.66	3.12	3.90
198818	Shaft	.72	.43	.55	198970	Plate	.12	3/.21	3/.26
198820	Facing	1.90	.96	1.19	198971	Ring	.08	2/.10	2/.13
198824	Oil Pan	5.04	3.02	3.79	198972	Shoe	.62	.37	.46
198832	Carbureter	14.20	8.52	10.65	198973	Fork	1.95	1.17	1.47
	See Green Section				198974	Flange	3.03	1.82	2.27
198833	Link	.14	.08	.10	198975	Seal	1.70	.85	1.02
198834	Body	2.97	1.78	2.23	198979	Plunger	.15	.09	.11
198852	Pedal	2.06	1.23	1.54	198983	Plunger	.62	.37	.46
198853	Pedal	2.31	1.39	1.74	198984	Housing	13.89	9.03	11.29
198867	Plate (E)	8.10	4.46	5.58	198985	Gasket	ea. .06	.03	.04
198868	Spring (E)	.25	.14	.18		In Pkgs. of 5			
198869	Clip	.03	.02	.03	198986	Plate	7.71	4.63	5.79
198870	Deflector-Prime	2.31	1.39	1.74	198987	Gasket	ea. .06	.03	.04
198873	Deflector-Prime	2.06	1.23	1.54		In Pkgs. of 5			
198877	Spring	.15	.09	.11	198988	Gear	13.63	8.18	10.22
198881	Generator (E)	70.15	37.88	49.11	198989	Ring	2.16	1.30	1.63
198882	Regulator (E)	13.35	7.21	9.35	198990	Plate	ea. 1.49	.89	1.12
	See Green Section					In Pkgs. of 12			
198885	Shaft (E)	3.40	1.84	2.38	198991	Pawl	1.75	1.05	1.32
198886	Shaft (E)	3.65	1.97	2.56	199006	Screw	ea. .06	.04	.05
198887	Core (E)	.87	.47	.61		In Pkgs. of 10			
198888	Core (E)	1.03	.56	.72	199008	Bolt	.15	.09	.11
198889	Core (E)	1.08	.58	.76	199013	Wheel	7.20	4.32	5.40
198900	Float	1.00	.60	.75	199014	Wheel	15.94	9.57	11.96
198901	Valve	1.08	.65	.81	199022	Cable	.17	.09	.11
198902	Gasket	ea. .14	.08	.10	199028	Lamp Kit	22.27	13.52	16.91
	In Pkgs. of 5				199035	Brush	.26	.13	.16
198903	Jet	.41	.25	.31	199036	Spring	ea. .05	.03	.04
198904	Gasket	.07	.04	.05		In Pkgs. of 10			
198905	Plug	.14	.08	.10	199037	Arm	ea. .21	.13	.15
198907	Jet	.41	.25	.31		In Pkgs. of 5			
198908	Jet	.41	.25	.31	199040	Screw	.03	.02	.03
198909	Plug	.14	.08	.10	199042	Armature	12.34	6.17	7.41
198910	Plunger	.95	.57	.71		Add \$1.00 net charge pending return of old armature			
198913	Plug	.14	.08	.10	199046	Use 195746			
198916	Use 1 ea. 526013, 526015				199050	Retainer	.46	.28	.35
198917	Piston	.37	.22	.28	199073	Plate	8.23	4.94	6.17
198919	Link	.31	.19	.24	199074	Pawl	1.75	1.05	1.32
198920	Cap	.31	.19	.24	199081	Use 199083			
198921	Pin	.03	.02	.03	199082	Use 199083			
198922	Spring	.14	.08	.10	199083	Spring	35.23	19.38	24.22
198925	Lever	ea. .24	.14	.18	199084	Use 195823			
	In Pkgs. of 5				199085	Spring	33.94	18.67	23.34
198926	Gasket	ea. .14	.08	.10	199086	Use 199085			
	In Pkgs. of 5				199091	Cover	1.49	.82	1.03
198927	Gasket	ea. .14	.08	.10	199092	Cover	1.49	.82	1.03
	In Pkgs. of 5				199105	Cable	2.57	1.42	1.78
198928	Valve	.27	.16	.20	199108	Gasket	ea. .07	2/.07	.05
198929	Gasket	ea. .07	.04	.05		In Pkgs. of 10			
	In Pkgs. of 5				199109	Shaft & Gears	34.46	18.96	23.70
198930	Strainer	ea. .20	.12	.15	199111	Ring	ea. .07	.04	.05
	In Pkgs. of 5					In Pkgs. of 25			
198931	Shaft	.74	.44	.55	199116	Pipe	3.90	2.15	2.54
198933	Pin	.03	.02	.03	199119	Support	.31	.19	.24
198934	Lever	.41	.25	.31	199133	Gear	1.20	.66	.83
198935	Coil	2.70	1.62	2.03	199134	Use 524882			
198936	Retainer	.03	.02	.03	9135	Bumper	.36	.22	.27
198937	Screw	.03	.02	.03					
198938	Valve	.14	.08	.10					

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
199140	Screw	ea. .05	.03	.04	199343	Bracket	1.39	.83	1.04
	In Pkgs. of 10				199347	Arm	2.57	1.54	1.93
199142	Use 519084				199348	Arm	2.57	1.54	1.93
199150	Plate	ea. .05	.03	.04	199365	Plate	3.60	2.16	2.71
	In Pkgs. of 4				199367	Seat	.72	.43	.55
199151	Plate	1.08	.65	.81	199372	Flange	1.08	.65	.81
199152	Plate	1.08	.65	.81	199373	Flange	1.08	.65	.81
199159	Link	1.00	.60	.75	199374	Pipe	3.25	1.79	2.11
199177	Retainer	ea. .08	.05	.06	199378	Bushing	.50	.28	.35
	In Pkgs. of 10				199379	Seal	1.35	.68	.81
199194	Bracket	.20	.12	.15	199381	Shim	.05	5/.15	5/.19
199198	Use 678708				199382	Shim	.05	5/.15	5/.19
199199	Use 678709				199383	Bolt	.20	.12	.15
199203	Use 520345				199385	Washer	.07	4/.16	4/.20
199204	Use 520346				199387	Bolt	.25	.15	.19
199207	End	2.31	1.28	1.59	199388	Bushing	.17	8/.64	8/.80
199208	End	2.31	1.28	1.59	199390	Shim	ea. .05	.03	.04
199209	End	3.60	1.99	2.48		In Pkgs. of 20			
199210	End	4.11	2.26	2.83	199391	Shim	ea. .05	.03	.04
199211	End	4.11	2.26	2.83		In Pkgs. of 20			
199212	End	4.11	2.26	2.83	199392	Shim	ea. .08	.05	.06
199213	End	4.11	2.26	2.83		In Pkgs. of 20			
199216	Member	2.42	1.57	1.96	199393	Shim	ea. .08	.05	.06
199220	Sleeve	.50	.30	.38		In Pkgs. of 20			
199222	Bushing	.12	.07	.09	199394	Arm	3.09	1.85	2.31
199227	Retainer	.03	2/.03	.02	199395	Arm	3.09	1.85	2.31
199228	Shaft	1.95	1.17	1.47	199396	Knuckle	8.74	5.25	6.56
199230	Shaft	1.23	.74	.93	199397	Knuckle	8.74	5.25	6.56
199233	Shaft	.77	.46	.58	199400	Plate (E)	8.60	4.64	6.02
199234	Spring	.25	.15	.19	199401	Armature (E)	23.90	12.91	16.73
199235	Cylinder (E)	9.50	4.75	6.18		Add \$1.00 net charge pending return of old armature			
199239	Strap	ea. .03	.02	.03	199402	Plate (E)	3.10	1.67	2.17
	In Pkgs. of 10				199409	Clip	.15	.08	.10
199249	Lever & Shaft	2.20	1.32	1.65	199412	Arm	2.57	1.54	1.93
199251	Poppet	.57	.34	.42	199413	Arm	2.57	1.54	1.93
199253	Cable	3.03	1.67	2.09	199415	Yoke	2.73	1.64	2.05
199254	Pedal	2.73	1.64	2.05	199416	Yoke	2.73	1.64	2.05
199255	Pedal	2.73	1.64	2.05	199418	Bolt	.20	.12	.15
199271	Spacer	.03	.02	.03	199423	Cover	3.34	2.01	2.51
199278	Outlet	1.40	.84	1.05	199428	Pulley	5.14	3.34	4.18
199279	Plate	ea. .05	.03	.04	199429	Slinger	.12	.07	.09
	In Pkgs. of 4				199430	Pin	.77	.42	.52
199282	Poppet	.46	.28	.35	199432	Rod	.62	.37	.46
199285	Core	17.23	10.34	12.92	199434	Rod	.62	.37	.46
199288	Clip	.12	.07	.09	199435	Spring	ea. .20	.12	.15
199293	Core	42.50	21.25	27.63		In Pkgs. of 10			
199294	Pipe	3.50	1.93	2.28	199438	Plug	.30	.18	.23
199300	Use 524114				199439	Axle	136.29	88.59	110.74
199302	Switch	.87	.52	.66	199440	Axle	136.29	88.59	110.74
199304	Washer	.07	.04	.05	199441	Blades	1.54	.93	1.16
199305	Spring	.05	.03	.04	199442	Nut	.62	.37	.46
199307	Pipe	.57	.34	.42	199444	Flywheel	5.14	3.09	3.86
199308	Arm	9.51	5.71	7.14	199445	Pipe	3.50	1.93	2.41
199309	Pin	4.63	2.78	3.48	199447	Pipe	4.25	2.34	2.76
199310	Thermostat	1.59	.80	1.00	199460	Cover	3.34	2.01	2.51
199313	Yoke	2.73	1.64	2.05	199462	Shaft	1.23	.74	.93
199314	Yoke	2.73	1.64	2.05	199464	Hanger	.25	.15	.19
199315	Pin	5.14	3.09	3.86	199465	Bracket	.25	.15	.19
199316	Pin	5.14	3.09	3.86	199469	Neck	2.06	1.23	1.54
199318	Yoke	2.57	1.54	1.93	199474	Member	2.42	1.57	1.96
199319	Yoke	2.57	1.54	1.93	199475	Shaft	1.25	.75	.94
199323	Flange	.46	.28	.35	199477	Rod	.31	.19	.24
199325	Bracket	1.13	.68	.85	199480	Rod	ea. .31	.19	.24
199326	Bracket	1.13	.68	.85		In Pkgs. of 10			
199328	Bracket	1.29	.77	.97	199481	Rod	ea. .31	.19	.24
199332	Arm	2.31	1.39	1.74		In Pkgs. of 10			
199333	Arm	2.31	1.39	1.74	199483	Use 525959			
199342	Bracket	1.39	.83	1.04					

## PARTS PRICE LIST

199 953

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
199485	Muffler	9.50	5.23	6.18	199719	Clip	.15	.08	.10
199488	Use 525975				199720	Cover	1.49	.82	1.03
199489	Neck	2.06	1.23	1.54	199721	Cover	1.49	.82	1.03
199490	Shaft	1.39	.83	1.04	199723	Use 199724			
199493	Pin	.05	5/.15	5/.19	199724	Cover	1.49	.82	1.03
199496	Impeller	1.80	1.08	1.35	199727	Canvas	.30	.17	.21
199502	Bar	8.00	3.20	4.40	199732	Use 676813			
199503	Bar	1.29	.77	.97	199753	Bracket	.51	.31	.39
199504	Bar	1.29	.77	.97	199759	Rod	.25	.15	.19
199506	Bar	1.44	.86	1.08	199761	Screw	.08	.05	.06
199507	Bar	1.44	.86	1.08	199763	Shaft	1.70	1.03	1.29
199508	Bar	1.44	.86	1.08	199767	Pipe	3.25	1.79	2.24
199509	Bar	1.44	.86	1.08	199769	Support	.41	.25	.31
199512	Washer	ea. .35	.21	.26	199770	Clamp	.20	.12	.15
	In Pkgs. of 20				199778X1	Bumper	3.09	2.06	2.57
199515	Damper	14.35	9.33	11.66	199779X1	Bumper	3.09	2.06	2.57
199516	Member	3.60	2.35	2.93	199781	Support	.41	.25	.31
199519	Jacket	3.55	2.13	2.66	199782	Clamp	.20	.12	.15
199533	Core	81.00	46.98	56.70	199802	Engine	See Green Section		
199534	Core	72.50	42.05	50.75	199820	Engine	See Green Section		
199540	Bar	11.50	4.60	6.33	199821	Use 522000			
199541	Bar	6.75	4.05	5.06	199825	Sleeve (E)	.13	.08	.09
199546	Bolt	ea. .25	.15	.19	199826	Lever (E)	.73	.44	.51
	In Pkgs. of 10				199827	Rod	See Green Section		
199547	Spacer	.41	.25	.31	199828	Rod	See Green Section		
199548	Plate	.17	.10	.13	199849	Button	1.29	.77	.97
199551	Hose	1.75	.96	1.14	199854	Use 199014			
199552	Hose	1.25	.69	.81	199856	Knob	.31	.19	.24
199553	Clamp	.12	.07	.09	199858	Button & Wire	.41	.25	.31
199556	Rod	.31	.19	.24	199861	Use 527910			
199570X1	Bumper	4.11	2.47	3.09	199862	Support	.31	.19	.24
199571	Hose	1.35	.74	.88	199863	Use 519036			
199574X1	Bumper	3.09	1.85	2.31	199874	Spacer	.12	.07	.09
199575X1	Bumper	3.09	1.85	2.31	199881	Bracket	.93	.61	.76
199608	Coil (E)	7.10	3.83	4.97	199882	Pipe	.82	.41	.51
199610	Switch & Cable (E)				199884	Pipe	.87	.44	.56
		4.00	2.16	2.80	199885	Pipe	.98	.49	.62
199611	Coil (E)	5.65	3.05	3.96	199886	Pipe	.98	.49	.62
199616	Coil (E)	6.85	3.70	4.80	199888	Bar	20.00	8.00	11.00
199619	Cover	.15	.09	.11	199889	Bar	1.70	1.02	1.28
199621	Washer	.10	.06	.08	199890	Bar	1.70	1.02	1.28
199624	Hanger	1.59	1.03	1.29	199891	Bar	1.29	.77	.97
199625	Hanger	1.59	1.03	1.29	199892	Bar	1.29	.77	.97
199626P	Shaft	4.32	2.59	3.24	199893	Pipe	.62	.37	.46
199628	Fork & Lever	1.13	.68	.85	199896	Bolt	.15	5/.45	5/.56
199631	Rod	.62	.37	.46	199897	Shaft	.93	.56	.70
199633	Rod	.62	.37	.46	199900	Rod	.62	.37	.46
199635	Jacket	3.55	2.13	2.66	199901	Rod	.62	.37	.46
199637	Member	1.70	1.10	1.38	199902	Shaft	2.01	1.20	1.60
199638	Body	2.57	1.54	1.93	199903	Shaft	2.01	1.20	1.60
199652	Poppet	ea. .57	.34	.42	199909	Bracket	.51	.31	.39
	In Pkgs. of 12				199910	Bracket	.51	.31	.39
199654	Pump	9.77	5.37	6.51	199912	Rod	.31	.19	.24
199655	Impeller	1.95	1.17	1.47	199915	Lever	.36	.22	.27
199660	Member	2.57	1.68	2.10	199918	Use 527420			
199663	Rod	.62	.37	.46	199925	Bracket	.62	.40	.50
199667P	Shaft	4.32	2.59	3.24	199926	Bracket	.62	.40	.50
199675	Washer	ea. .03	.02	.03	199927	Member	4.53	2.94	3.68
	In Pkgs. of 10				199936X1	Wheel	14.91	8.95	11.19
199676	Bracket	.62	.40	.50	199938X1	Use 681091			
199677	Bracket	.62	.40	.50	199942X1	Emblem	.77	.46	.58
199683	Impeller	2.01	1.20	1.50	199943X1	Emblem	.77	.46	.58
199684	Pump	12.86	7.07	8.84	199944X1	Ring	3.34	2.01	2.51
199694	Hanger	1.03	.67	.83	199945	Hub	1.03	.62	.77
199695	Distributor (E)	16.60	8.96	11.62	199950	Member	.93	.61	.76
199697	Use 529278				199951	Support	1.03	.62	.77
199699	Transmission	79.72	51.82	64.78	199952	Cap	.30	.15	.19
199717	Use 515471				199953	Shaft	3.85	1.93	2.31

The symbols used in this book are explained on Page III.

## PARTS PRICE LIST

PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET	PART NO.	NAME	LIST PRICE	DEALER NET	PREF. NET
199954	Use 676714								
199955	Shaft & Weights (E)	5.45	2.94	3.82					
199956X1	Wheel	15.94	9.57	11.96					
199962	Post & Worm	10.50	6.83	8.54					
199963	Post & Worm	10.50	6.83	8.54					
199964	Housing	7.05	4.58	5.72					
199965	Housing	8.49	5.51	6.89					
199967X1	Knob In Pkgs. of 10	ea. .31	.19	.24					
199968X1	Extension	.41	.25	.31					
199984	Plate (E)	6.20	3.72	4.34					
199985	Plate (E)	6.20	3.72	4.34					
199986	Use 2-676580								
199987	Use 676578								
199988	Shoe (E)	3.10	1.86	2.17					
199989	Shoe (E)	2.85	1.71	2.00					
199992	Spring (E)	.25	.15	.18					
199993	Lever (E)	.54	.32	.38					
199994	Lever (E)	.54	.32	.38					
199995	Link (E)	.34	.20	.24					
199996	Link (E)	.34	.20	.24					
199997	Washer (E) In Pkgs. of 10	ea. .03	.02	.03					
199998	Washer (E)	.03	.02	.03					
199999	Washer (E) In Pkgs. of 10	ea. .03	.02	.03					